

Blower Kit
48" Collection System
966046001 CE
Original Instructions

CONTENTS

SAFETY RULES4	OPERATION12
GENERAL OPERATION4	TIPS FOR IMPROVED BAGGING12
SLOPE OPERATION4	GENERAL RECOMMENDATIONS12
CHILDREN5	STORAGE13
SERVICE5	REPAIR PARTS14
ASSEMBLY 8	

CONGRATULATIONS on the purchase of a new collection system. It has been designed, engineered and manufactured to give you the best possible dependability and performance.

Should you experience any problem you cannot easily remedy, please contact your nearest authorized service center/ department. They have competent, well-trained technicians and the proper tools for service and repairs.

Please read and retain this manual. The instructions will enable you to assemble and maintain your collection system properly. Always observe the "SAFETY RULES".

Λ

WARNING!

Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

KNOW YOUR BLOWER SYSTEM

READ THIS OPERATION MANUAL AND SAFETY RULES BEFORE ASSEMBLING OR OPERATING YOUR BLOWER SYSTEM. Compare the illustrations with the carton contents to familiarize yourself with the parts before starting the assembly. Study the operating instructions and safety precautions thoroughly to insure proper functioning of your Grass Catcher and to prevent injury to yourself and others. Save this manual for future reference.



The operation of any mower can result in foreign objects thrown into the eyes, which can result in severe eye damage. ALWAYS wear safety glasses or eye shields before starting your mower and while mowing. Standard safety glasses are recommended or a wide vision safety mask for over spectacles.

SAFETY RULES



SAFE OPERATION PRACTICES FOR RIDE-ON MOWERS



DANGER!

THIS CUTTING MACHINE IS CAPABLE OF AMPUTATING HANDS AND FEET AND THROWING OBJECTS. FAILURE TO OBSERVE THE FOLLOWING SAFETY INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

GENERAL OPERATION

- Read, understand and follow all instructions in the manual and on the machine before starting.
- Only allow responsible adults, who are familiar with the instructions, to operate the machine.
- Clear the area of objects such as rocks, stones, toys, wire etc., which could be picked up and thrown by the blades.
- Be sure the area is clear of all people and pets before mowing. Stop the machine if anyone enters the area.
- Never carry passengers or children even with blades off.
- Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing.
- Be aware of the mower discharge direction and do not direct it towards anyone. Do not operate the mower without either the entire grass catcher or the guard in place.
- Slow down before turning.
- Never leave the machine unattended when the engine is running. Always turn off the blades, set the parking brake, stop the engine and remove the key before leaving the machine.
- Turn off blades when not mowing.
- Stop engine before removing grass catcher or unclogging chute.
- Mow only in daylight or good artificial light.
- Do not operate the machine while under the influence of alcohol or drugs.
- Watch out for traffic when operating near or crossing roadways.
- Use extra care when loading and unloading the machine onto a trailer or truck.
- Data indicates that operators, age 60 years and above, are involved in a large percentage of riding mower-related injuries. These operators should evaluate their ability to operate the riding mower safely enough to protect themselves and others from serious injury.

- **DO NOT** operate mower with grass catcher, unless the front weights are installed.
- Keep machine free of grass, leaves or other debris buildup which can touch hot exhaust/ engine parts and burn. Do not allow the mower deck to plow leaves or other debris which can cause buildup to occur. Clean any oil or fuel spillage before operating or storing the machine. Allow machine to cool before storage.

SLOPE OPERATION

Slopes are a major factor related to loss-of-control and tip-over accidents, which can result in severe injury or death. All slopes require extra caution. If you cannot back up the slope or if you feel uneasy on it, do not mow it.

DO

- Mow up and down slopes (10° Max.), not across.
- Remove obstacles such as rocks, tree limbs, etc.
- Watch for holes, ruts, or bumps. Uneven terrain could overturn the machine. Tall grass can hide obstacles.
- Use slow speed. Choose a low speed so that you will not have to stop while on the slope.
- Use extra care with grass catchers or other attachments. These can change the stability of the machine.
- Keep all movement on the slopes slow and gradual. Do not make sudden changes in speed or direction.
- Avoid starting or stopping on a slope. If tires lose traction, disengage the blades and proceed slowly **straight** down the slope.

SAFETY RULES



SAFE OPERATION PRACTICES FOR RIDE-ON MOWERS



DO NOT

- Do not turn on slopes unless necessary, and then, turn slowly and gradually downhill, if possible.
- Do not mow near drop-off, ditches, or embankments. The mower could suddenly turn over if a wheel is over the edge of a cliff or ditch, or if an edge caves in.
- **Do not** mow on wet grass. Reduced traction could cause sliding.
- **Do not** try to stabilize the machine by putting your foot on the ground.

CHILDREN

Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the machine and the mowing activity. Never assume that children will remain where you last saw them.

- NEVER allow children to operate the machine.
- Keep children out of the mowing area and under the watchful care of another responsible adult.
- Be alert and turn off the machine if children enter the area.
- Before and when backing, look behind and **down** for small children.
- Never carry children. They may fall off and be seriously injured or interfere with safe machine operation.
- Use extra care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.

SERVICE

- The operation of any mower can result in foreign objects thrown into the eyes, which can result in severe eye damage. Always wear safety glasses or eye shields while operating your mower or performing any adjustments or repairs. We recommend a wide vision safety mask over spectacles or standard safety glasses.
- Use extra care in handling gasoline and other fuels. They are flammable and vapors are explosive.
 - Use only an approved container.
 - Never remove gas cap or add fuel with the engine running.
 - Allow engine to cool before refueling.
 - Do not smoke.
 - Never refuel the machine indoors.
 - Never store the machine or fuel container inside where there is an open flame, such as a water heater.
- Never run a machine inside a closed area.
- Keep nuts and bolts, especially blade attachment bolts, tight and keep equipment in good condition.
- Never tamper with safety devices. Check for proper operation regularly.



CAUTION

In order to prevent accidental starting when setting up, transporting, adjusting or making repairs, always disconnect spark plug wire and place wire where it cannot contact spark plug.

SAFETY RULES



SAFE OPERATION PRACTICES FOR RIDE-ON MOWERS



- Stop and inspect the equipment if you strike an object. Repair, if necessary, before restarting.
- Never make adjustments or repairs with the engine running.
- Grass catcher components are subject to wear, damage, and deterioration, which could expose moving parts or allow objects to be thrown.
 Frequently check components and replace with manufacturer's recommended parts, when necessary.
- Mower blades are sharp and can cut. Wrap the blade(s) or wear gloves, and use extra caution when servicing them.
- Check brake operation frequently. Adjust and service as shown in the Operator's Manual.



WARNING!

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals know to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.



WARNING!

DO NOT tow any trailers, etc. with this mower. They may jackknife or over turn causing damage to the mower and possibly serious injury to the operator.

UNPACKING INSTRUCTIONS

Remove all parts and packing materials from carton.


TOOLS REQUIRED

- 7/16" Wrench or ratchet and socket
- 1/2" Wrench or ratchet and socket
- 7/8" Socket
- Torque Wrench
- Phillips Head Screwdriver
- Hacksaw
- Pliers

CONTAINER CONTENTS

- Blower Assembly
- Drive Pulley
- Belt Shield
- Belt
- Mounting Bracket
- Bag of Hardware

Weight



NOTE: When right hand (R.H.) and left hand (L.H.) are mentioned in this manual, it means when you are seated on the mower in the operator's position.




CAUTION

BEFORE ASSEMBLING GRASS CATCHER TO MOWER:


- Set parking brake.
- Place motion control levers in "NEUTRAL" position.
- Turn ignition key "OFF" and remove key.
- Make sure the blades and all moving parts have completely stopped.
- Disconnect spark plug and place wire where it cannot come in contact with plug.

■ INSTALLING DRIVE PULLEY

- Remove the discharge chute from the deck.
 (Deck configuration will vary by size and model)
- 2. Lower deck to the lowest cutting position.
- 3. Remove the right hand (discharge side) belt cover from the deck.
- Relieve the tension from the deck belt and remove from the center deck pulley. (See Operator's Manual if necessary)




- 5. Remove the nut securing the right hand deck pulley to the spindle.
- 6. Install drive pulley included in collection system kit on top of the current deck pulley.
- 7. Reinstall the nut on the spindle and torque to 55-75 ft/lbs.
- 8. Reinstall the deck belt.




2 MOUNTING BLOWER ASSEMBLY

- 1. Position blower over the discharge tabs on the deck and set blower onto the deck.
- 2. Be sure the blower is sitting flush against the outside of the deck.




3. Install the front mount bracket to the deck with the bolt, washers and nut supplied with the kit.




3 INSTALLING DRIVE BELT

- 1. Make sure the tension release lever is forward or disengaged.
- 2. Place the belt over the pulley on the deck. Refer to illustration for proper routing.
- 3. Move the tension release arm to the rear and engage in the latch.




INSTALLING BELT COVERS

- 1. Using a hacksaw, trim the belt cover along the dashed line.
- 2. Place the deck belt shield on the deck over the drive pulley and secure with hardware removed from steel belt shield.
- 3. Place retainer on the outer pulley cover.
- 4. Align the tab end of the belt cover into the slot on the deck belt shield and the other end over the end of the outer pulley cover.
- 5. Secure with washer and bolt.




5 TRIMMING MIDDLE CHUTE

- 1. Using the hacksaw, trim along the dashed line.
- Locate the middle chute, flat washer, hood latch, weld nut, lock washer and machine screw from kit.
- 3. Install in the appropriate hole at the upper end of the middle chute, according to deck size.




6 INSTALLING MIDDLE CHUTE

- 1. Place middle chute over the top end of the blower assembly.
- 2. Latch middle chute to blower assembly.



7INSTALLING BAGGER MOUNT


- Install the bagger mount tube to the rear guard with ⁵/₁₆-18 x 3½ bolts and flange nuts from kit.
 NOTE: Depending on model, rear guard hole may need to be drilled out to ⁵/₁₆" if kit hardware is too large.
- 2. Install kit support straps on the outside of the mount tube as shown in the illustration. Using a ⁵/₁₆-18 x 1½ bolt, attach the front side of the strap to the fender support. Do not add flange nut at this time. Place the reinforcement plate to the outside of the fender support. Secure with additional 1½ bolt and fasten both bolts with flange nuts. Repeat steps on opposite side. NOTE: The front side of the kit support straps should be on the inside of the mower frame.
- 3. Tighten all hardware.




8 INSTALLING CHUTE SUPPORT

- 1. Position upper chute support against bagger inlet, flush at outer edges. See Illustration.
- 2. Using support as a template, drill two ³/₈ holes into bagger hood.

Upper Chute Support




3. Secure upper chute support to hood with hex bolts, washers and nyloc nuts.



9 INSTALLING WEIGHT KITS

- Bolt cast weight to weight brackets using ³/₈-16 x
 bolts and four nuts.
- 2. Slide both weight brackets over the front tube on the frame. Be sure to position the weight assembly in the center of the frame.
- 3. Secure with 3/8-16 x 3½ bolts and four nuts.






CAUTION

DO NOT operate mower with grass catcher without front weights installed.

10 MOUNTING COVER ASSEMBLY


NOTE: Assistance from another person may ease mounting the cover assembly to mower.

- 1. Lift and rotate cover to align the cover brackets with support assembly tubes.
- 2. Slide the cover down over the support tubes until secure.



1 1 INSTALLING SPACER PLUGS

Remove plastic end caps from the center two bag support arms. Fully insert spacer plugs into the ends of the support tubes. It may be necessary to tap the spacers into place with a hammer or mallet. Replace the plastic end cap back over the spacer. The additional extension will hold the hood more securely when latched.



OPERATION

TIPS FOR IMPROVED BAGGING

Follow the mower operation instructions in you mower operator's manual.

When using the grass catcher on a lawn where grass and leaf bagging equipment has not been used, thatch and debris that has accumulated for long periods of time is picked up. The amount collected and the total time of operation may be greater than experienced with regular use of the grass catcher.

- Always run throttle at full speed when bagging.
- Select a speed low enough to give good mower cutting performance, good quality cut and good bagging performance.

NOTE: It may be necessary to overlap width of cut to suit your conditions.

- If grass is extremely tall, it should be mowed twice. The first time relatively high, the second time to desired height.
- Use left hand side of mower for trimming.
- Plastic trash bags (3.0 mil, 30 gallon) can be inserted inside grass catcher containers for ease of debris disposal. To remove the plastic trash bags when full:
 - a. Disengage blades, shift into neutral, engage the parking brake and stop the engine.
 - b. Unlatch and raise cover.
 - c. Remove one container at a time by grasping container handles and pulling toward the rear, off of the tube rails.
 - d. With the container resting on the ground, close and secure the top of the plastic lawn bag.
 - e. Tip the container on its side and slide the filled bag from the container.
 - f. Install a new plastic lawn bag with the edges of the bag draped over upper lip of the Container (for replacement bags refer to REPLACEMENT PARTS).
 - g. Repeat for other container.
 - h. Reinstall containers making sure right container overlaps left container at center supports.
 - Close cover and secure latches over center support tubes.
- Avoid cutting wet grass or in the morning while the dew is still heavy. Grass clippings collected under these conditions tend to be sticky and adhere to the walls of the flow path causing clogging.

- If the grass catcher fails to pick up cut grass or leaves, it is an indication that clogging has occurred in the system or that the grass catcher containers are full.
 - a. Disengage blades, place motion control levers in neutral position.
 - Unlatch and raise cover.
 - Slide out containers and dispose of clippings.
 - Replace containers, close cover, and latch.
 - b. Unlatch chutes and check for clogging.
 - Remove all debris in chute.
 - Reassemble and latch chutes.

GENERAL RECOMMENDATIONS

Always observe safety rules when performing any maintenance.

- Before each use check for loose fasteners.
- · Clean unit thoroughly after each use.

BLADE CARE

For best results mower blades must be kept sharp. Replace bent or damaged blades.

See BLADE CARE instructions in your mower operator's manual.



CAUTION

BEFORE PERFORMING MAINTENANCE, SERVICE OR ADJUSTMENTS:

- Set parking brake.
- Place motion control levers in "NEUTRAL" position.
- Place clutch control in "DISENGAGED" position.
- Turn ignition key to "OFF" position.
- Make sure blades and all moving parts have completely stopped.
- Disconnect spark plug wire(s) from spark plug(s) and place wire where it cannot come in contact with plug.

OPERATION

STORAGE

When grass catcher is to be stored for a period of time, clean it thoroughly, remove all dirt, grass, leaves, etc. Store in a clean, dry place.



CAUTION

- DO NOT operate mower with grass catcher partially installed.
- Disengage blades and stop engine before leaving mower seat to empty containers, unclogging chutes, etc.
- Close cover before starting.
- Disengage mower blades when crossing driveways or gravel surfaces and other areas where thrown objects could be a hazard.
- DO NOT attempt to vacuum cans or other potentially hazardous projectiles.




CAUTION

Do not leave grass in bagger containers. Empty containers after each use and before storing. Failure to do so may result in spontaneous combustion which could develop into a fire.




CAUTION

Grass catcher components are subject to wear, damage and deterioration, which could expose moving parts or allow objects to be thrown. Frequently check components and replace with manufacturer's recommended parts, when necessary.




ITEM	I PART NO.	QTY.	DESCRIPTION	ITEM	PART	NO.	QTY.	DESCRIPTION
1	539 101977	1TRA	CTION SPRING	32	539	130335.	1	MOUNT, IDLER, UPPER
2	539 976952	1 SCR	EW 10-24 x ⁵ / ₈ RD HD	33	539	130336.	1	MOUNT, IDLER, LOWER
3	539 976934	1HCS	⁵ / ₁₆ -18 x ³ / ₄	34	539	130337.	1	ARM, IDLER
4	539 104763	1 RET	AINER U TYPE	35	539	130338.	1	ARM, TENSION
5	539 105785	1 DEC	AL, WARNING	36	539	130339.	1	BRACKET, MOUNT, FRONT
6	539 106741	1 DEC	AL, SEVERING	37	539	130340.	1	BRACKET, MOUNT, REAR
7	539 108084	1 WAS	SHER 3/16 x 3/4 x 16 GA	38	539	130341.	1	PLATE, OUTER
8	539 108088	1 LATO	CH, HOOD	39	539	130346.	1	KEEPER
9	539 108089	1 WEL	D NUT, PLATED	40	539	200282.	3	NUT ³ / ₈ -16 HEX JAM NYLOC
10	539 108120	2 NUT	1/4-20 HEX NYLOC	41	539	919078.	1	PULLEY, IDLER
11	539 990717	7 NUT	⁵ / ₁₆ -18 HEX NYLOC	42	539	976949.	1	HCS ³ /8-16 x 1 ³ / ₄
12	539 108735	2 NUT	1/4-20 HEX FLANGE	43	539	990188.	3	WASHER 5/16 SAE FLAT
13	539 109552	2 WAS	SHER 3/16 LOCK	44	539	990055.	. 13	WASHER 1/4 FLAT SAE
14	539 110321	2 BOL	T, HEX ³ / ₈ -24 x 1 ¹ / ₄ GR 8	45	539	990302.	8	SCREW 1/4 x 3/8 THRD FRM
15	539 110323	2 WAS	HER, HARDENED	46	539	108461.	3	HCS 1/4-20 x 1/2
	539 113683							WASHER 3/8 SPLT LOCK
	539 115667							WASHER 3/8 SAE FLT
	539 125229							HCS ⁵ / ₁₆ -18 x 1
	539 130292							RHSNB ⁵ / ₁₆ -18 x ³ / ₄
	539 130309							HCS 1/4-20 x 7/8
	539 130295							HCS ³ / ₈ -16 x 1½
	539 130296							WASHER 5/16 STD FLT
	539 130301							DECAL, BELT ROUTING
			ER, OUTER PULLEY					KEEPER, BELT, OUTER
	539 130313							KEEPER, BELT, REAR
	539 130314							PLATE, BACKING
	539 130315							PLATE, BACKING
			FT, IMPELLER					RHSNB ⁵ / ₁₆ -18 x 1
	539 105826							RHSNB ³ / ₈ -16 x 1
30	539 130323	1 SPA	CER	61	539	130344.	1	HOUSING w/DECALS

31.. 539 130324.... 1.... PULLEY



ITEN	I PART NO.	QTY.	DESCRIPTION	ITEM	PART NO.	QTY.	DESCRIPTION
1	539 111587	1 WEI	GHT PLATE	11	539 100472	2 RHSI	NB ⁵ / ₁₆ -18 x 1 ¹ / ₄
2	522 923202	2 WEI	GHT BRACKET	12	539 990209	2 HCS	⁵ / ₁₆ -18 x 1
3	521 996501	8 NUT	³/8-16 HEX FLANGE	13	539 131091	1 TUBE	E, MOUNT
4	539 108271	4 HCS	3 ³ /8-16 x 3 ¹ / ₂	14	539 976937	2 HCS	⁵ / ₁₆ -18 x 2
5	539 101341	4 HCS	3 ³ / ₈ -16 x 3	15	539 990692	4 WAS	HER 5/16 STD FLT
6	539 130306	1 SHIE	ELD, BELT	16	523 112802	2 PLAT	E, REINFORCEMENT
7	539 130319	1PUL	LEY	17	539 112899	8 NUT	5/16-18 HEX FLG NYLOC
8	539 105743	1 DEC	AL, NO STEP	18	523 084702	1 STRA	AP, SUPPORT, LT
9	539 101520	2 HCS	5 ⁵ / ₁₆ -18 x 3 ¹ / ₄	19	523 084902	1 STRA	AP, SUPPORT, RT
10	539 130347	1 BEL	Γ				



ITEM PART NO. QTY. DESCRIPTION	ITEM PART NO. QTY. DESCRIPTION
1 532 195373 1 COVER	16 539 108096 2 HAIR PIN
2 532 192709 1 SCREEN, COVER	17 539 976977 14 NUT #10-24 CROWNLOCK
3 532 176990 1 FRAME, BAGGER	18 539 990717 2 NUT ⁵ / ₁₆ -18 HEX NYLOC
4 532 192550 1 SEAL, COVER	19 539 108081 1 SCREW, SPEC 10-14 x ½
5 532 192603 1 GASKET, COVER	20 539 108082 1 INDICATOR, BAG DUMP
6 532 400226 3 CONTAINER, SOFT BAG	21 539 108083 2 SCREW 10-24 x 1 ¹ / ₈
7 532 192786 2 PIN, HINGE	22 539 108084 3 WASHER ³ / ₁₆ x ³ / ₄
8 532 130895 2 HANDLE, BAGGER COVER	23 539 108085 2 SPACER, SPLIT
9 539 110234 1 SUPPORT, HOSE	24 539 108086 2 NUT, ACORN 10-24
10 539 112294 1 FLEX TRIM, BLACK	25 539 108088 1 LATCH, HOOD
11 539 108097 4 PLUG, TUBING END	26 539 108089 1 WELD NUT, PLATED
12 522 801301 2 PLUG SPACER	27 522 739201 1 CHUTE, UPPER
13 539 990188 4 WASHER ⁵ / ₁₆ SAE FLAT	28 539 109552 2 WASHER ³ / ₁₆ LOCK
14 539 990627 2 HCS ⁵ / ₁₆ -18 x 1 ¹ / ₄	29 539 130294 1 CHUTE, MIDDLE
15 539 976952 8 SCREW #10-24 x ⁵ / ₈	

P/N 115 151727R1 02/25/10