

# INSTALLATION INSTRUCTIONS

## Light Kit - 576 809001

1. Slide the mounting bracket front to back over the top loop of the Roll Over Protection System (ROPS).
2. Remove the small set screws at the sides of the light assemblies and separate the brackets. Loosely fasten both the light brackets and mounting brackets to the top loop, using the  $\frac{5}{16}$  bolts and nuts.
3. Reinstall the lights into the light brackets using the side set screws.
4. Position the lights as desired and tighten the mounting hardware.

*When connecting the main harness to the lights, the harness should be oriented so that it can be routed down the back of the left side of the ROPS.*

5. Connect the BLUE harness wires to the BLUE ground wire on the lights.
6. Connect the YELLOW wire with RED stripe to the BLACK power wire on the lights.
7. Secure and insulate the connections with electrical tape.
8. Use the extra loom on the harness to cover the connections and wires to the lights. Tape the ends of the loom to secure it.
9. Locate the frame harness below the left side of the seat. It may be tucked under the frame.

### **Models without tank-mounted lights:**

10. Connect the new accessory light harness directly to the frame harness and proceed to step 12. The extra connector on the light assembly harness will not be used.

### **Models with tank-mounted lights:**

11. Units having tank-mounted lights will have a connector plugged into the frame harness. Unplug the tank light wire from the accessory connector and plug both the frame harness and the tank light wire into the new accessory light harness.

12. Turn the ignition switch to the ACC position to make sure the lights work.
13. Select locations on the back of the ROPS to secure the harness. Peel and stick the wire tie mounting blocks in the desired locations. Secure the harness to the blocks with wire ties, leaving harness slightly loose to allow for the ROPS to be folded down.
14. Use additional wire ties to secure the harness to the frame.

