



SERVICE 		13
		SX 86.107


Clearing Saw Accessories

Freischneider **Zubehöre**

Débroussailleuse **Accessoires**


Desbrozadora Accessories

- **Röjsågstillbehör**




Saw blades 200 mm–8"


Maxi 200 saw blade
no 502 04 13-02



Scarlet 200 saw blade
no 501 91 34-01




Guard
no 502 03 93-01




Saw blades 225 mm–9"


Maxi 225 saw blade
no 502 01 95-02



Scarlet 225 saw blade
no 501 91 35-01





Guard
no 502 03 94-01



Saw blades 225 mm–9"


Spets 225 pointed-tooth blade
no 502 14 25-01






Brush blades 255 mm-10"


Multi 255-4 brush blade
no 501 91 05-02




Multi 255-3 brush blade
no 501 31 64-01



Plant protector (complete)
no 502 12 26-01




Guard
no 502 03 95-01




Brush blades 300 mm-12"


Multi 300 brush blade
no 502 04 68-01



Guard
no 502 03 96-01




Support cup no 502 13 93-01




Nylon cordheads


Trimmy Fix
no 502 13 87-01




Trimmy H
no 501 91 28-03




Trimmy Hit
no 501 95 40-01



Trimmy S
no 508 01 01-02




Guard
no 502 10 47-01




Spare cord \varnothing 2,4 mm

15 m, 45 feet
no 508 01 51-49



98 m, 297 feet
no 502 04 77-01



 **Husqvarna**
SWEDEN
The Clearing Saw Professionals