


Spreader



1.1990

Spare parts




Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar

A**B****C**

D



PARTNUMBER SQUARE NOTE

531 00 27-50	A
531 00 27-51	D
531 00 27-52	D
531 00 27-53	D
531 00 27-54	A
531 00 27-55	A
531 00 27-56	C
531 00 27-57	A
531 00 27-58	A
531 00 27-59	D
531 00 27-60	B
531 00 27-61	A
531 00 27-62	B
531 00 27-63	A
531 00 27-65	A
531 00 27-66	A
531 00 27-67	D
531 00 27-68	D
531 00 27-69	A
531 00 27-70	D
531 00 27-71	C
531 00 27-72	C
531 00 27-73	D
531 00 27-74	D
531 00 27-75	D
531 00 27-76	D
531 00 27-77	A
531 00 27-78	D
531 00 27-79	B
531 00 27-80	B
531 00 27-81	B
531 00 27-82	D
531 00 27-83	A,B
531 00 27-84	B
531 00 27-85	B
531 00 27-86	B
531 00 27-87	B
531 00 27-88	D
531 00 27-89	C
531 00 27-90	A
531 00 27-91	D
531 00 27-92	D
531 00 27-93	D
721 61 67-01	A,B
721 61 85-01	D
725 23 70-71	A,B
725 23 76-51	A,C,D
725 23 79-51	A,B,D
725 24 60-51	D
725 24 95-71	C
725 25 00-51	C
725 25 01-51	C
731 23 16-01	A,B,D
731 23 18-01	D
731 23 20-01	A,C,D
734 11 52-01	A,C
734 11 63-01	D
734 11 72-01	C,D