



Jet 51



1.1992

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

REPAIR PARTS

20" ROTARY LAWN MOWER - - MODEL NO. JET 51, PRODUCT NO. 954 05 98-01

KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
2	874 76 06-24 Hex Washer Head Screw 1/4-20 x 1-1/2	37	532 06 23-35 Belleville Washer
3	532 80 05-47 Trim Plate	38	532 08 49-21 Shoulder Bolt 3/8-16
4	532 85 07-58 Control Bar	39	532 80 03-33 Wheel Assembly
5	532 06 36-01 Locknut 1/4-20	40	532 75 16-58 Washer
6	532 03 69-53 Self-tapping Screw #10-24 x 5/8	41	532 08 39-23 Locknut
7	532 13 19-59 Handle Bolt 5/16-18 x 1 -3/4	42	532 80 06-27 Hubcap
8	874 76 04-44 Machine Screw 1/4-20 x 2-1/8	43	532 12 50-44 Front Baffle
9	532 85 14-61 Throttle Control	44	532 75 15-92 Locknut 3/8-16
10	819 09 10-16 Washer	46	532 85 10-84 Hex Head Screw 3/8-24 x 1 -3/8 Gr. 8
11	532 85 16-69 Engine Zone Control Cable	47	532 85 02-63 Helical Lockwasher 3/8
12	532 75 00-97 Hex Washer Head Screw # 10-24 x 12	48	532 85 10-74 Hardened Washer
13	532 12 51-62 Up-Stop Bracket	49	532 85 09-72 20" Blade
14	532 80 03-58 Upper Handle With Grip	50	532 85 09-77 Blade Adapter
15	532 85 07-24 Handle Grip	51	873 68 04-00 Locknut 1/4-20
16	532 06 64-26 Wire	52	532 10 73-39 Danger Decal
17	532 13 20-01 Rope Guide	53	532 08 75-89 Torsion Spring
18	532 05 17-93 Hairpin Cotter	54	812 00 00-14 E-Ring Axel 1/4 spar 5,7
19	532 06 36-88 Handle Knob	55	532 08 75-90 Hinge Rod
21	532 75 12-28 Rear Skirt	56	532 08 75-93 Housing Bracket Assembly
22	532 08 12-76 Hex Washer Head Screw # 10-24 x 1/2	57	532 85 07-78 Discharge Guard
23	532 12 52-07 Rear Skirt Bracket	58	532 12 52-14 Lower Handle
24	532 12 50-47 Handle Bracket Assembly (Right)	61	874 64 10-08 Thread Rolling Screw #10-32 x 5/8
25	532 12 50-49 Handle Bracket Assembly (Left)	62	532 85 12-19 * Cable Clamp
26	532 85 09-98 Thread Rolling Screw 3/8-16 x 1	63	-- -- -- -- * Engine - Briggs & Stratton Model No. 96502, 3137-01
27	532 12 52-05 Support Handle Bracket (Right)	64	819 09 10-16 Washer
28	532 12 52-06 Support Handle Bracket (Left)	—	532 12 50-46 Rear Baffle (Not Shown)
29	874 78 05-16 Screw 5/16-18	# —	532 13 21-02 Operator's Manual (Scand)
30	532 13 08-77 Lawn Mower Housing (Includes Key # 52)	# —	532 13 21-03 Operator's Manual (Euro)
31	532 10 30-96 Wheel Adjusting Bracket (L.R., R.F.)	# —	532 80 05-70 Decal (Engine)
32	532 08 49-20 Spacer	# —	532 80 06-28 Decal (Housing)
33	532 10 30-95 Wheel Adjusting Bracket (R.R., L.F.)	# —	532 85 07-88 Decal (Trim Plate)
34	532 12 51-68 Selector Spring	# —	532 80 06-39 Decal, Warning
35	532 07 78-65 Selector Knob	# —	532 80 11-13 Decal, Warning
36	532 75 06-10 Axle Arm Assembly		

* These Parts must be purchased through an authorised Briggs & Stratton Dealer.

