


 **Husqvarna**

1993 -05- 2 4



# HuskyJet



**1.1993**

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**

# REPAIR PARTS

## 20" ROTARY LAWN MOWER- MODEL NO. HUSKY JET, PRODUCT NO. 954 06 301

KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION		
1	532 08 69-02	Control Bar	26	819 21 16-16	Washer
2	532 13 20-01	Rope Guide	27	532 13 20-10	Flange Locknut 3/8-16
3	817 02 10-08	Hex Washer Head Self-tapping Screw # 10-24 x 1/2	28	874 76 04-12	Hex Head Bolt 1/420 x 3/4
4	532 12 51-89	Lower Hands	30	532 85 09-98	Hex Head Thread Rolling Screw 3/8-16 x 1
5		* Cabs Clamp (Engine)	33	532 70 07-05	Housing
6	873 68 04-00	Locknut 1/4-20	34	532 85 09-77	Blade Adapter
7	532 12 53-71	Upper Handle	35	532 85 09-72	Blade 20"
8	532 85 18-09	Engine Zone Control Cable	36	532 85 10-74	Washer (Hardened)
9	874 78 04-24	Hex Head Bolt 1/4-20 x 1-1/2	37	532 85 02-63	Helical Lock Washer
10	532 12 51-62	Up-Stop Bracket	38	532 85 10-84	Hex Head Machine Screw 3/8-24 x 1-3/8 Gr. 8
11	532 06 64-26	Wire Tie	39	-----	Engine, Briggs & Stratton Model No. 95902, Type No.3117-02
12	874 76 06-16	Hex Head Bolt 3/8-16 x 1	40	873 22 04-00	Hex Nut 1/4-20
13	532 12 53-70	Front Baffle	41	532 13 19-22	Throttle Cable STD
14	532 75 12-28	Rear Skirt	42	874 76 04-44	Machine Screw 1/4-20 x 2.12
17	532 12 50-78	Engine Washer	43	819 09 10-16	Flat Washer
18	819 13 13-11	Flat Washer	44	532 12 52-07	Skirt Bracket
19	532 75 20-52	Discharge Guard	45	873 68 06-00	Locknut 5/8-16
20	532 06 76-09	Shoulder Bolt	46	532 08 38-16	Screw, #10 x 5/8
21	532 13 04-91	Wheel Assembly 7.00 x 1.50	47	532 85 04-72	Cable Clip, Throttle
22	532 13 66-24	Spacer Washer			
23	532 10 73-39	Danger Decal			
24	819 13 13-11	Washer			

\* These parts must be purchased through an authorised Briggs & Stratton dealer.

