

Spreader



1.1994

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

Replaces

Ersetzt

Remplace


Vervangt



Reemplaza

Ersätter


106 23 23-62

A



B**C**

D



PART NUMBER	SQUARE	NOTE
506 67 52-01	D	
531 00 27-50	A	
531 00 27-53	D	
531 00 27-55	A	
531 00 27-58	A	
531 00 27-59	D	
531 00 27-60	B	
531 00 27-62	B	
531 00 27-63	A	
531 00 27-66	A	
531 00 27-69	A	
531 00 27-70	D	
531 00 27-72	C	
531 00 27-73	D	
531 00 27-74	D	
531 00 27-77	A	
531 00 27-81	D	
531 00 27-83	AB	
531 00 27-87	B	
531 00 27-88	D	
531 00 27-90	A	
531 00 27-92	D	
531 00 46-01	A	
531 00 46-02	D	
531 00 46-03	H	
531 00 46-04	B	
531 00 46-05	B	
531 00 46-06	C	
531 00 46-07	D	
531 00 46-08	D	
531 00 46-09	D	
531 00 46-10	D	
531 00 46-11	A	
531 00 46-12	A	
531 00 46-13	A	
531 00 46-14	B	
531 00 46-15	C	
531 00 46-16	B	
531 00 46-17	B	
531 00 46-18	B	
531 00 46-19	AC	
531 00 46-20	B	
721 61 67-01	B	
721 61 68-01	D	
725 23 70-71	AB	
725 23 79-51	ACD	
725 24 60-51	D	
725 24 95-71	C	
725 25 01-51	C	
731 23 16-01	ABD	
731 23 18-01	D	
731 23 26-01	AC	
734 11 52-01	AB	
734 11 63-01	D	
734 11 72-01	C	