

Accessory Guide for Trimmers and Brushcutters 1998



Accessory Guide for Trimmers and Brushcutters 1998



	Trimmy Fix M10. Fixed cord. Cord: 2,4-3,4 mm	Trimmy H II M10. Manual feed. Cord: 2,0-2,4 mm	Trimmy S M12. Manual feed. Cord: 2,4 mm	Trimmy S II M12. Manual feed. Cord: 2,4-3,3 mm	Trimmy Hit VI R 3/8" Right hand thread. Semi-Automatic feed. Cord: 2,0 mm	Trimmy Hit VI L 3/8" Left hand thread. Semi-Automatic feed. Cord: 2,0 mm	Trimmy Hit Pro M10. Semi-Automatic feed. Cord: 2,0-2,4 mm	Trimmy Superauto II Automatic feed. Cord: 2,0-2,4 mm	Tricut M10. Jointed plastic grass blades Diameter 300 mm	Tricut M12. Jointed plastic grass blades Diameter 300 mm	Grass 200-4 Grass blade, 4 teeth. Diameter: 200 mm	Grass 255-8 Grass blade, 8 teeth. Diameter: 250 mm	Grass 255-4 Grass blade, 4 teeth. Diameter: 255 mm	Multi 255-3 Grass knife, 3 teeth. Diameter: 255 mm	Multi 275-4 Grass knife, 4 teeth. Diameter: 275 mm	Multi 300-3 Grass knife, 3 teeth. Diameter: 300 mm	Maxi X 200-26 Saw blade, 26 teeth. Diameter: 200 mm	Maxi XS 200-22 Saw blade, 22 teeth. Diameter: 200 mm	Maxi XS 225-22 Saw blade, 22 teeth. Diameter: 225 mm	Opti 255-22 Saw blade, 22 teeth. Diameter: 255 mm	
	531 00 38-69	531 00 38-81	508 01 01-02	502 26 08-01	952 70 85-62	952 71 55-81	503 78 78-01	531 00 38-09	531 00 38-11	531 00 38-24	952 71 55-80	503 81 44-01	503 74 88-01	502 17 58-01	503 74 66-01	502 17 56-01	508 90 15-01	508 90 14-01	508 90 24-01	502 26 84-01	
Mondo					A																
122L	B	B					B		B												
Mondo Max						C															
225L/LD 232L	D	D					D	D	D			S	S	S							
Mondo Mega						C					L						L				
225R/RD	D	D					D	D	D			M,Q	M,Q	M,Q			G				
232R/RD	D	D					D	D	D			M,Q	M,Q		M,Q		G				
235R *New gear 1998					D*					D,N*						N,P* R	N,P* R	G*			
240R 245R/RX			E	E						E,O				K,P, R	O,P R	O,P R		F,H			
250R			E	E						E,O				K,R	O,R	O,R		F,H	I		
252RX			E	E										K,R	O,R	O,R		F,H	I		
265RX			E	E												O,R		F,H	I	J	
240RBD	D	D					D	D	D			M,Q	M,Q	M,Q	M,Q						

Splash Guard Plastic 35°. Knife for adjusting cord length. Ø450 mm.	Splash Guard Plastic 90°. Knife for adjusting cord length. Ø420 mm.	Splash Guard Plastic 45°. Knife for adjusting cord length. Ø450 mm.	Splash Guard Plastic 90°. Knife for adjusting cord length. Ø450 mm.	Splash Guard Plastic 90°. Knife for adjusting cord length. Ø500 mm.	Blade Guard Steel. For 200 mm blades.	Blade Guard Steel. For 200 mm blades.	Blade Guard with plant protector Steel. For 200 mm blades.	Blade Guard Die-cut aluminium. For 225 mm blades.	Blade Guard Die-cut aluminium. For 255 mm blades.	Blade Guard with plant protector Steel. For 255 mm blades.	Blade Guard Steel. For up to 200 mm blades.	Blade Guard Plastic. For up to 275 mm grass blades.	Blade Guard Plastic. For up to 300 mm grass blades.	Blade Guard Plastic. For up to 300 mm grass blades.	Support Cup M10. Plastic. Fixed.	Support Cup M10. Plastic. Fixed.	Support Cup Plastic. With ballbearing.	J-handle Kit J-handle for using grass blades with a trimmer.
530 04 72-71	502 10 47-01	530 04 98-95	503 74 50-04	503 91 60-01	502 27 22-01	503 77 39-01	502 14 55-01	502 03 94-03	502 03 95-03	502 12 26-01	530 01 42-10	503 74 40-01	503 89 52-01	502 26 34-01	503 90 18-01	503 89 01-01	502 15 70-01	503 78 17-01
A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S