


Accessories






IPL, Brush T-20406, 953 51 61-01, 1998-09, Art.nr 106 24 62-61

Brush

Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar


953 51 61-01 Street Brush for tractors

Pos	Part number	Part name	Qty	Pos	Part number	Part name	Qty
1	531 02 11-16	Frame	1	53	531 02 11-35	Collar	1
2	531 02 11-17	Weldment	1	54	531 02 11-36	Collar	1
3	531 00 51-52	Roller Shaft	1	55	531 02 11-37	Washer	4
4	531 00 51-53	Brush Ring	26	56	531 00 52-61	Pulley	2
5	531 00 51-54	Collar, Plastic	25	57	531 00 51-97	Collar	5
6	531 00 51-55	Flange	1	58	531 02 11-38	Bearing	8
7	531 00 51-08	Bearing, Flange	2	59	531 00 51-98	Circlip	3
8	531 00 51-57	Chain Tightener	1	60	531 00 52-89	Collar	1
9	531 00 51-58	Chain Wheel	1	61	531 00 52-90	Collar	1
10	531 02 11-18	Collar	1	62	531 00 52-83	Support	1
11	531 02 11-51	Circlip	1	63	531 00 52-85	Guide, Belt	2
12	531 00 51-60	Chain Wheel	1	64	531 00 52-86	Collar	2
13	531 00 51-61	Drive Shaft	1	65	531 02 11-39	Pulley	1
14	531 00 52-20	Key	1	66	531 02 11-40	Screw	1
15	531 02 11-19	Frame	1	67	531 00 52-65	Collar	1
16	531 02 11-20	Belt Guard	1	68	531 02 11-41	Weldment, Lift	1
17	531 02 11-21	Chain Guard	1	69	531 02 11-42	Nut	1
18	531 02 11-22	Chain Wheel	1	70	531 02 11-43	V-Belt	1
19	531 00 51-67	Support Shaft, Wheel	2	71	531 00 51-41	Grip	1
20	531 02 11-23	Screw, Special	1	72	531 00 52-12	Screw	2
21	531 00 51-69	Bushing, Plastic	2	73	531 02 11-44	Screw	3
22	531 00 51-70	Support, Wheel	2	74	531 02 11-45	Washer	2
23	531 00 51-71	Pin, Split	2	75	531 02 11-46	Screw	4
24	531 00 51-72	Support Wheel	2	76	531 00 52-91	Screw, Lock	1
25	531 00 51-73	Guard, Support Wheel	4	77	531 02 11-47	Washer	2
26	531 02 11-24	Drive Chain	1	78	531 02 11-48	Nut, Lock	2
27	531 00 51-75	Pulley	1	79	531 02 11-49	Screw	1
28	531 00 51-76	Circlip	1	80	531 02 11-82	Side Plate, Left	1
29	531 00 51-12	Bearing	1	81	531 02 11-83	Side Plate, Right	1
30	531 00 51-77	Screw	2	82	531 02 11-84	Washer	11
31	531 00 51-78	Pin	1	83	531 00 52-15	Collar	2
32	531 00 51-79	Universal Joint	1	84	531 02 11-85	Washer	1
33	531 00 51-80	Guard, Drive Shaft	1	87	531 00 52-16	Pin, Spring	4
34	531 00 51-81	Bearing	1	88	531 00 52-17	Pin Set	2
35	531 00 51-82	Clamp	1	89	531 02 11-74	Screw	1
36	531 00 51-83	Support	1	91	531 02 11-86	Washer	1
37	531 02 11-10	Support, Lift	1	92	531 02 11-87	Circlip	1
38	531 02 11-25	Weldment, Lift	1	93	531 02 11-88	Bearing	2
39	531 02 11-26	Lever	1	94	531 02 11-89	Pin	1
40	531 02 11-27	Screw	3	95	531 00 52-27	Rubber	1
41	531 02 11-28	Screw	5	96	531 00 52-29	Plate	1
42	531 02 11-29	Nut	6	97	531 00 52-26	Frame	1
43	531 02 11-30	Nut, Lock	8	98	531 00 52-28	Screw	6
44	531 02 11-31	Screw	2	99	531 00 51-66	Pulley	1
45	531 00 51-87	Screw, Special	1	100	531 02 11-90	Drive Chain	1
46	531 02 11-32	Nut	4	101	531 02 12-33	Decal	1
47	531 00 51-92	Shaft	2	102	531 02 12-34	Decal, Street Brush	1
48	531 00 52-80	Belt Tightener	1				
49	531 00 52-03	Spring	1				
50	531 02 11-33	Screw	1				
51	531 02 11-34	Shaft	2				
52	531 00 51-43	Pin, Spring	3				



953 51 61-01

T-20406



953 51 61-01

T-20406

