

Jet 50

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar

REPAIR PARTS

ROTARY LAWN MOWER MODEL NO. JET50N PRODUCT NO. 954 17 00-32



REPAIR PARTS

ROTARY LAWN MOWER MODEL NO. JET50N PRODUCT NO. 954 17 00-32

| KEY NO. | PART NO. | DESCRIPTION | KEY NO. | PART NO. | DESCRIPTION |
|---------|------------------|--|---------|------------------|---|
| 1 | 532086902 | Control Bar | 36 | ----- | *Engine - Briggs & Stratton Model No. 9D902 |
| 2 | 532165694 | Upper Handle | | | Order parts from engine manufacturer |
| 3 | 532157082 | Lower Handle | 38 | 532140543 | Rear Skirt |
| 4 | 532153638 | Rope Guide | 39 | 532750097 | Hex Washer Head Screw #10-24 x .50 |
| 5 | 532063601 | Locknut 1/4-20 | 41 | 532145494 | Decal, Danger |
| 6 | 532131959 | Handle Bolt 5/16-18 x 1-3/4 | 42 | 532146026 | Front Baffle |
| 7 | 532158755 | Hex Washer Head Screw 1/4-20 x 2.12 | 43 | 532851462 | Throttle Control |
| 10 | 532130861 | Engine Zone Control Cable | 45 | 532125207 | Skirt Brackets |
| 11 | 532750097 | Hex Washer Head Screw #10-24 x 1/2 | 46 | 532083816 | Screw #10 |
| 12 | 532125162 | Up-Stop Bracket | 47 | 532111190 | * Clamp |
| 13 | 532085825 | Screw | 48 | 532087930 | Throttle Clip |
| 14 | 532069180 | Nut | 50 | 532139901 | Wheel Adjusting Bracket |
| 15 | 532128638 | Steel Wingnut 5/16-18 | 51 | 532146630 | Spacer |
| 16 | 532066426 | Wire Tie | 52 | 532087877 | Selector Knob |
| 17 | 532051793 | Hairpin Cotter | 53 | 532141730 | Selector Spring |
| 18 | 532750149 | Discharge Guard | 54 | 532149857 | Axle Arm Assembly |
| 19 | 532173862 | Housing Assembly Kit (Includes #42) | 55 | 532083923 | Locknut |
| 20 | 532170977 | Handle Bracket Assembly (Left) | 57 | 532800090 | Hubcap |
| 21 | 532170975 | Handle Bracket Assembly (Right) | 59 | 532128415 | Pop Rivet |
| 22 | 532062335 | Belleville Washer | 60 | 532125424 | Handle Support Bracket (Right) |
| 23 | 532800060 | Wheel & Tire Assembly | 61 | 532125423 | Handle Support Bracket (Left) |
| 24 | 532142748 | Shoulder Bolt | 62 | 532087593 | Housing Bracket |
| 25 | 532850999 | Hex Head Thread Rolling Screw 3/8-16 x 2 | 63 | 532147286 | Hinge Rod |
| 27 | 532149741 | Thread Cutting Screw 5/16-18 x 3/4 | 64 | 532087589 | Torsion Spring |
| 28 | 532154147 | Foot Guard | 65 | 532053998 | Washer |
| 29 | 532751592 | Locknut 3/8-16 | 66 | 532701313 | Engine Spacer Ring |
| 30 | 532063601 | Nut 1/4-20 | -- | 532125046 | Rear Baffle (Not Shown) |
| 31 | 532851084 | Hex Head Screw 3/8-24 x 1-3/8 Gr. 8 | — | 532163073 | Operator's Manual (Sandinavian) |
| 32 | 532850263 | Helical Lockwasher 3/8 | — | 532163074 | Operator's Manual (European) |
| 33 | 532851074 | Hardened Washer | | | |
| 34 | 532850972 | 20" Blade | | | |
| 35 | 532850977 | Blade Adapter | | | |