



165 BT




Repair Parts Manual

Backpack Blower


A**165BT**

Ref. #	Part #	Description	Ref. #	Part #	Description
1	695 00 07-99	Elbow Pipe Compl.	12	695 00 06-33	Tapping Screw (M5x20)
2	695 00 00-05	O-Ring	13	695 00 06-34	Rubber AV Mount
3	695 00 08-00	Elbow Pipe	14	695 00 06-35	Rubber AV Mount
4	695 00 08-01	Hose Band	15	695 00 08-09	Fan Case
5	695 00 08-02	Wire Clamp	16	695 00 06-37	Pre-Coat Lock Bolt
6	695 00 08-03	Flexible Pipe	17	695 00 08-10	Fan
7	695 00 08-04	Base Pipe	18	695 00 08-11	Fan Case
8	695 00 08-05	Throttle Lever Assy.	19	695 00 06-40	Pre-Coat Lock Bolt
9	695 00 08-06	Middle Pipe	20	695 00 08-12	Fan Cover
10	695 00 08-07	Bend Pipe	21	695 00 08-13	Socket Screw
11	695 00 01-10	Wire Band	22	695 00 00-40	Nylon Nut
			23	695 00 11-01	Concentrator Nozzle

B**165BT**


Ref. #	Part #	Description
1	695 00 00-38	Flange Nylon Nut (M6)
2	695 00 00-45	Washer
3	695 00 06-41	Shoulder Band
4	695 00 06-42	Truss Screw (M6x16)
5	501 94 19-01	U-Nut (M6)
6	695 00 06-43	Clip
7	695 00 06-44	Backpack Pad
8	695 00 08-16	Screw (M6x16)
9	695 00 08-17	Backpack Frame
10	695 00 08-18	Fuel Tank

C




T



compl. 695 00 08-20




D




E




F





G




H






J



K



L



M

