


## YTH 1842 A


954569790



Repair Parts Manual


Ride Mower

TRACTOR - - MODEL NO.YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
SCHEMATIC



# REPAIR PARTS

TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
ELECTRICAL



# REPAIR PARTS


TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
ELECTRICAL

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                          |
|------------|--------------|--------------------------------------|
| 1          | 532 16 34-65 | Battery                              |
| 2          | 874 76 04-12 | Bolt Hex Hd 1/4-20unc X 3/4          |
| 8          | 532 17 66-89 | Box Battery                          |
| 16         | 532 17 61-37 | Switch Interlock                     |
| 21         | 532 17 56-88 | Harness Asm Light W/4152j            |
| 22         | 532 00 41-52 | Bulb Light #1156                     |
| 24         | 532 12 47-80 | Cable Battery 6 Ga 11" red           |
| 25         | 532 14 61-47 | Cable Battery 6 Ga 44" red w/16 wire |
| 26         | 532 17 51-58 | Fuse                                 |
| 27         | 873 51 04-00 | Nut Keps Hex 1/4-20 Unc              |
| 28         | 532 12 47-73 | Cable Ground 6 Ga 12" black          |
| 29         | 532 16 07-84 | Switch Plunger Olive                 |
| 30         | 532 17 55-66 | Switch Ign Delta                     |
| 33         | 532 14 04-01 | Key Ign Molded Generic               |
| 40         | 532 17 97-22 | Harness Ign.                         |
| 41         | 871 11 04-08 | Bolt Blk Fin Hex 1/4 - 20 x 1/2      |
| 42         | 532 13 15-63 | Cover Terminal Red                   |
| 43         | 532 17 88-61 | Solenoid                             |
| 48         | 532 14 08-44 | Adapter Ammeter Rectangular          |
| 52         | 532 14 19-40 | Protection Wire Loop                 |
| 81         | 532 10 97-48 | Relay Asm.                           |
| 90         | 532 18 04-49 | Cover Terminal Battery               |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR - - MODEL NO.YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
CHASSIS AND ENCLOSURES



# REPAIR PARTS


## TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90 CHASSIS AND ENCLOSURES

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                      |
|------------|--------------|----------------------------------|
| 1          | 532 17 46-19 | Chassis Stamping                 |
| 2          | 532 17 65-54 | Drawbar, 12 Ga.                  |
| 3          | 817 06 06-12 | Screw 3/8-16 x 3/4               |
| 5          | 532 15 52-72 | Bumper Hood/Dash                 |
| 9          | 532 17 18-53 | Dash Slksr                       |
| 10         | 872 14 06-08 | Bolt Carriage 3/8-16 x 1         |
| 11         | 532 17 49-96 | Panel Dash Lh                    |
| 13         | 532 18 17-19 | Panel Dash Rh                    |
| 14         | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2        |
| 17         | 532 18 52-11 | Hood LT/PL                       |
| 18         | 532 18 49-21 | Bumper Hood                      |
| 26         | 873 80 06-00 | Nut Lock Hex W/Ins 3/8-16 Unc    |
| 28         | 532 18 52-92 | Grille/Lens Asm                  |
| 30         | 532 18 10-01 | Fender Footrest                  |
| 31         | 532 13 99-76 | Bracket Fender                   |
| 37         | 817 49 05-08 | Screw Thdrol 6/16-18 x 1/2 TYT   |
| 38         | 532 17 57-10 | Bracket Asm Pivot Mower Rear     |
| 39         | 532 17 47-14 | Bracket Pivot                    |
| 58         | 532 15 01-27 | Air Duct Engine P/L              |
| 60         | 872 14 06-06 | Bolt RdHd Sqnk 3/8-16 Unc x 3/4  |
| 64         | 532 15 47-98 | Dash Lower STLT                  |
| 74         | 873 68 06-00 | Nut Crownlock 3/8-16 Unc         |
| 142        | 532 17 57-02 | Plate Reinforcement STLT         |
| 143        | 532 15 49-66 | Bracket Swaybar Chassis          |
| 144        | 532 17 55-82 | Bracket Footrest                 |
| 145        | 532 15 65-24 | Rod Pivot Chassis/Hood           |
| 159        | 532 16 65-08 | Cupholder                        |
| 166        | 532 17 18-75 | Screw HwHd Hi-Lo #13-16 x 3/4    |
| 206        | 532 17 01-65 | Bolt Shoulder 5/16-18 TT         |
| 207        | 817 67 05-08 | Screw Thdrol 5/16-18 x 1/2       |
| 208        | 817 67 06-08 | Screw Thdrol 3/8-16x1/2 Ty-tt    |
| 209        | 817 00 06-12 | Screw Hex Wsh Thdr. 3/8-16 x 3/4 |
| 212        | 532 18 35-48 | Insert Lens Reflective           |
| 258        | 532 18 52-14 | Lens Husq Laser LT Clear RH      |
| 259        | 532 18 52-13 | Lens Husq Laser LT Clear LH      |
| 260        | 532 18 54-29 | Cover Lens                       |
| 261        | 532 18 54-33 | Insert Grille                    |
| - -        | 532 00 54-79 | Plug Button                      |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

## REPAIR PARTS

**TRACTOR - - MODEL NO.YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
DRIVE**



# REPAIR PARTS

**TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
DRIVE**

| KEY NO. | PART NO.     | DESCRIPTION                                                            | KEY NO. | PART NO.     | DESCRIPTION                             |
|---------|--------------|------------------------------------------------------------------------|---------|--------------|-----------------------------------------|
| 1       | -----        | Transaxle Hydro Gr Model 322-0510<br>(Order parts from transaxle mfg.) | 71      | 532 16 91-83 | Strap Torque Lh Hydro                   |
| 8       | 532 16 58-66 | Rod Shift Fender                                                       | 73      | 532 16 91-82 | Strap Torque Rh Hydro                   |
| 10      | 876 02 04-16 | Pin Cotter 1/8 x 1 CAD                                                 | 74      | 532 13 70-57 | Spacer, Axle                            |
| 14      | 810 04 04-00 | Washer Lock Hvy Helical 1/4                                            | 75      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Gauge         |
| 15      | 874 49 05-44 | Bolt Hex Flg Hd 5/16-18 X Gr.5                                         | 76      | 812 00 00-01 | E-Ring                                  |
| 16      | 873 80 05-00 | Nut Lock Hex W/Ins. 5/16-18 Unc P                                      | 77      | 532 12 35-83 | Key, Square                             |
| 19      | 873 80 06-00 | Nut Lock Hex W/Wsh 3/8-16 Unc                                          | 78      | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Gauge         |
| 21      | 532 14 08-45 | Knob, Deluxe                                                           | 81      | 532 16 55-96 | Shaft Asm. Cross Hydro                  |
| 22      | 532 16 94-98 | Rod, Brake Hydro                                                       | 82      | 532 16 57-11 | Spring Torsion T/A                      |
| 24      | 873 35 06-00 | Nut                                                                    | 83      | 819 17 12-16 | Washer 17/32 x 3/4 x 16 Ga.             |
| 25      | 532 10 68-88 | Spring, Brake Rod                                                      | 84      | 532 16 98-43 | Link Transaxle                          |
| 26      | 819 13 13-16 | Washer                                                                 | 89      | 532 16 65-10 | Console, Shift                          |
| 27      | 876 02 04-12 | Pin Cotter 1/8 x 3/4 CAD.                                              | 90      | 532 12 43-46 | Nut Self Thd Wsh Hd 1/4 Zinc            |
| 28      | 532 17 57-65 | Rod, Parking Brake                                                     | 95      | 532 17 02-01 | Control Asm Bypass Hydro                |
| 29      | 532 07 16-73 | Cap, Parking Brake                                                     | 96      | 532 12 47-88 | Retainer Spring 1" Zinc/Cad             |
| 30      | 532 17 49-73 | Bracket, Transaxle                                                     | 103     | 873 94 08-00 | Nut Hex Jam Toplock 1/2-20 Unf          |
| 32      | 874 76 05-12 | Bolt Hex Hd 5/16-18 Unc x 3/4                                          | 116     | 872 14 06-08 | Boulon 3/8-16 x 1                       |
| 34      | 532 17 55-78 | Shaft, Foot Pedal                                                      | 120     | 873 90 06-00 | Nut Lock Flg 3/8-16                     |
| 35      | 532 12 01-83 | Bearing, Nylon                                                         | 150     | 532 17 54-56 | Spacer Retainer                         |
| 36      | 819 21 16-16 | Washer                                                                 | 151     | 819 13 32-10 | Washer 13/32 x 2 x 10 Ga.               |
| 37      | 532 12 49-63 | Pin, Roll                                                              | 156     | 532 16 60-02 | Washer Srrtd 5/16 ID x 1.0 x .125<br>Tk |
| 38      | 532 17 91-14 | Pulley, Composite                                                      | 158     | 532 16 55-89 | Bracket Shift Mount                     |
| 39      | 874 76 06-48 | Bolt                                                                   | 159     | 532 18 39-00 | Hub Tapered Flange Shift LT             |
| 41      | 532 17 55-56 | Keeper, Belt Idler                                                     | 161     | 872 14 04-06 | Bolt Rdhd Sqnrk 1/4-20 x 3/4 Gr. 5      |
| 47      | 532 12 77-83 | Pulley, Idler, V-Groove                                                | 162     | 873 68 04-00 | Nut Crownlock 1/4-20 Unc                |
| 48      | 532 15 44-07 | Bellcrank Clutch Grnd Drv Stl                                          | 163     | 874 78 04-16 | Bolt Hex Fin 1/4-20 unc x 1 Gr. 5       |
| 49      | 532 12 32-05 | Retainer, Belt                                                         | 164     | 819 09 10-10 | Washer 5/8 x .281 x 10 Ga               |
| 50      | 872 11 06-12 | Bolt Carr Sh 3/8-16 x 1-1/2 Gr. 5                                      | 165     | 532 16 56-23 | Bracket Pivot Lever                     |
| 51      | 873 68 06-00 | Nut                                                                    | 166     | 532 16 68-80 | Screw 5/16-18 x 5/8 TT Yellow           |
| 52      | 873 68 05-00 | Nut Crownlock 5/16-18                                                  | 168     | 532 16 54-92 | Bolt Shoulder 5/16-18 x .561 TT         |
| 53      | 532 10 57-10 | Link, Clutch                                                           | 169     | 532 16 55-80 | Plate Fastening Cross Shf. STLT/<br>CRD |
| 55      | 532 10 57-09 | Spring, Return, Clutch                                                 | 197     | 532 16 96-13 | Nyliner Snap-In 5/8" ID                 |
| 56      | 817 06 06-20 | Screw 3/8-16 x 1-1/4                                                   | 198     | 532 16 95-93 | Washer Nyl. 7/8 ID x .105"              |
| 57      | 532 14 02-94 | V-Belt, Ground Drive                                                   | 199     | 532 16 96-12 | Bolt Shoulder 5/16-18 Unc               |
| 59      | 532 16 96-91 | Keeper, Center Span                                                    | 200     | 872 14 05-08 | Bolt Rdhd Sq Neck 5/16-18unc x 1        |
| 61      | 817 12 06-14 | Screw 3/8-16 x .875                                                    | 202     | 872 11 06-14 | Bolt Carr Sh 3/8-16 x 1-3/4 Gr. 5       |
| 62      | 532 12 48-72 | Cover, Pedal                                                           | 205     | 819 17 16-16 | Washer 17/32 x 1 x 16 Ga.               |
| 63      | 532 17 54-10 | Pulley, Clutch Eng                                                     | 212     | 532 14 52-12 | Nut Hex Flg Lock                        |
| 64      | 871 17 07-64 | Bolt Hex 7/16-20 x 4 Ga. 5                                             | 250     | 817 06 06-12 | Screw 3/8-16 x 3/4                      |
| 65      | 810 04 07-00 | Washer                                                                 |         |              |                                         |
| 66      | 532 15 47-78 | Keeper Belt Engine                                                     |         |              |                                         |
| 70      | 532 13 46-83 | Guide Belt Mower Drive RH                                              |         |              |                                         |

**NOTE:** All component dimensions give in U.S. inches.  
1 inch = 25.4 mm.

**TRACTOR - - MODEL NO.YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90**  
**STEERING ASSEMBLY**



# REPAIR PARTS


## TRACTOR - - MODEL NO.YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90 STEERING ASSEMBLY

| KEY NO. | PART NO.     | DESCRIPTION                         |
|---------|--------------|-------------------------------------|
| 1       | 532 18 54-37 | Wheel Steering                      |
| 2       | 532 17 51-31 | Axle Asm                            |
| 3       | 532 16 98-40 | Spindle Asm LH                      |
| 4       | 532 16 98-39 | Spindle Asm RH                      |
| 5       | 532 12 49-31 | Bearing Race Thrust Harden          |
| 6       | 532 12 17-48 | Washer 25/32 X 1-5/8 X 16 Ga        |
| 7       | 819 27 20-16 | Washer 27/32 X 1-1/4 X 16 Ga        |
| 8       | 812 00 00-29 | Ring Klip #t5304-75                 |
| 9       | 532 12 49-37 | Bearing Col Strg Blk                |
| 10      | 532 17 51-21 | Link Drag                           |
| 11      | 810 04 06-00 | Washer Lock Hvy Hlcl Spr 3/8        |
| 12      | 873 94 08-00 | Nut Hex Jam Toplock 1/2-20 Unf      |
| 13      | 532 13 65-18 | Spacer Brg Axle Front               |
| 15      | 532 14 52-12 | Nut Hex Flange Lock                 |
| 17      | 532 18 06-41 | Shaft Asm Strg                      |
| 26      | 532 12 68-47 | Bushing Link Drag Blk LR            |
| 28      | 819 13 14-16 | Washer 13/32 X 7/8 X 16 Ga          |
| 29      | 817 06 06-12 | Screw 3/8-16x3/4                    |
| 30      | 876 02 04-12 | Pin Cotter 1/8 X 3/4 Cad            |
| 32      | 532 13 04-65 | Rod Tie Wire Form 19 75 Mech        |
| 36      | 532 15 50-99 | Bushing Strg                        |
| 37      | 532 15 29-27 | Screw                               |
| 38      | 532 16 66-26 | Cap Wheel Steering                  |
| 39      | 819 18 24-11 | Washer 9/16 ID X 1-1/2 OD 11 G. Zin |
| 40      | 532 12 47-01 | Lock nut                            |
| 41      | 532 15 99-45 | Adaptor Wheel Strg                  |
| 42      | 532 16 96-34 | Boot Steering Shaft                 |
| 43      | 532 12 17-49 | Washer 25/32 X 1 1/4 X 16 Ga        |
| 44      | 532 18 06-40 | Extension Steering Shaft LR/LT      |
| 46      | 532 12 12-32 | Cap Spindle Fr Top Blk              |
| 47      | 532 18 32-26 | Fitting Grease                      |
| 51      | 873 54 04-00 | Nut Crownlock 1/4-28                |
| 54      | 871 13 04-20 | Bolt Hex 1/4-28unf x 1-1/4 Ga. 8    |
| 65      | 532 16 03-67 | Spacer Brace Axle                   |
| 68      | 532 16 98-27 | Axle, Brace                         |
| 71      | 532 17 51-46 | Steering Asm                        |
| 82      | 532 16 98-35 | Bracket Susp Chassis Front          |
| 85      | 532 13 38-35 | Fastner Christmas Tree              |
| 88      | 532 17 51-18 | Bolt Shoulder 7/16-20               |
| 91      | 532 17 55-53 | Clip Steering                       |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
SEAT ASSEMBLY




| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 14 08-39 | Seat                           |
| 2       | 532 14 05-51 | Bracket Pivot Seat 8 720       |
| 3       | 871 11 06-16 | Bolt Fin Hex 3/8-16unc X 1     |
| 4       | 819 13 16-10 | Washer 13/32 X 1 X 10 Ga       |
| 5       | 532 14 50-06 | Clip Push-In                   |
| 6       | 873 80 06-00 | Nut Hex w/Ins. 3/8-16 Unc      |
| 7       | 532 12 41-81 | Spring Seat Cprsn 2 250 Blk Zi |
| 8       | 817 00 06-16 | Screw 3/8-16 X 1               |
| 9       | 819 13 16-14 | Washer 13/32 X 1 X 14 Ga.      |
| 10      | 532 18 24-93 | Pan Seat                       |
| 11      | 532 16 63-69 | Knob Seat                      |
| 12      | 532 12 12-46 | Bracket Mounting Switch        |

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 13      | 532 12 12-48 | Bushing Snap Blk Nyl 50 Id     |
| 14      | 872 05 04-12 | Bolt Rdhd Sqnk 1/4-20x1-1/2    |
| 15      | 532 13 43-00 | Spacer Split 28x 96 Yel Zinc   |
| 16      | 532 12 12-50 | Spring Cprsn 1 27 Blk Pnt      |
| 17      | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr 5 Zinc |
| 21      | 532 17 18-52 | Bolt Shoulder 5/16-18 Unc-2A   |
| 22      | 873 80 05-00 | Nut Hex Lock W/Ins 5/16-18     |
| 24      | 819 17 19-12 | Washer 17/32 X 1-3/16 X 12 Ga. |
| 25      | 532 12 70-18 | Bolt Shoulder 5/16-18 X 62     |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm


# REPAIR PARTS

TRACTOR - - MODEL NO.YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
DECALS



| KEY NO. | PART NO.     | DESCRIPTION                  | KEY NO. | PART NO.            | DESCRIPTION                    |
|---------|--------------|------------------------------|---------|---------------------|--------------------------------|
| 1       | 532 15 70-32 | Decal Oper. Step Thru Eng/Fr | 11      | 532 17 05-64        | Decal SW Husq Prem             |
| 2       | 532 18 58-15 | Decal Side Panel             | 14      | 532 16 03-96        | Decal V-Belt Schematic         |
| 3       | 532 18 58-28 | Decal Hood RH                | 20      | 532 14 50-05        | Decal Bat Dan/Psn              |
| 4       | 532 18 58-29 | Decal Hood LH                | --      | 532 13 83-11        | Decal Handle Lft Height Adjust |
| 5       | 532 18 09-41 | Decal Hood Cust.             | --      | 532 16 92-10        | Decal Bypass Lt Hydro          |
| 6       | 532 18 58-30 | Decal Engine                 | --      | 532 18 58-37        | Decal Replc Part               |
| 7       | 532 17 91-28 | Decal Deck B 42              | --      | <b>532 17 12-84</b> | Pad Footrest RH                |
| 8       | 532 17 05-63 | Decal Warning                | --      | <b>532 17 12-85</b> | Pad Footrest LH                |
| 9       | 532 17 68-22 | Decal Fender Husq            | --      | 532 18 52-00        | Manual Owner's (English)       |
| 10      | 532 15 71-40 | Decal Fender Danger Eng/Fr   | --      | 532 18 52-01        | Manual Owner's (French)        |

## WHEELS & TIRES




| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                    |
| 2       | 532 06 51-39 | Stem Valve                        |
| 3       | 532 10 62-22 | Tire F Ts 15 X 6 0 - 6 Service    |
| 4       | 532 05 99-04 | Tube Front (Service Item Only)    |
| 5       | 532 13 83-36 | Rim Asm 6"front Silver Service    |
| 6       | 532 12 49-57 | Fitting Grease (Front Wheel Only) |
| 7       | 532 12 49-59 | Bearing Flange (Front Wheel Only) |
| 8       | 532 13 83-37 | Rim Asm 8"rear Silver Service     |
| 9       | 532 10 62-68 | Tire R Ts 18x9 5-8 C Service      |
| 10      | 532 12 49-26 | Tube Rear (Service Item Only)     |
| 11      | 532 17 50-39 | Cap Axle Blk 1 50 X 1 00          |
| --      | 532 14 43-34 | Sealant, Tire ( 10 oz. Tube)      |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
ENGINE



# REPAIR PARTS


TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
ENGINE

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                                                  |
|------------|--------------|--------------------------------------------------------------|
| 1          | 532 17 08-05 | Control Th/ch Flag                                           |
| 2          | 817 72 04-08 | Screw Hex Thd Cut 1/4-20 x 1/2                               |
| 3          | -----        | Engine, Kohl CV492<br>(Order parts from engine manufacturer) |
| 4          | 532 17 46-67 | Muffler                                                      |
| 13         | 532 16-38-31 | Gasket Eng                                                   |
| 14         | 532 14 84-56 | Tube Drain Oil Easy                                          |
| 16         | 811 05 06-00 | Washer Lock Ext Tooth 3/8                                    |
| 23         | 532 16 98-37 | Shield Brn/Dbr Guard                                         |
| 29         | 532 13 71-80 | Kit Spark Arrestor (Flat Scrn)                               |
| 31         | 532 18 49-00 | Tank Fuel Front                                              |
| 32         | 532 14 05-27 | Cap Asm Fuel W/sym Vented                                    |
| 33         | 532 12 34-87 | Clamp Hose Black                                             |
| 37         | 532 13 70-40 | Line Fuel 20"                                                |
| 38         | 532 18 16-54 | Plug Drain Oil Easy                                          |
| 40         | 532 12 40-28 | Bushing Snap Nyl Blk Fuel Line                               |
| 44         | 817 67 04-12 | Screw Hexwsh Thdrol 1/4-20 x 3/4                             |
| 45         | 817 00 06-12 | Screw Hexwsh Thdr 3/8-16 x 3/4                               |
| 46         | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga                                    |
| 77         | 819 10 12-16 | Washer 5/16x 3/4 x 16 Ga.                                    |
| 80         | 874 76 05-08 | Bolt Hex Hd 5/16-18 x 1/2                                    |
| 101        | 532 16 33-05 | Nut Flange M8 1.25 N/LK Zinc                                 |
| 105        | 817 12 06-16 | Screw 3/8-16 x 1                                             |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
MOWER DECK



42\_D\_man-t-path\_stt1\_3.

# REPAIR PARTS


## TRACTOR - - MODEL NO.YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90 MOWER DECK

| KEY NO. | PART NO.            | DESCRIPTION                                                            | KEY NO. | PART NO.     | DESCRIPTION                                                                                   |
|---------|---------------------|------------------------------------------------------------------------|---------|--------------|-----------------------------------------------------------------------------------------------|
| 1       | 532 16 58-92        | Deck Asm MWR 42"weldment                                               | 91      | 532 18 05-32 | Bracket Roller Nose LH                                                                        |
| 2       | 872 14 05-06        | Bolt Rdhd Sqnk 5/16-18unc X3/4                                         | 92      | 873 80 06-00 | Nut Lock Hex w/Ins. 3/8-16 Unc                                                                |
| 3       | 532 13 80-17        | Bracket Asm Fr Sway Bar 38/42                                          | 94      | 532 13 22-64 | Roller Nose                                                                                   |
| 4       | 532 16 54-60        | Bracket Asm Deck 42"sway Bar                                           | 95      | 532 18 05-33 | Bracket Roller Nose RH                                                                        |
| 5       | 532 12 46-70        | Retainer Spring                                                        | 101     | 532 13 64-20 | Cover Mulch 42"                                                                               |
| 6       | 532 17 80-24        | Deck Sway Bar                                                          | 102     | 871 08 10-10 | Screw Pan Head Phillip 10-24 x 5/8                                                            |
| 8       | 532 85 08-57        | Bolt 3/8 - 24 X 1.25 Gr 8                                              | 103     | 819 06 12-16 | Washer #10                                                                                    |
| 9       | 810 03 06-00        | Washer Lock Hvy 3/8                                                    | 104     | 810 07 10-00 | Washer Lock #10                                                                               |
| 10      | 532 14 02-96        | Washer Hard Blade Mower Vented<br>(The following blades are available) | 105     | 532 16 07-93 | Latch Asm. Mulch                                                                              |
| 11      | 532 13 41-49        | Blade, 42" Mulching Std (For mulching mowers only)                     | 106     | 532 12 50-04 | Nut Weld #10-24                                                                               |
| --      | 532 13 97-75        | Blade, 42" Mulching Premium (For better wear when mulching)            | 111     | 532 17 92-92 | Bracket Wheel Gauge LH 42" Deck                                                               |
| --      | 532 13 89-71        | Blade, 42" Hi-Lift (For bagging or discharging)                        | 112     | 532 17 92-93 | Bracket Gauge Wheel RH 42" Deck                                                               |
| 13      | 532 13 76-45        | Shaft Asm W/lower Bearing                                              | 113     | 817 06 05-10 | Screw Tapping 3/8-16 x .625                                                                   |
| 14      | 532 12 87-74        | Housing Mandrel Vented                                                 | 114     | 873 51 05-00 | Nut Keps 5/16-18 Unc                                                                          |
| 15      | 532 11 04-85        | Bearing Ball Mandrel                                                   | 116     | 532 12 48-42 | Bolt Shoulder                                                                                 |
| 16      | 532 17 44-93        | Stripper Mower                                                         | 117     | 532 16 57-46 | Wheel Gauge                                                                                   |
| 18      | 872 14 05-05        | Bolt Rdhd Sqnk 5/16-18 X 5/8                                           | 118     | 873 93 06-00 | Nut Centerlock 3/8-16 UNC                                                                     |
| 19      | 532 13 28-27        | Bolt Shoulder                                                          | 119     | 819 12 14-14 | Washer 3/8 x 7/8 x 14 Ga.                                                                     |
| 20      | 532 15 97-70        | Baffle Vortex 42                                                       | 129     | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga.                                                                 |
| 21      | 873 68 05-00        | Nut Crownlock 5/16-18 UNC                                              | 130     | 872 14 06-08 | Bolt RdHd Sqnk 3/8-16 Unc x 1                                                                 |
| 23      | 532 17 75-63        | Bracket Deflector Mower 42"                                            | 131     | 874 78 06-16 | Bolt Fin Hex 3/8-16 Unc x 1 Gr. 5                                                             |
| 24      | 532 10 53-04        | Cap Sleeve 80x 112 Blk Mower                                           | 132     | 817 00 06-12 | Screw Hex Wsh Thdr. 3/8-16 x 3/4                                                              |
| 25      | 532 12 37-13        | Spring Torsion Deflector 2 52                                          | 142     | 532 16 58-90 | Arm Spring Brake Mower                                                                        |
| 26      | 532 11 04-52        | Nut Push Phos & Oil                                                    | 143     | 532 15 71-09 | Bracket Arm Idler 42"                                                                         |
| 27      | 532 17 18-59        | Shield Deflector Mower 42" Blk                                         | 144     | 532 15 86-34 | Keeper Belt 42" Clutch                                                                        |
| 28      | 819 11 10-16        | Washer 11/32 X 5/8 X 16 Ga                                             | 145     | 532 16 58-88 | Pulley Idler Flat                                                                             |
| 29      | 532 13 14-91        | Rod Hinge 42"6 75 Wlg                                                  | 146     | 532 17 19-77 | Bolt Carriage Idler                                                                           |
| 30      | 532 17 39-84        | Screw Thd Rolling                                                      | 147     | 532 13 13-35 | Spring Extension                                                                              |
| 31      | 532 12 99-63        | Washer Spacer Mower Vented                                             | 148     | 532 16 90-22 | Spring Return Idler                                                                           |
| 32      | 532 15 35-35        | Pulley Mandrel 42"                                                     | 149     | 532 16 58-98 | Retainer Spring Yellow                                                                        |
| 33      | 532 17 83-42        | Nut Toplock Flng                                                       | 150     | 819 09 12-16 | Washer 9/32 x 3/4 x 16 Ga.                                                                    |
| 34      | 872 11 06-14        | Bolt Rdhd 3/8-16uncx1-3/4 Gr5                                          | 151     | 532 16 96-70 | Bracket Clutch Cable                                                                          |
| 36      | 532 13 14-94        | Pulley Idler Flat 3 060                                                | 152     | 532 16 96-76 | Clutch Cable 42"                                                                              |
| 37      | 819 13 13-16        | Washer 13/32 X 13/16 X 16                                              | 153     | 532 16 96-74 | Washer Flat 3/8" Type B                                                                       |
| 40      | 873 68 06-00        | Nut Crownlock 3/8-16 UNC                                               | 154     | 532 16 96-75 | Spring Retainer                                                                               |
| 44      | 532 14 00-88        | Guard Mandrel LH Black                                                 | 155     | 532 16 96-71 | Spring Retention Lvr Cltch Cab                                                                |
| 45      | 532 12 47-88        | Spring Retainer 1" Zinc/cad                                            | 156     | 532 16 96-72 | Spacer Clutch Cable                                                                           |
| 46      | 532 13 77-29        | Screw Hex Thd Cut 1/4-20 x 5/8 T                                       | 157     | 532 16 96-69 | Rod Clutch Cable 3/8"                                                                         |
| 48      | 532 13 39-44        | Washer Hardened Smaller                                                | 158     | 817 72 04-08 | Screw Hex Thd Cut 1/4-20 x 1/2                                                                |
| 52      | 532 13 98-88        | Bolt Shoulder 5/16-18 Unc Blkz                                         | 159     | 872 14 06-14 | Bolt Rdhd Sqn 3/8-16 Unc x 1-3/4                                                              |
| 53      | <b>532 18 49-07</b> | Arm Asm Pad Brake                                                      | 182     | 532 17 91-26 | Rod Roller Nose                                                                               |
| 54      | 532 17 85-15        | Washer Hardened                                                        | 183     | 532 16 35-52 | Retainer Spring                                                                               |
| 55      | 532 15 50-46        | Arm Idler 42"mower LT/YT                                               | 184     | 819 13 14-10 | Washer 13/32 x 7/8 x 10 Ga.                                                                   |
| 56      | 532 16 57-23        | Spacer Retainer Mower                                                  | --      | 532 13 07-94 | Mandrel Assembly(Includes Hous-<br>ing, Shaft and Shaft Hardware<br>Only-Pulley not Included) |
| 59      | 532 14 10-43        | Guard TUV Idler                                                        | --      | 532 16 95-83 | Replacement Mower, Complete                                                                   |
| 67      | 532 10 69-32        | Knob Rd 3/8-16 Plstc Thds Blk                                          |         |              |                                                                                               |
| 68      | 532 14 49-59        | V-Belt Mower 42"                                                       |         |              |                                                                                               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
MOWER LIFT



# REPAIR PARTS

TRACTOR - - MODEL NO. YTH1842 (YTH1842A), PRODUCT NO. 954 56 97-90  
MOWER LIFT

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                  |
|------------|--------------|------------------------------|
| 1          | 532 15 94-60 | Wire Asm Inner W/plunger LT  |
| 2          | 532 15 94-71 | Shaft Asm Lift               |
| 3          | 532 10 57-67 | Pin Groove                   |
| 4          | 812 00 00-02 | E Ring #5133-62              |
| 5          | 819 21 16-21 | Washer PLTD 21/32 X 1 X 21ga |
| 6          | 532 12 01-83 | Bearing Nylon Blk 629 Id     |
| 7          | 532 10 94-13 | Grip Handle Bicycle          |
| 8          | 532 12 45-26 | Button Plunger Black         |
| 11         | 532 13 98-65 | Link Lift LH                 |
| 12         | 532 13 98-66 | Link Lift RH                 |
| 13         | 532 12 46-70 | Retainer Spring              |
| 15         | 532 17 32-88 | Link Front                   |
| 16         | 873 35 08-00 | Nut Jam Hex 1/2-13 Unc       |
| 17         | 532 17 56-89 | Trunnion                     |
| 18         | 873 80 08-00 | Nut Lock W/Wsh 1/2-13 Unc    |
| 19         | 532 13 98-68 | Arm Suspension Rear          |
| 20         | 532 16 35-52 | Spring, Retainer             |
| 31         | 532 16 98-65 | Bearing Pvt. Lift            |
| 32         | 873 54 06-00 | Nut Crownlock 3/8-24         |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm