

Accessory Guide for Trimmers and Brushcutters

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar



MODEL	Grass	Coarse grass	Bushes and trees
323C/326C	A + 8 10		
325C _x	B + 2 8 10		
323L/325L/325L _x	C D + 1 3 7 9 11 12 14	X X + 20 40	
326L/326L _x	C D + 1 3 7 9 11 12 14	X X + 20 40	
323LD/325LD _x	C D + 1 3 7 9 11 12 14 42 43	X X + 20 40 41 44	
232L (1")	E + 1 3 7 9 11 12 14	Y Y + 20	
323RJ/325RJ _x	C D + 1 3 7 9 11 12 14	D + S + 20 21 40	
323R/325R _x	C D + 1 3 7 9 11 12 14	D + S + 20 21 L + 28 33	
325RD _x /326R _x	C D + 1 3 7 9 11 12 14	D + S + 20 21 L + 28 33	
232R (1")	E + 1 3 7 9 11 12 14	H + S + 20 21 25 N + 28 33	
235R/235RII (1")	E + 4 6 13 J + 13	J + T U + 23 25 27 N + 28 33	
240R/245R	F + 4 5 6 13 I + 13	I + T U + 24 26 Q + 22 R + 29 34 M + 29 34	
250R	F + 4 5 6 13 I + 13	I + U + 24 26 Q + 22 R + 29 34 M + 29 34 O + 30 Z	
245RX	F + 4 5 6 13 I + 13	I + T U + 24 26 Q + 22 R + 29 34 M + 29 34	
252RX	F + 4 5 6	I + U + 24 26 Q + 22 R + 29 34 M + 29 34 O + 30	
265RX	F + 4 5 6	I + U + 26 M + 29 34 O + 30 P + 31	
142RB/152RB (1")	G + 4 6 13	G + T U + 21 25 27	
142RJ/152RJ (1")	G + 4 6 13	G + T U + 21 25 27	

TRIMMER GUARD	SAW BLADE GUARD	SUPPORT CUP
A 537 02 61-01	L 537 02 21-01 (200mm) (incl. adapter)	S 503 89 01-01
B 537 07 67-01	M 502 27 22-01 (200mm)	T 503 90 18-02 (20mm/1")
C 503 97 71-01	N 503 77 39-01 (200mm)	U 502 15 70-02 (Ballbearing)
D 503 93 42-02 combi	O 502 03 94-03 (225mm)	
E 503 74 50-04	P 502 03 95-03 (255mm)	
F 503 91 60-01		
G 531 00 77-01		

BLADE GUARD	PLANT PROTECTION	J-HANDLE KIT
H 503 74 40-01	Q 502 12 26-01 (255mm)	X 537 04 85-01
I 502 26 34-01	R 502 14 55-01 (200mm)	Y 503 78 17-03
J 503 89 52-01		Z 537 16 55-01
K 537 15 36-01		

CUTTING EQUIPMENT			ATTACHMENTS
1 Fix M10 (Fixed) 531 00 38-69	12 Tricut M10 531 00 38-11	27 Multi 300-3 1" 537 14 94-01	40 Saw head 537 18 33-11
2 Fix 3/8" R (Fixed) 531 00 75-34	13 Tricut M12 531 00 38-24	28 Maxi S 200-26 1" 508 90 45-01	40 Saw head 537 18 33-12 (USA)
3 H II 1" (Manual) 531 00 60-92	14 S35 1" (Manual) 531 00 92-24	29 Maxi XS 200-22 508 90 14-01	41 Saw 537 18 33-16
4 Auto 55 1" 531 00 92-26		30 Maxi XS 225-22 508 90 24-01	41 Saw 537 18 33-17 (USA)
5 S (Manual) 508 01 01-02	20 Grass 255-8 1" 537 02 19-01	31 Opti 255-22 502 26 84-01	42 Sweeper 537 19 67-01
6 S II 1" (Manual) 502 26 08-11	21 Grass 255-4 1" 537 14 96-01	32 Shredder blade 537 18 06-01	43 Edger 537 19 69-01
7 T35 1" (Semiauto) 531 00 92-25	22 Multi 255-3 537 14 89-01	33 Scarlett 200-22 537 26 57-01 (1")	44 Hedge trimmer 537 19 66-01
8 Hit VII (R) (Semiauto) 531 00 75-84	23 Multi 255-3 1" 537 14 90-01	34 Scarlett 200-22 537 26 56-01 (20mm)	
9 Hit Pro (Semiauto) 503 78 78-01	24 Multi 275-4 537 14 91-01		
10 Hit Junior 3/8" 531 00 75-28	25 Multi 275-4 1" 537 14 92-01		
11 Super Auto II 1" 531 00 60-93	26 Multi 300-3 537 14 93-01		