

JET 55 S

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

ROTARY LAWN MOWER -- MODEL NUMBER JET55S (JET55SR) PRODUCT NUMBER 954 17 00-93




ROTARY LAWN MOWER - - MODEL NUMBER JET55S (JET55SR) PRODUCT NUMBER 954 17 00-93

KEY NO.	PART NO.	DESCRIPTION
1	532 14 57-94	Control Bar
2	532 16 42-65	Handle Grip
3	532 16 93-69	Upper Handle, with Grip
5	532 08 38-16	Thread Rolling Screw #10-32 x 5/8
6	532 21 31-46	Cable Clamp
7	532 13 63-76	Handle Knob
9	532 06 64-26	Wire Ties
11	532 17 95-85	Rope Guide
12	532 15 41-47	Footguard
13	532 18 21-57	Throttle Control
14	532 14 49-29	Screw
15	532 15 34-18	Lower Handle
16	532 13 19-59	Handle Bolt 5/16-18 x 1-3/4
18	532 08 58-25	Screw
19	532 06 91-80	Nut
17	532 05 17-93	Hairpin Cotter
23	532 05 71-43	Wave Washer
26	532 14 72-86	Hinge Rod
27	532 08 75-89	Torsion Spring
28	532 08 75-93	Housing Bracket Assembly
29	532 85 07-78	Discharge Guard
30	532 15 70-08	Hubcap
31	532 08 39-23	Locknut 3/8-16
33	532 75 05-50	Wheel & Tire Assembly 8.00 x 2.00
34	532 14 27-48	Shoulder Bolt 3/8-16
35	532 06 23-35	Belleville Washer 1/2
36	532 15 12-54	Axle Arm Assembly
37	532 13 28-00	Selector Knob
38	532 12 52-59	Selector Spring
40	532 14 66-30	Spacer
41	532 80 03-70	Wheel Adjusting Bracket (Left)

KEY NO.	PART NO.	DESCRIPTION
42	532 80 03-68	Wheel Adjusting Bracket (Right)
43	532 17 09-77	Handle Bracket Assembly (Left)
44	532 17 09-75	Handle Bracket Assembly (Right)
45	532 17 05-00	Lawn Mower Housing
47	532 14 97-41	Self Tapping Screw 5/16-18 x 3/4
48	532 75 15-92	Locknut 3/8-16
49	532 06 36-01	Locknut 1/4-20
52	532 12 50-78	Washer
53	532 18 20-02	Debris Shield
54	532 15 04-06	Hex Head Thread Rolling Screw 3/8-16 x 1
55	532 85 10-84	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
56	532 85 02-63	Washer, Lock Helical 3/8
57	532 85 10-74	Hardened Washer
58	532 15 71-01	22" Blade
59	532 85 15-14	Blade Adapter
60	532 18 21-66	Danger Decal
61	532 17 04-91	Front Baffle Kit
66	532 08 45-96	Engine Pulley
67	532 08 76-77	Hi-Pro Key #HP 505
70	---	Engine - Briggs & Stratton Model No. 12H802 (Order parts from engine manufacturer)
71	532 13 20-04	Nut, Hex
74	817 60 04-06	Screw
75	532 18 21-34	Warning Decal (Not Shown)
76	532 14 92-93	Cable, Engine Zone Control
77	532 12 54-44	Plate, Mulching
--	532 12 53-81	Rear Baffle (Not Shown)
--	532 17 78-79	Operator's Manual, European
--	532 17 78-80	Operator's Manual, Scandinavian

NOTE:All component dimensions given in U.S. inches.
1 inch = 25.4 mm

ROTARY LAWN MOWER - - MODEL NUMBER JET55S (JET55SR) PRODUCT NUMBER 954 17 00-93



ROTARY LAWN MOWER - - MODEL NUMBER JET55S (JET55SR) PRODUCT NUMBER 954 17 00-93

5


KEY NO.	PART NO.	DESCRIPTION
1	532 18 45-88	Drive Control
2	532 15 87-55	Hex Washer Hd Screw 1/4-20 x 2-1/8
3	532 75 11-52	Locknut
5	532 14 65-27	V-Belt
6	532 75 00-97	Hex Washer Head Screw #10-24 x 1/2
8	532 13 28-00	Selector Knob
9	532 15 04-95	Spring Retainer
10	532 15 10-09	Wheel Adjuster Assembly (Left)
11	532 15 10-10	Wheel Adjuster Assembly (Right)
12	532 18 05-04	Dust Cover
13	532 13 70-54	Pinion
14	812 00 00-58	E-Ring
15	532 18 07-59	Wheel & Tire Assembly 8.00 x 2.00
17	532 06 77-25	Washer
18	532 08 39-23	Locknut
19	532 15 70-08	Hubcap

KEY NO.	PART NO.	DESCRIPTION
20	532 08 60-12	Drive Shaft Cover
22	532 13 70-90	Spring
23	532 70 25-11	Gear Case Assy. (See Breakdown)
25	532 07 51-92	Spring
27	532 13 70-52	Drive Pulley
28	532 13 20-10	Flanged Locknut
32	532 14 60-72	Pan Head Tapping Screw #10-24 x 2-3/4
34	532 70 04-22	Drive Cover
36	532 06 36-01	Locknut
37	532 05 71-43	Spring Wave Washer

Available accessories not included with lawn mower:
 - - GCK5000 Grass Catcher

NOTE:All component dimensions given in U.S. inches.
 1 inch = 25.4 mm

ROTARY LAWN MOWER
MODEL NUMBER JET55S (JET55SR) - PRODUCT NUMBER 954 17 00-93
GEAR CASE ASSEMBLY - - PART NUMBER 532 70 25-11



KEY NO.	PART NO.	DESCRIPTION
1	817 49 04-16	Tapping Screw 1/4-20 x 1-1/4
2	532 14 02-69	Engagement Bracket
3	532 13 70-53	Shifter
4	532 05 70-72	Seal
6	532 04 83-73	Gear Case Halves Kit (Includes Key Numbers 4 and 7)
7	532 07 78-81	Bearing
8	532 13 70-51	Worm Shaft
9	532 13 70-74	Drive Shaft
10	532 05 70-79	Hardened Washer
11	532 13 14-84	Clutch Yoke
12	532 70 03-43	Bushing
13	532 08 64-47	Plug
14	532 13 70-50	Helical Gear
15	532 75 04-36	Clutch Jaw
16	532 75 03-69	Grease
17	812 00 00-03	E-Ring
18	532 85 08-48	Hi-Pro Key
19	532 12 54-41	Spring Bracket

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm