

JET 49

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

ROTARY LAWN MOWER - - MODEL NUMBER HUSKY JET (JET49M) PRODUCT NUMBER 954 16 31-01



ROTARY LAWN MOWER - - MODEL NUMBER HUSKY JET (JET49M) PRODUCT NUMBER 954 16 31-01

KEY NO.	PART NO.	DESCRIPTION
1	532 08 69-02	Control Bar
2	532 17 95-85	Rope Guide
3	532 75 06-34	Hex Washer Head Self-tapping Screw #10-24 x 1/2
4	532 17 35-42	Lower Handle
5	532 21 31-46	Cable Clamp (Engine)
6	532 06 36-01	Locknut 1/4-20
7	532 17 35-41	Upper Handle
8	532 70 08-92	Engine Zone Control Cable
9	874 35 04-24	Hex Head Bolt 1/4-20 x 1-1/2
10	532 12 51-62	Up-Stop Bracket
11	532 06 64-26	Wire Tie
12	532 13 70-09	Hex Head Bolt 3/8-16 x 1
13	532 14 15-19	Front Baffle
15	532 08 58-25	Screw
16	532 06 91-80	Nut
17	532 12 50-78	Engine Washer
19	532 75 20-52	Discharge Guard
20	532 06 76-09	Shoulder Bolt
21	532 80 00-60	Wheel Assembly 7.00 x 1.50
22	532 13 66-24	Spacer Washer
23	532 18 21-66	Danger Decal
24	532 05 56-11	Washer
25	532 15 41-47	Foot Guard
27	532 13 20-10	Flange Locknut 3/8-16
28	874 76 04-12	Hex Head Bolt 1/4-20 x 3/4

KEY NO.	PART NO.	DESCRIPTION
30	532 15 04-06	Hex Head Thread Rolling Screw 3/8-16 x 1
33	532 16 22-26	Housing Kit
34	532 85 09-77	Blade Adapter
35	532 85 09-72	Blade 20"
36	532 85 10-74	Washer (Hardened)
37	532 85 02-63	Helical Lock Washer
38	532 85 10-84	Hex Head Machine Screw 3/8-24 x 1-3/8 Gr. 8
39	- - -	Engine, Briggs & Stratton, Model No. 9D902 (Order parts from engine manufacturer)
40	532 13 20-04	Hex Nut 1/4-20
41	532 18 21-58	Throttle Cable STD
42	532 15 87-55	Hex Washer Hd Screw 1/4-20 x 2.0
45	532 75 15-92	Locknut 5/8- 16
46	532 08 38-16	Screw, #10 x 5/8
47	532 08 79-30	Cable Clip, Throttle
48	532 12 84-15	Pop Rivet
49	532 16 22-34	Deflector Bracket
--	532 16 30-73	Operator's Manual (Scand.)
--	532 16 30-74	Operator's Manual (Euro.)
--	532 14 15-20	Rear Baffle (Not Shown)

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm