




# SPARE PARTS LIST

TRACTORS/RIDE MOWERS

LT151, 96011000100, 954170240,  
2005-01

# REPAIR PARTS

TRACTOR - MODEL NO. LT151 (96011000100), PRODUCT NO. 954 17 02-40  
CHASSIS AND ENCLOSURES




## CHASSIS &amp; ENCLOSURES

LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
1	532 17 46-19	FRAME		1
2	532 17 65-54	PLATE		1
5	532 15 52-72	DAMPER		1
9	532 19 39-37	DASH		1
10	872 14 06-08	BOLT		1
11	532 17 49-96	DASHBOARD		1
13	532 18 17-19	DASHBOARD		1
14	817 49 06-08	SCREW		1
17	532 18 88-93	HOOD		1
18	532 18 49-21	BUMPER		1
26	873 80 06-00	NUT		1
28	532 18 35-38	GRILL		1
30	532 19 39-38	FENDER		1
31	532 13 99-76	BRACKET		1
37	817 49 05-08	SCREW		1
38	532 17 57-10	BRACKET		1
39	532 17 47-14	BRACKET PIVOT LASER LT		1
58	532 18 71-54	DUCT		1
60	872 14 06-06	BOLT		1
64	532 15 47-98	PANEL		1
74	873 68 06-00	NUT		1
142	532 17 57-02	PLATE		1
143	532 18 66-89	BRACKET		1
144	532 17 55-82	BRACKET		1
145	532 15 65-24	SHAFT		1
206	532 17 01-65	BOLT		1
207	817 67 05-08	SCREW		1
208	817 67 06-08	SCREW		1
209	817 00 06-12	SCREW		1
212	532 18 35-48	INSERT		1
258	532 18 52-14	LENS		1
259	532 18 52-13	LENS		1
260	532 18 52-16	INSERT		1
261	532 18 52-12	INSERT		1
272	532 18 88-95	VENT HOOD LH		1
273	532 18 88-96	VENT HOOD RH		1
278	532 19 16-11	SCREW		1
--	532 00 54-79	PLUG		1
--	532 18 78-01	PLUG		1
--	532 19 39-35	PLUG		1

### REPAIR PARTS

TRACTOR - MODEL NO. LT151 (96011000100), PRODUCT NO. 954 17 02-40  
DECALS




## DECALS

LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
1	532 19 11-49	DECAL		1
2	532 14 08-37	DECAL		1
3	532 18 89-23	DECAL		1
4	532 19 44-01			1
5	532 18 89-25	DECAL		1
6	532 18 04-32	DECAL		1
7	532 18 89-21	DECAL		1
8	532 18 21-66	DECAL		1
9	532 18 89-28	DECAL		1
10	532 14 54-98	DECAL		1
11	532 15 97-36	DECAL		1
12	532 15 97-37	DECAL		1
14	532 13 68-32	DECAL		1
20	532 14 50-05	DECAL		1
--	532 18 82-52	PAD, FOOTREST LH		1
--	532 16 25-98	DECAL		1
--	532 18 82-53	PAD, FOOTREST RH		1
--	532 13 83-11	DECAL		1
--	532 19 38-77	OPERATORS MANUAL		1
--	532 19 38-78	OPERATORS MANUAL		1

# REPAIR PARTS

TRACTOR - MODEL NO. LT151 (96011000100), PRODUCT NO. 954 17 02-40  
DRIVE



## DRIVE

LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
2	532 14 66-82	SPRING		1
3	532 12 36-66	PULLEY		1
4	812 00 00-28	CLIP		1
5	532 12 15-20	BRACKET		1
6	817 06 05-12	SCREW		1
8	532 19 25-02	ROD SHIFT		1
10	876 02 04-16	SPLIT PIN		1
11	532 10 57-01	WASHER		1
13	874 55 04-12	BOLT		1
14	810 04 04-00	WASHER		1
15	874 49 05-44	SCREW		1
16	873 80 05-00	LOCK NUT		1
18	874 78 06-16	BOLT		1
19	873 80 06-00	NUT		1
21	532 12 12-74	KNOB		1
22	532 13 08-04	ROD		1
24	873 35 06-00	NUT		1
25	532 10 68-88	SPRING		1
26	819 13 13-16	WASHER		1
27	876 02 04-12	SPLIT PIN		1
28	532 17 57-65	SHAFT		1
29	532 07 16-73	COVER		1
30	532 17 49-73	BRACKET		1
32	874 76 05-12	BOLT		1
34	532 17 55-78	SHAFT		1
35	532 12 01-83	BEARING		1
36	819 21 16-16	WASHER		1
37	532 12 49-63	PIN RETAINING SCREW		1
38	532 17 91-14	PULLEY		1
39	872 11 06-22	BOLT		1
41	532 17 55-56	BELT GUIDE		1
47	532 12 77-83	PULLEY		1
48	532 15 44-07	GUIDE		1
49	532 12 32-05	BELT GUIDE		1
50	872 11 06-12	BOLT		1
51	873 68 06-00	NUT		1
52	873 68 05-00	NUT		1
53	532 10 57-10	LINK		1
55	532 10 57-09	SPRING		1
56	817 06 06-20	SCREW		1
57	532 13 08-01	V-BELT		1
59	532 16 96-91	BELT GUIDE		1
61	817 12 06-14	SCREW		1
62	532 12 48-72	PEDAL RUBBER		1
63	532 18 02-19	PULLEY		1
64	532 17 39-37	BOLT		1
65	810 04 07-00	WASHER		1
66	532 15 47-78	TENSIONER		1
69	532 14 24-32	SCREW		1
70	532 18 02-18	BELT GUIDE		1
74	532 13 70-57	SPACER		1
75	532 12 17-49	WASHER		1
76	812 00 00-01	RETAINER RING		1
77	532 12 35-83	KEY		1
78	532 12 17-48	WASHER		1
79	532 12 50-96	WOODRUFF KEY		1
80	532 13 14-86	ROD		1
81	532 16 55-94	SHAFT		1
82	532 16 57-11	SPRING		1
83	819 17 12-16	WASHER		1
84	532 16 62-28	LINK		1
85	532 15 03-60	NUT		1
89	532 19 57-20	BRACKET		1
96	532 12 47-88	RETAINING RING		1

## DRIVE


LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
112	819 09 12-10	WASHER		1
113	532 12 72-85	BRACKET		1
116	872 14 06-08	BOLT		1
120	873 90 06-00	NUT		1
150	532 17 54-56	SPACER		1
151	819 13 32-10	WASHER		1
156	532 16 60-02	WASHER		1
158	532 16 55-89	BRACKET		1
159	532 18 39-00	LEVER		1
161	872 14 04-06	BOLT		1
162	873 68 04-00	NUT		1
163	874 78 04-16	BOLT		1
165	532 16 56-23	BRACKET		1
166	817 49 05-10	SCREW		1
168	532 16 54-92	BOLT		1
169	532 16 55-80	RETAINER		1
170	532 18 74-14	KEEPER BELT T/A		1
197	532 16 96-13	SLEEVE		1
198	532 16 95-93	WASHER		1
202	872 11 06-14	BOLT		1
212	532 14 52-12	NUT		1
263	817 00 06-12	SCREW		1
268	532 18 24-02	PROTECTOR		1
275	819 13 16-14	WASHER		1



# REPAIR PARTS

TRACTOR - MODEL NO. LT151 (96011000100), PRODUCT NO. 954 17 02-40  
ELECTRICAL




## ELECTRICAL

LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
1	532 14 49-27	BATTERY		1
2	874 76 04-12	BOLT		1
8	532 17 66-89	BATTERY BOX		1
16	532 17 61-38	SWITCH INTERLOCK		1
21	532 17 56-88	HARNESS		1
22	532 00 41-52	BULB		1
24	532 12 47-80	CABLE		1
25	532 14 61-47	CABLE		1
26	532 17 51-58	FUSE		1
27	873 51 04-00	NUT		1
28	532 12 47-73	CABLE		1
29	532 12 13-05	SWITCH		1
30	532 17 55-66	SWITCH		1
33	532 14 04-01	KEY		1
40	532 17 97-20	HARNESS		1
41	871 11 04-08	BOLT		1
42	532 13 15-63	COVER		1
43	532 17 88-61	SOLENOID		1
48	532 14 08-44	ADAPTER		1
52	532 14 19-40	PROTECTOR		1
90	532 18 04-49	COVER		1

# REPAIR PARTS

TRACTOR - MODEL NO. LT151 (96011000100), PRODUCT NO. 954 17 02-40  
ENGINE



## ENGINE

LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
1	532 17 08-05	CONTROL THROT /CH FLAG		1
2	817 72 04-08	SCREW		1
4	532 18 86-55	MUFFLER EXHAUST		1
8	532 17 18-77	BOLT		1
13	532 18 59-09	GASKET		1
14	532 14 84-56	TUBE		1
23	532 16 98-37	HEAT SHIELD		1
29	532 13 71-80	SPARK ARRESTER KIT		1
31	532 18 49-00	TANK FUEL FRONT 1.25		1
32	532 14 05-27	FUEL CAP		1
33	532 12 34-87	HOSE CLAMP		1
37	532 13 70-40	HOSE		1
38	532 18 16-54	PLUG		1
40	532 12 40-28	BUSHING		1
44	817 67 04-12	SCREW		1
45	817 00 06-12	SCREW		1
46	819 09 14-16	WASHER		1
81	873 51 04-00	NUT		1
105	817 12 06-16	BOLT		1
116	532 18 43-62	NUT HEX FLANGE TOPLOCK		1
117	532 18 86-54	TUBE EXHAUST		1




## MOWER DECK / CUTTING DECK

LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
1	532 17 45-95	MOWER DECK ASSY		1
2	872 14 05-06	BOLT		1
3	532 13 80-17	BRACKE		1
4	532 17 56-54	BRACKET		1
5	532 12 46-70	RETAINING RING		1
6	532 17 80-24	LEVER		1
7	532 14 06-08	HOLDER		1
8	532 85 08-57	BOLT		1
9	810 03 06-00	WASHER		1
10	532 14 02-96	WASHER		1
11	532 13 84-96	RIDE ON BLADE		1
13	532 13 76-45	SHAFT		1
14	532 12 87-74	BEARING HOUSING		1
15	532 11 04-85	BEARING		1
16	532 17 44-93	STRIPPER. MANDREL.BLACK		1
19	532 13 28-27	SPEC. BOLT		1
21	873 68 05-00	NUT		1
23	532 13 66-31	BRACKET		1
24	532 10 53-04	HUB CAP		1
25	532 12 37-13	SPRING		1
26	532 11 04-52	NUT		1
27	532 17 61-62	SHIELD		1
28	819 11 10-16	WASHER		1
29	532 12 19-80	ROD		1
30	532 17 39-84	SCREW		1
31	532 18 76-90	WASHER		1
32	532 15 35-31	PULLEY		1
33	532 17 83-42	NUT		1
34	872 11 06-14	BOLT		1
36	532 13 14-94	PULLEY		1
40	873 68 06-00	NUT		1
45	532 12 47-88	RETAINING RING		1
53	532 13 08-40	BRAKE LEVER		1
54	532 17 85-15	WASHER		1
55	532 13 38-40	LEVER		1
56	532 16 57-23	SPACER		1
67	532 10 69-32	KNOB		1
68	532 18 02-13	BELT		1
89	819 13 13-11	WASHER		1
92	873 80 06-00	NUT		1
107	532 13 35-02	SPACER		1
108	532 13 35-03	LEVER		1
113	817 49 05-08	SCREW		1
122	532 17 45-05	ROD		1
123	532 17 45-04	ROD		1
129	819 13 13-12	WASHER		1
130	874 78 06-16	BOLT		1
131	872 14 06-08	BOLT		1
146	532 16 58-91	BOLT		1
148	532 16 90-22	SPRING		1
149	532 16 58-98	SPRING		1
150	819 09 12-10	WASHER		1
152	532 17 60-79	CABLE		1
158	817 72 04-08	SCREW		1
164	532 17 49-76	BRACKET		1
168	532 17 23-77	BRACKET		1
169	532 17 49-77	BRACKET		1
170	532 17 23-59	BRACKET		1
171	532 16 52-37	ROD		1
172	532 17 23-55	BRACKET		1
--	532 13 07-94	MANDREL		1
185	532 18 82-34	HEAD ASM. CABLE CLUTCH		1
--	532 18 13-76	HOUSING		1

## REPAIR PARTS

TRACTOR - MODEL NO. LT151 (96011000100), PRODUCT NO. 954 17 02-40  
MOWER LIFT



lift-rh.1piece\_3

## MOWER LIFT / DECK LIFT


LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
1	532 15 94-60	WIRE		1
2	532 15 94-71	LEVER		1
3	532 10 57-67	PIN RETAINING SCREW		1
4	812 00 00-02	RETAINING RING		1
5	819 21 16-21	WASHER		1
6	532 12 01-83	BEARING		1
7	532 10 94-13	GRIP		1
8	532 12 45-26	KNOB		1
11	532 13 98-65	LINK		1
12	532 13 98-66	LINK		1
13	532 12 46-70	RETAINING RING		1
15	532 17 32-88	LINK		1
16	873 35 08-00	NUT		1
17	532 17 56-89	BRACKET		1
18	873 80 08-00	NUT		1
19	532 13 98-68	LEVER		1
20	532 16 35-52	CLIP		1
31	532 16 98-65	BEARING		1
32	873 54 06-00	NUT		1



# REPAIR PARTS

TRACTOR - MODEL NO. LT151 (96011000100), PRODUCT NO. 954 17 02-40  
SEAT ASSEMBLY




## SEAT

LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
1	532 18 49-92	SEAT		1
2	532 14 05-51	BRACKET		1
3	871 11 06-16	SCREW		1
4	819 13 16-10	WASHER		1
5	532 14 50-06	CLIP		1
6	873 80 06-00	NUT		1
7	532 12 41-81	SPRING		1
8	817 00 06-16	SCREW		1
9	819 13 16-14	WASHER		1
10	532 18 24-93	BRACKET		1
11	532 16 63-69	WING NUT		1
12	532 12 12-46	BRACKET		1
13	532 12 12-48	BUSHING		1
14	872 05 04-12	BOLT		1
15	532 13 43-00	SPACER		1
16	532 12 12-50	SPRING		1
17	532 12 39-76	LOCKNUT		1
21	532 17 18-52	BOLT		1
22	873 80 05-00	LOCK NUT		1
24	819 17 19-12	WASHER		1
25	532 12 70-18	BOLT		1

# REPAIR PARTS

TRACTOR - MODEL NO. LT151 (96011000100), PRODUCT NO. 954 17 02-40  
STEERING ASSEMBLY



## STEERING


LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
1	532 19 39-43	WHEEL STEERING		1
2	532 17 51-31	AXLE		1
3	532 16 98-40	SPINDLE		1
4	532 16 98-39	SPINDLE		1
5	532 12 49-31	WASHER		1
6	532 12 17-48	WASHER		1
7	819 27 20-16	WASHER		1
8	812 00 00-29	RETAINER RING		1
9	532 12 49-37	BEARING COL. STRG.		1
10	532 17 51-21	ROD		1
11	810 04 06-00	WASHER		1
13	532 13 65-18	PIPE		1
15	532 14 52-12	NUT		1
17	532 19 07-53	ROD		1
29	817 00 06-12	SCREW		1
32	532 17 18-88	ROD		1
33	819 11 12-16	WASHER		1
34	810 04 05-00	WASHER		1
35	873 54 05-00	NUT		1
36	532 15 50-99	BUSHING		1
37	532 15 29-27	SCREW		1
38	532 19 36-52	HUB		1
39	819 11 38-12	WASHER		1
40	873 54 06-00	NUT		1
41	532 18 67-37	ADAPTER		1
42	532 16 96-34	SLEEVE		1
43	532 12 17-49	WASHER		1
44	532 19 07-52	SHAFT		1
46	532 12 12-32	HUB CAP		1
47	532 18 32-26	FITTING		1
65	532 16 03-67	SPACER		1
67	872 11 06-18	BOLT		1
68	532 16 98-27	SHAFT		1
71	532 17 51-46	STEERING GEAR		1
82	532 16 98-35	BRACKET		1
88	532 17 51-18	BOLT		1
91	532 17 55-53	SPRING		1
95	532 18 89-67	WASHER		1
97	874 78 05-64	BOLT		1

# REPAIR PARTS

TRACTOR - MODEL NO. LT151 (96011000100), PRODUCT NO. 954 17 02-40

## WHEELS & TIRES



## WHEELS &amp; TIRES

LT151, 96011000100, 954170240, 2005-01

Ref	Part No	Description	Remark	QTY KIT
1	532 05 91-92	CAP VALVE		1
2	532 06 51-39	NIPPLE		1
3	532 10 62-22	TIRE		1
4	532 05 99-04	HOSE		1
5	532 13 83-36	RIM SPROCKET		1
6	532 12 49-57	FITTING		1
7	532 12 49-59	BEARING		1
8	532 13 83-37	RIM SPROCKET		1
9	532 10 62-68	TIRE		1
10	532 12 49-26	HOSE		1
11	532 17 50-39	HUB CAP		1
--	532 14 43-34	SEALING FOAM		1