








# SPARE PARTS LIST

HEDGE TRIMMERS/POLE HEDGE  
TRIMMERS

326 HD60 X-SERIES, 2006-07

**N** Accessories  
Zubehöre  
Accessoires  
Acessorios  
Tillbehör

\*compl 502 21 60-09




## ACCESSORIES

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
501 69 17-01	COMBINATION WRENCH		1
502 21 60-09	ACCESSORY BAG		1
503 55 86-01	SPANNER		1
503 98 96-01	GREASE		1
531 00 75-12	GREASE		1
531 00 75-13	GREASE		1
531 00 92-05	GREASE		1

**M** compl 503 28 34-02

**ZAMA C1Q - EL 25A**




① 531 00 45-52  
**Set of gaskets**  
**Dichtungssatz**  
**Juego de juntas**  
**Jeu de joints**  
**Packningssats**

② 531 00 45-53  
**Repairkit**  
**Reparatursatz**  
**Juego de reparación**  
**Kit de réparation**  
**Reparationsatz**

## CARBURETOR

326 HD60 X-SERIES, 2006-07


Part No	Description	Remark	QTY KIT
503 28 34-02	CARBURETTOR		1
503 47 89-01	COLLAR		1
503 47 90-01	SCREW		1
503 47 92-01	SCREW		1
503 47 96-01	SCREW		1
503 47 97-01	VALVE		1
503 48 00-01	PIN RETAINING SCREW		1
503 48 01-01	SCREW		1
503 48 05-01	SCREW		2
503 48 08-01	SPRING		1
503 48 11-01	PIECE		1
503 48 18-01	SCREW		1
503 48 19-01	COLLAR		1
503 53 57-01	STRAINER		1
503 66 59-01	LEVER		1
503 75 53-01	SCREW		1
503 97 40-01	WASHER		1
503 97 43-01	COVER		1
537 01 25-01	BALL		1
537 01 26-01	SPRING		1
537 01 96-01	SHAFT ASSY		1
537 01 97-01	SPRING		1
537 01 98-01	LEVER		1
537 01 99-01	VALVE		1
537 02 00-01	DIAPHRAGM PUMP		1
537 02 01-01	GASKET		1
537 02 02-01	COVER		1
537 02 03-01	SPRING		1
537 02 04-01	GASKET		1
537 02 06-01	SCREW		1
537 02 07-01	SCREW		1
537 02 08-01	PLUG		1
537 02 09-01	SHAFT ASSY		1
537 02 10-01	SPRING		1
537 02 16-01	LIMITER CAP		1
537 02 16-01	LIMITER CAP		1
537 04 89-01	DIAPHRAGM		1
537 04 90-01	LEVER		1
537 12 78-01	SCREW		1
537 37 03-01	VALVE		1
544 01 82-01	MAIN NOZZLE		1



## CARBURETOR &amp; AIR FILTER

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
502 20 40-01	KNOB		1
502 20 65-03	SCREW EHHM		1
503 20 14-25	SCREW IHSCFMO		2
503 21 75-50	SCREW IHSCFT		2
503 21 77-16	SCREW IHSCFT		1
503 22 65-04	SQUARE NUT		2
503 28 34-02	CARBURETTOR		1
503 49 71-01	GASKET		1
503 91 09-01	INSULATION WALL		1
503 94 26-01	INLET PIPE		1
537 02 33-01	CHOKE CONTROL		1
537 05 78-01	BRACKET		1
537 06 63-01	FILTER COVER		1
537 14 31-01	AIR FILTER ASSY		1
537 14 54-02	CYLINDER COVER		1
731 23 14-01	HEXAGON NUT		1
740 68 11-21	V-RING		1






## COVER

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 21 28-10	SCREW CCRPANT		3
503 21 44-16	SCREW IHSCFTO		1
503 21 62-20	SCREW IHSCFT		2
503 21 62-20	SCREW IHSCFT		2
503 22 72-01	SPEED NUT		1
537 03 44-01	LABEL		1
537 08 05-02	HEAT PROTECTOR		1
537 09 66-01	HEAT SHIELD		1
537 14 54-02	CYLINDER COVER		1
544 11 07-01	LABEL		1

**E** \*compl 537 08 52-01




## CRANKCASE

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 21 62-20	SCREW IHSCFT		7
503 21 66-20	SCREW IHSCFT		1
503 21 71-16	SCREW IHSCFT		2
503 21 77-16	SCREW IHSCFT		1
537 06 68-01	INSERT CRANKCASE		1
537 06 69-01	GASKET CRANKCASE		1
537 08 52-01	CRANKCASE		1
537 08 85-01	GASKET		1
537 10 50-01	SNAP		1

**A** \*compl 537 12 81-03





## CRANKSHAFT

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 71 22-01	BEARING		1
503 94 02-03	BEARING CAGE		1
503 94 05-01	CUP		1
537 12 81-03	CRANKSHAFT ASSY		1
537 12 88-02	BEARING CAGE		1

**J** \*compl 537 10 56-07 326HD60  
 \*compl 537 10 56-08 326HD75




## CUTTING EQUIPMENT

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 20 17-22	SCREW EHHM		5
503 20 17-22	SCREW EHHM		4
503 22 00-05	HEXAGON NUT		2
503 22 00-06	HEXAGON NUT		5
503 22 00-06	HEXAGON NUT		4
503 23 00-24	WASHER		5
503 23 00-24	WASHER		4
503 23 00-24	WASHER		1
503 92 28-02	SCREW		2
537 05 05-01	BASEPLATE		1
537 10 01-05	BLADE	One piece/package	2
537 10 01-06	BLADE	One piece/package	2
537 10 03-01	PROTECTIVE PLATE		1
537 10 56-07	CUTTING DECK		1
537 10 56-08	CUTTING DECK		1
537 10 70-01	BEAM		1
537 10 70-02	BEAM		1
537 11 08-01	TRANSPORT GUARD		1
537 11 08-02	TRANSPORT GUARD		1
537 37 20-01	COVER		1
725 23 72-71	SCREW EHHM		1
731 23 16-01	HEXAGON NUT		1

**D** \*compl 537 22 16-01

\*\*compl 537 08 51-02






## CYLINDER PISTON

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 20 29-56	SCREW IHSCFM		3
503 23 51-09	SPARK PLUG		1
503 28 90-43	PISTON RING		2
503 71 22-01	BEARING		1
537 08 51-02	PISTON		1
537 17 23-01	AIR CONDUCTOR		1
537 22 16-01	MUFFLER ASSY		1
537 22 18-01	SPARK ARRESTER SCREEN		1
537 37 65-04	PISTON		1
725 53 37-55	SCREW IHSCM		4
737 44 08-00	CIRCLIP		2

**C**




## FUEL TANK

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 44 32-01	FILTER		1
503 73 58-01	BUSHING		2
503 91 10-01	SUSPENSION		4
503 93 66-01	PRIMER HOUSING		1
503 98 47-02	FUEL TANK		1
537 04 24-01	FUEL HOSE		2
537 09 16-03	TANK CAP		1
537 18 49-01	O-RING		1
537 18 49-01	O-RING		1
544 32 50-01	FUEL HOSE		1

**K**

- \*compl 537 18 94-02
- \*\*compl 503 98 23-03
- \*\*\*compl 537 11 02-01
- \*\*\*\*compl 544 08 32-01




## GEAR HOUSING

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 21 27-13	SCREW CCRPANT		1
503 21 62-20	SCREW IHSCFT		3
503 21 68-16	SCREW IHSCFT		2
503 21 68-16	SCREW IHSCFT		6
503 22 72-01	SPEED NUT		1
503 23 00-14	WASHER		1
503 23 03-01	WASHER		1
503 25 05-01	BALL BEARING		1
503 26 32-03	O-RING		1
503 98 17-01	GEAR RIM		1
503 98 19-01	DRIVE SHAFT		1
503 98 20-01	NUT		1
503 98 22-01	SPACER		1
503 98 23-03	DRIVE SHAFT		1
537 03 96-01	CLUTCH DRUM		1
537 05 33-01	SEALING		1
537 08 04-01	WEAR PLATE		1
537 09 01-01	GEAR WHEEL SHAFT		1
537 09 03-01	WASHER		1
537 09 89-01	GUIDE PLATE		1
537 11 02-01	HUB CAP		1
537 17 17-01	BRACKET		1
537 17 35-02	CONNECTING ROD		1
537 17 35-02	CONNECTING ROD		1
537 18 94-02	GEAR HOUSING		1
537 24 25-01	CLUTCH HUB		1
544 08 32-01	CLUTCH ASSY		1
725 64 49-56	SCREW IHCSFM		2
738 21 02-04	BALL BEARING		1
738 21 88-00	BALL BEARING		1
738 21 98-04	BALL BEARING		1
738 88 10-01	LUBRICATION NIPPLE		1

**L** \*compl 537 28 00-05





## HANDLE &amp; CONTROLS

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 21 06-22	SCREW IHSCT		2
503 21 07-16	SCREW IHSCT		3
503 21 27-13	SCREW CCRPANT		1
503 21 29-06	SCREW CCRPANT		1
503 21 68-16	SCREW IHSCT		2
503 21 68-16	SCREW IHSCT		2
503 21 68-16	SCREW IHSCT		2
503 73 45-01	LABEL		1
503 73 45-01	LABEL		1
503 77 05-01	LOCKING BUTTON		1
503 77 06-01	RECOIL SPRING		1
503 77 09-01	SECURING PLATE		1
503 77 10-03	FRONT HANDLE		1
503 79 15-02	LATCH		1
506 01 44-02	THROTTLE TRIGGER		1
537 08 06-01	SPRING		1
537 08 07-01	SPRING		1
537 08 07-01	SPRING		1
537 08 08-01	SPRING		2
537 10 51-02	WIRING		1
537 18 39-01	THROTTLE LOCKOUT		1
537 28 00-05	HANDLE ASSY		1
537 41 90-01	SWITCH		1
734 11 25-41	WASHER		1
740 44 16-00	O-RING		1

**B**

\*compl 537 41 88-01





## IGNITION SYSTEM

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 21 66-18	SCREW IHST		2
537 06 44-03	COVER		1
537 09 17-01	SECURING PLATE		1
537 24 96-02	FLYWHEEL		1
537 41 88-01	ELECTRONIC MODULE		1
731 71 16-51	HEXAGON NUT FLANGE		1

**H** \*compl 544 00 25-01

537 35 34-36 **326HD60**  
537 35 34-37 **326HD75**





537 35 34-36 **326HD60**



537 35 34-37 **326HD75**

\*\*compl 503 87 33-02



## STARTER

326 HD60 X-SERIES, 2006-07

Part No	Description	Remark	QTY KIT
503 21 62-20	SCREW IHSCFT		1
503 21 77-25	SCREW IHSCFT		1
503 85 89-01	STARTER CORD		1
503 85 90-01	RECOIL SPRING		1
503 87 33-02	BRIDGE		1
503 87 35-02	STARTER PAWL		1
503 87 36-01	SPRING		1
537 00 84-01	STARTER HANDLE		1
537 35 34-36	LABEL		1
537 35 34-36	LABEL		1
537 35 34-37	LABEL		1
537 35 34-37	LABEL		1
537 37 93-01	SPACING SLEEVE		2
544 00 24-01	STARTER HOUSING		1
544 00 25-01	STARTER ASSY		1
544 03 86-01	STARTER PULLEY		1
544 03 87-01	DRIVER		1
544 03 88-01	SPRING		1
544 16 65-01	STARTER PULLEY ASSY		1
731 71 16-51	HEXAGON NUT FLANGE		1
735 31 08-20	E-CLIP		1