

125R (Canada Only)

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar

A



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	545036401	Nose Cone - LH	24.	545056201	Assy - Cable Wire	44.	530096295	Assy - Gearbox
2.	545036501	Nose Cone - RH	25.	537174201	Spring - Trigger	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;">Not Shown</div>		
3.	530016448	Screw	26.	537160801	Trigger - Throttle			
4.	530016449	Screw	27.	503216618	Screw			
5.	503721003	Handle-Assist	28.	503200735	Screw			
6.	503210745	Bolt	29.	537160301	Housing-Throttle - RH			
7.	545056601	Clamp-Harness (lower)	30.	545007507	Flexshaft			
8.	530015940	Screw	31.	537216202	Harness w/warning			
9.	545067101	Assy-Throttle Housing (Incl. 18,19,20,21,22,23, 24,25,26,27,28,29)	32.	545030901	Kit-Shield (Incl. 33,34)			
10.	502199503	Handlebar	33.	530052286	Limiter - Line			
11.	503804501	Cover-Assist Handle	34.	530015814	Screw			
12.	502211201	Clip-Handlebar	36.	503890101	Cup-Support			
13.	530057986	Clamp-Harness (upper)	37.	537285601	Support - Flange			
14.	545030701	Kit-Driveshaft	38.	503856301	Locknut - Blade			
15.	530015814	Screw	39.	530016014	Screw			
16.	530058563	Clamp - Bracket	40.	530016301	Screw			
17.	545058501	Clamp 1" Handlebar	41.	530150294	Assy - Dustcup			
18.	545030601	Kit-Switch	42.	530015771	Screw			
19.	537160701	Lockout-Starter Throttle	43.	530057554	Bracket - Shield			
20.	537174301	Spring - Lockout						
21.	503221013	Nut						
22.	537160601	Lockout - Throttle						
23.	537160203	Housing - Throttle - LH						
						545047543	Manual	
						545056101	Decal-Warning	
						537312901	Guard - Transport	
						530031159	Wrench-Hex	
						502114602	Wrench-Spark Plug	

B



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530150253	Filter	25.	530016426	Screw	48.	530403094	Nut
2.	530016101	Nut-Carb. Screw	26.	545029602	Starter Hsg. w/eyelet	49.	530016456	Screw
3.	530057845	Air Box	27.	545029801	Kit-Starter Spring	50.	545017501	Assy-Fan Housing
4.	530057844	Lever - Choke	28.	545029701	Kit-Starter Pulley	51.	530150039	Assy-Clutch Drum
5.	545050402	Kit-Carb. Gasket (Incl 7,61)	29.	530016468	Screw	52.	545050405	Kit-Clutch Assy.
6.	530035596	Adaptor-Carb.	30.	545073802	Assy-Starter Hsg.(Incl. 23,24,26,27,28,29)	53.	530057852	Spacer
7.	545030101	Kit-Gasket (foam)	31.	530059780	Isolator-Tank	54.	530039242	Flywheel
8.	530016400	Bolt	32.	530058982	Bolt-Muffler	55.	545054601	Crankcase
9.	545001001	Cylinder	33.	530015496	Screw	56.	545013401	Bearing
10.	952030201	Plug-Spark (RCJ-8Y)	34.	530150440	Shield-Heat	57.	545030001	Kit-Crankshaft
11.	545050403	Kit-Crankshaft seal	35.	530016449	Screw	58.	530015162	Retainer-Piston Pin
12.	530016475	Washer-Starter	36.	530059784	Guard-Muffler	59.	530019283	Ring-Piston
13.	530016450	Spring-Starter Cup	37.	545030501	Kit-Spark Arrestor (Incl. 33)	60.	545030301	Kit-Piston (Incl. 58,59)
14.	530150568	Assy-Starter Cup	38.	530057847	Assy-Muffler	61.	545030101	Kit-Gasket (adaptor seal)
15.	530059800	Coupling-Starter	39.	530057848	Gasket-Paper Metal	62.	530015897	Screw
16.	530095646	Assy-Fuel Filter	40.	530015897	Screw	63.	545006033	Kit-Carb. (Incl. 4,5,64)
17.	545030201	Kit-Fuel Line	41.	545046701	Module	64.	545030101	Kit-Gasket (air box)
18.	530150350	Assy-Cap w/ret.(Incl. 19)	42.	530039227	Assy-Leadwire	65.	530057846	Cover-Air Box
19.	530019293	O-ring - Fuel Cap	43.	530016456	Screw	66.	530059796	Assy-Knob
20.	530057853	Assy-Fuel Tank (Incl. 16,17,18,19)	44.	530016030	Washer	67.	545030101	Kit-Gasket (Incl. 5,7,11,19,39,61,64)
21.	530057851	Shroud-Rear	45.	530094189	Washer-Clutch	Not Shown		
22.	530016448	Screw	46.	530016469	Screw	530058709	Bulb-Purge	
23.	545029901	Kit-Rope	47.	530016470	Screw			
24.	530150318	Handle-Starter						