



Walk Mower

# 917.375820

.



# HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 917.375820



REPAIR PARTS


## HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 917.375820

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	196403	Upper Handle Assembly (Includes Foam Grip)	30	180413X004	Axle Arm Assembly	56	88652	Screw, Hinge 1/4-20 x 1-1/4
2	183567	Engine Zone Control Cable	31	189808X418	Selector Knob	57	51793	Hairpin Cotter
3	850733X004	Bracket, Upstop	32	198169X004	Selector Spring	58	151590X498	Lower Handle
4	166649	Mulcher Plug	33	189917X418	Mulcher Door	59	191574	Handle Bolt
5	66426	Wire Tie	34	146630	Spacer	60	74760612	Bolt, Hex Head 3/8-16 x 3/4
6	189713X418	Handle Knob	35	700325X007	Wheel Adjusting Bracket	62	199314	Debris Shield
7	750634	Screw	36	175735	Hinge Bracket Assembly	63	192325	Screw, Debris Shield
8	194580X422	Control Bar	37	150078	Screw, Sems, Thread Cutting 5/16-18 x 3/4	64	- - -	Engine, Briggs & Stratton, Model No. 125K02-0654-E1 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
9	193679	Rear Door Assembly (Includes Springs)	38	402574X418	Discharge Deflector	65	197480	O-Ring
10	128415	Pop Rivet	39	195915X479	Handle Bracket Assembly, LH	69	197991	Clip, Cable
11	150050	Screw, Self-Tapping #10-24 x 5/8	40	195914X479	Handle Bracket Assembly, RH	70	182748	Foam Grip
37	12	54583	12	54583	Screw, Hex Head, Sems 1/4-20 x 1/2	71	188839X004	Mounting Bracket, DebrisShield
14	195622X479	Back Plate	41	150406	Bolt, Hex Head, Engine 3/8-16	72	182227	Screw #8
15	700365X479	Side Baffle	42	193000	Spring, Torsion	73	197162	Belt Keeper
16	176655X479	Discharge Baffle	43	73800400	Nut, Hex, Nylock	74	182228	Nut, Hex
17	140661X479	Rear Baffle	44	197556	Kit, Lawn Mower Housing (Includes Key #14, 15 and 51)	- -	161058	Warning Decal (not shown)
18	132004	Keps Locknut 1/4-20	45	175650	Rod, Hinge	- -	402735	Owner's Manual
19	194788	Rope Guide	46	194037	Blade Adapter / Pulley	Available accessories not included with mower:		
20	189008	Rear Skirt	47	141114	Blade, 22"	- -	71 33623	Gas Can (2.5 Gallon Container)
21	170938	Spring, Rear Door, LH	48	851074	Washer, Hardened	- -	71 33500	Fuel Stabilizer
24	170939	Spring, Rear Door, RH	49	850263	Washer, Helical	- -	71 33000	SAE 30W Oil (20 Ounce Bottle)
25	145212	Nut, Hex, Flanged	50	851084	Screw, Machine, Hex Head 3/8-24 x 1-3/8 Grade 8			
26	184193	Bolt, Rear Door	51	170031	Front Baffle			
27	193906X460	Wheel & Tire Assembly, Rear	52	85463	Danger Decal			
28	142748	Bolt, Shoulder 3/8-16 x 1	53	17600406	Screw			
29	61651	Washer, Belleville	54	88348	Washer, Flat			
			55	751592	Locknut, Hex 3/8-16			

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

# HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 917.375820




## HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 917.375820


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	404142	Drive Control Assembly (Includes Cable)	36	191636	Gearcase Assembly, Complete
2	195745	Cover, Drive Control, Top	38	73800400	Locknut, Hex 1/4-20
3	187353	Pulley	40	192849	Spring
4	190039	Lever, Drive Control	41	195107	Kit, Wheel Adjuster, RH (Includes Knob and Bearing)
5	195744	Cover, Drive Control, Bottom			
6	186198	Screw, Torx Head #8 x 5/8	54	401189	Grassbag Assembly
7	400235X479	Mounting Bracket, Drive Control	55	86012	Driveshaft Cover
8	197195	Cable, Drive Control	57	189680	Frame, Grassbag
9	184987	Cap, Drive Control, Bottom	61	196886	Case, Upper
10	189074	Decal, Drive Control	62	197057	Shaft, Output
11	193912X460	Wheel & Tire Assembly	63	183508	Seal, Output Shaft
12	12000058	E-Ring	64	183511	Bushing
13	750003	Gear, Pinion	65	183509	Washer
14	189403	Dust Cover	66	183514	Seal, Worm Shaft
15	191017	Pawl, Drive	67	183506	Bearing, Ball
16	67725	Washer, Flat 3/8	68	183499	Gear, 27 Teeth
17	191039	Bearing, Wheel Adjuster	69	196884	Fixed Dog Clutch
18	196401	Selector Knob	70	183505	Wireform
23	88652	Screw 1/4-20 x 1-1/4	71	196883	Movable Dog Clutch
24	191730	Nut, Hex	72	196882	Fork
25	197163X479	Belt Guide Bracket	73	183513	Screw, Case
26	192325	Screw	74	196881	Case, Lower
27	175262	Pan Head Tapping Screw #10-24 x 2-3/4	75	196880	Seal, Lever
28	194407X418	Drive Cover	76	196879	Lever
29	83923	Locknut, Hex	77	196878	Screw, Lever
32	194018	Drive Pulley	78	196877	Spring
33	196857	V-Belt	79	183502	Shaft, Worm
35	195110	Kit, Wheel Adjuster, LH (Includes Knob and Bearing)			


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.









1058 OWNER'S MANUAL

1330 REPAIR MANUAL

1329 REPLACEMENT ENGINE

1036 EMISSIONS LABEL

KEY PART NO.	NO.	DESCRIPTION
1	697322	Cylinder Assembly
2	399269	Kit-Bushing/Seal
3	299819s	• Seal-Oil (Magneto Side)
4	493279	Sump-Engine
5	691160	Head-Cylinder
7	692249	• Gasket-Cylinder Head
8	695250	Breather Assembly
9	699472	Gasket-Breather
10	691125	Screw (Breather Assembly)
11	691781	Tube-Breather
12	692232	• Gasket-Crankcase
13	690912	Screw (Cylinder Head)
15	691680	Plug-Oil Drain
16	691450	Crankshaft
20	399781s	• Seal-Oil (PTO Side)
22	691092	Screw (Engine Sump)
23	691987	Flywheel
24	222698s	Key-Flywheel
25	790359	Piston Assembly (Std.)
	791326	Piston Assembly (.020" Oversize)
26	790360	Ring Set (Standard)
	791324	Ring Set (.020" Oversize)

KEY PART NO.	NO.	DESCRIPTION
27	691866	Lock-Piston Pin
28	499423	Pin-Piston
29	499424	Rod-Connecting
32	691664	Screw (Connecting Rod)
32A	695759	Screw (Connecting Rod)
33	262651s	Valve-Exhaust
34	262652s	Valve-Intake
35	691270	Spring-Valve (Intake)
36	691270	Spring-Valve (Exhaust)
37	694086	Guard-Flywheel
40	692194	Retainer-Valve
43	691997	Slinger-Governor/Oil
45	690548	Tappet-Valve
46	691449	Camshaft
48	498829	Short Block
50	497465	Manifold-Intake
51	272199s	• Gasket-Intake
54	691650	Screw (Intake Manifold)
55	691421	Housing-Rewind Starter
58	697316	Rope-Starter (Cut to Fit)
60	281434s	Grip-Starter Rope
65	690837	Screw (Rewind Starter)
78	691108	Screw (Flywheel Guard)



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
81	691740	Lock-Muffler Screw	592	690800	Nut (Rewind Starter)
95	691636	Screw (Throttle Valve)	597	691696	Screw (Pawl Friction Plate)
97	696565	Shaft-Throttle	601	791850	Clamp-Hose
104	691242	Ø Pin-Float Hinge	604	698588	Cover-Control
117	498978	Jet-Main (Standard)	608	497680	Starter-Rewind
118	494870	Jet-Main (High Altitude)	613	691340	Screw (Muffler)
121	498260	Kit-Carburetor Overhaul	615	690340	Retainer-Governor Shaft
125	498170	Carburetor	616	698801	Crank-Governor
127	694468	Ø Plug-Welch	617	270344s	•Ø‡ Seal (Intake Manifold)
130	696564	Valve-Throttle	621	692310	Switch-Stop
133	398187	Float-Carburetor	633	691321	Ø‡ Seal-Throttle Shaft
134	398188	Ø Valve-Needle/Seat	635	66538	Boot-Spark Plug
137	693981	Ø‡ Gasket-Float Bowl	668	493823	• Spacer (Includes 2)
163	272653s	•Ø‡ Gasket-Air Cleaner	670	692294	Spacer-Fuel Tank
187	791766	Line-Fuel (Cut to Fit)	684	690345	Screw (Breather Cover)
188	693399	Screw (Control Bracket)	689	691855	Spring-Friction
190	690940	Screw (Fuel Tank)	718	690959	Pin-Locating
202	691829	Link-Mechanical Governor	741	691830	Gear-Timing
209	699056	Spring-Governor	745	691648	Screw (Brake)
222	791128	Bracket-Control	842	691031	• Seal (Dipstick Tube)
227	690783	Control Lever-Governor	847	692047	Assembly-Dipstick/Tube
276	271716	Ø Sealing Washer	851	493880s	Terminal-Spark Plug
287	690940	Screw (Dipstick Tube)	868	697338	Seal-Valve
300	692038	Muffler	869	691155	Seat-Valve (Intake)
304	695892	Housing-Blower	870	690380	Seat-Valve (Exhaust)
305	691108	Screw (Blower Housing)	871	262001	Bushing-Guide (Exhaust)
306	690450	Shield-Cylinder		63709	Bushing-Guide (Intake)
307	690345	Screw (Cylinder Shield)	921	697343	Cover-Blower Housing
332	690662	Nut (Flywheel)	922	692135	Spring-Brake
333	802574	Armature-Magneto	923	695891	Brake
334	691061	Screw (Armature Magneto)	957	699985	Cap-Fuel Tank
337	802592s	Spark Plug	966	792040	Base-Air Cleaner Primer
356	692390	Wire-Stop	968	692298	Cover-Air Cleaner
358	497316	Engine Gasket Set	969	690700	Screw (Blower Cover)
363	19069	Flywheel Puller	972	699374	Tank-Fuel
365	692524	Screw (Carburetor)	975	493640	Bowl-Float
383	89838	Wrench-Spark Plug	976	496115	Primer-Carburetor
404	690272	Washer (Governor Crank)	977	498261	Set-Carburetor Gasket
425	690670	Screw (Air Cleaner Cover)	1036	792156	Label-Emission
443	692523	Screw (Air Cleaner Base)	1058	276171	Owner's Manual
445	491588s	Filter-Air Cleaner Cartridge	1059	692311	Kit-Screw/Washer
455	791960	Cup-Flywheel	1210	498144	Pulley/Spring (Pulley)
456	692299	Plate-Pawl Friction	1211	498144	Pulley/Spring (Spring)
459	281505s	Pawl-Ratchet	1329	125K02-0025	Replacement Engine
505	691251	Nut (Gov. Control Lever)	1330	272147	Repair Manual
523	499621	Dipstick	- -	398067	Spark Arrester
524	692296	• Seal-Dipstick Tube			(available accessory)
525	495265	Tube-Dipstick			
529	691923	Grommet			• Included in Engine Gasket Set, Key No. 358
562	691119	Bolt (Gov. Control Lever)			Ø Included in Carb. Overhaul Kit, Key No. 121
564	698589	Screw (Control Cover)			‡ Included in Carb. Gasket Set, Key No. 977
584	697734	Cover-Breather Passage			
585	691879	• Gasket-Breather Passage			

**NOTE:** All component dimensions given in U.S.