

Grass Catcher Grass Collector CET342

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

CET342 (96071001200)



KEY NO.	PART NO.	DESCRIPTION
1	532 40 10-47	Adapter
2	532 06 91-80	Nut, Crownlock #10-24
3	532 19 27-09	Screen, Cover
4	532 19 53-73	Cover Assembly (Includes Key No. 34, 37)
5	532 12 68-40	Chute, Upper
6	818 02 10-08	Screw, Special #10-14x1/2
7	532 13 09-33	Full bag Indicator
8	532 08 71-75	Screw, #10-24 x 1-1/8
9	819 06 12-16	Washer 3/16x3/4x16 Ga.
10	532 00 72-06	Spacer, Split
11	532 06 08-67	Nut, Acorn #10-24
12	810 07 10-00	Washer, lock
13	532 10 98-08	Latch, Chute
14	532 12 50-04	Nut, Weld
15	532 13 07-60	Latch, Hook

KEY NO.	PART NO.	DESCRIPTION
16	532 13 07-59	Rubber, Latch
18	532 16 28-03	Chute, Lower
20	871 16 10-10	Screw #10-24 x 5/8
26	532 12 46-70	Spring, Retainer
28	532 19 83-64	Support Assembly
29	532 17 69-97	Shoulder Bolt, Tapping
30	532 16 58-98	Spring, Retainer
31	532 17 40-83	Plug, Tubing End
32	532 17 69-90	Bagger, Frame
33	532 19 27-86	Pin, Hinge
34	532 19 25-50	Gasket, Cover
35	532 18 32-86	Container, Top
36	532 12 95-86	Container, Bottom
37	532 19 26-03	Ring, Cover Gasket
38	532 13 08-95	Latch Handle, Cover
--	532 41 19-53	Owner's Manual