


Grass Catcher Grass Collector H346HG

Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar

H346HG (96071001300)



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
2	532 06 91-80	Nut, Crownlock #10-24	16	532 13 07-59	Rubber, Latch
3	532 19 27-09	Screen, Cover	18	532 40 54-55	Chute, Lower
4	532 19 53-73	Cover Assembly (Includes Key No. 34, 37)	20	871 16 10-10	Screw #10-24 x 5/8
5	532 41 13-97	Chute, Upper	26	532 12 46-70	Spring, Retainer
6	818 02 10-08	Screw, Special #10-14x1/2	27	532 19 81-28	Support Assembly
7	532 13 09-33	Full bag Indicator	28	532 16 58-98	Spring, Retainer
8	532 08 71-75	Screw, #10-24 x 1-1/8	31	532 17 40-83	Plug, Tubing End
9	819 06 12-16	Washer 3/16x3/4x16 Ga.	32	532 17 69-90	Bagger, Frame
10	532 00 72-06	Spacer, Split	33	532 19 27-86	Pin, Hinge
11	532 06 08-67	Nut, Acorn #10-24	34	532 19 25-50	Gasket, Cover
12	810 07 10-00	Washer, lock	35	532 18 32-86	Container, Top
13	532 10 98-08	Latch, Chute	36	532 12 95-86	Container, Bottom
14	532 12 50-04	Nut, Weld	37	532 19 26-03	Ring, Cover Gasket
15	532 13 07-60	Latch, Hook	38	532 13 08-95	Latch Handle, Cover
			--	532 41 19-58	Owner's Manual