

# LT151

**Spare parts**

**Ersatzteile**

**Pièces détachées**


**Reserve onderdelen**

**Repuestos**

**Reservdelar**


# ILLUSTRATED PARTS LIST

**MODEL NO. 96041001707**  
**CUSTOMER CATALOG NO. LT151**  
**PRODUCT NO. 960 41 00-17**



413001


**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17**  
**DECALS 27**



| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 1       | 532 40 03-89 | Decal, Operators            |
| 2       | 532 42 20-12 | Decal, Hood/Fender          |
| 3       | 532 19 68-41 | Decal, Warning Eng. Symbols |
| 4       | 532 40 85-96 | Decal, Hood Panel           |
| 5       | 532 15 97-36 | Decal, Chassis Hot Muffler  |
| 6       | 532 18 04-32 | Decal, Fender 100 DB/CE     |
| 7       | 532 18 21-66 | Decal, Cutfinger CE         |
| 8       | 532 40 87-71 | Decal, Rpl.                 |
| 9       | 532 14 50-05 | Decal, Battery Dan./Poi.    |
| 10      | 532 14 08-37 | Decal, Saddle Brake Parking |

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 11      | 532 19 63-57 | Decal, Warning                |
| 12      | 532 19 43-02 | Decal, Mower V-Belt Schematic |
| 13      | 532 15 97-37 | Decal, Brake/Clutch Symbol    |
| --      | 532 41 08-05 | Pad, Footrest, LH             |
| --      | 532 41 10-56 | Pad, Footrest, RH             |
| --      | 532 16 25-98 | Decal, Drawbar Load Limit     |
| --      | 532 40 78-08 | Manual Oper. Euro             |
| --      | 532 40 78-09 | Manual Oper. Scand            |
| --      | 532 40 78-10 | Manual Oper. E-Bloc           |
| --      | 532 40 78-11 | Manual Oper. Baltic           |

**WHEELS AND TIRES**




| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                    |
| 2       | 532 06 51-39 | Stem Valve                        |
| 3       | 532 13 83-36 | Rim Asm. 6" Front                 |
| 4       | 532 05 99-04 | Tube Front (Service Item Only)    |
| 5       | 532 10 62-22 | Tire F T 15 x 6 0 - 6             |
| 6       | 532 12 49-57 | Fitting Grease (Front Wheel Only) |
| 7       | 532 12 49-59 | Bearing Flange (Front Wheel Only) |
| 8       | 532 17 50-39 | Cap Axle Blk. 1 50 x 1 00         |
| 9       | 532 42 05-31 | Tire R 18 x 9.5-8 Turf Saver LT   |
| 10      | 532 12 49-26 | Tube Rear (Service Item Only)     |
| 11      | 532 13 83-37 | Rim Asm. 8" Rear                  |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. Tube)       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm




TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17  
SCHEMATIC 38

SCH10



**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17**  
**ELECTRICAL 32**

T02S




**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17  
ELECTRICAL 32**

| <b>KEY<br/>NO.</b> | <b>PART<br/>NO.</b> | <b>DESCRIPTION</b>               |
|--------------------|---------------------|----------------------------------|
| 1                  | 532 16 34-65        | Battery                          |
| 2                  | 874 76 04-12        | Bolt Hex Head 1/4-20 x 3/4       |
| 8                  | 532 19 32-28        | Box Battery                      |
| 16                 | 532 17 61-38        | Switch Interlock Push-In         |
| 21                 | 532 40 02-52        | Harness Socket Light w/4152J     |
| 22                 | 532 00 41-52        | Bulb Light                       |
| 25                 | 532 41 28-94        | Cable Starter                    |
| 26                 | 532 17 51-58        | Fuse                             |
| 27                 | 873 51 04-00        | Nut Keps Hex 1/4-20 unc          |
| 28                 | 532 19 88-85        | Cable, Ground                    |
| 29                 | 532 40 15-45        | Switch, Seat                     |
| 30                 | 532 19 33-50        | Switch, Ign.                     |
| 33                 | 532 41 19-35        | Key/Chain                        |
| 34                 | 532 11 07-12        | Switch Light/Reset               |
| 40                 | 532 40 10-98        | Harness Ign. Dash                |
| 41                 | 817 72 04-08        | Screw Thd. Cut 1/4-20 x 1/2      |
| 42                 | 532 13 15-63        | Cover, Terminal                  |
| 43                 | 532 19 25-07        | Solenoid                         |
| 55                 | 817 06 05-12        | Screw Thdrol. 5/16-18 x 3/4 TYTT |
| 71                 | 532 40 04-49        | Harness Chassis                  |
| 79                 | 532 17 52-42        | Socket Asm. Bulb Twistlock       |
| 87                 | 532 19 78-02        | Switch Interlock Clutch Cable    |
| 90                 | 532 40 07-25        | Cover Terminal                   |
| 92                 | 532 19 66-15        | Harness Pigtail Reverse Switch   |
| 93                 | 532 19 25-40        | Screw Plastite 10-14 x 2.0       |
| 94                 | 532 19 18-34        | Module Reverse ROS               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17**  
**CHASSIS AND ENCLOSURES 39**



chassis-tex\_TEX LT HUSQ\_11\_r1


**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17**  
**CHASSIS AND ENCLOSURES 39**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                        |
|------------|--------------|------------------------------------|
| 2          | 532 41 22-82 | Drawbar                            |
| 3          | 532 40 50-12 | Logo                               |
| 5          | 532 40 75-92 | Dash                               |
| 6          | 532 40 48-83 | Clip Tinnerman                     |
| 14         | 532 41 10-73 | Hood                               |
| 15         | 532 41 10-79 | Lens LH                            |
| 18         | 532 40 66-67 | Grille                             |
| 25         | 532 41 10-78 | Lens RH                            |
| 36         | 817 06 05-12 | Screw 5/16-18 x 3/4                |
| 37         | 532 41 63-07 | Fender                             |
| 58         | 532 41 22-80 | Drawbar Upper                      |
| 68         | 817 49 05-08 | Screw Thdrol. 5/16-18 x 1/2        |
| 130        | 532 41 63-58 | Screw #10 x .750 BOS Thread        |
| 137        | 532 40 75-90 | Bumper Dash                        |
| 150        | 532 40 75-37 | Air Duct                           |
| 151        | 532 40 78-07 | Bracket Pivot                      |
| 152        | 532 19 43-29 | Shield Browning                    |
| 159        | 817 00 06-12 | Screw 3/8-16 x 3/4                 |
| 162        | 532 14 24-32 | Screw Hex Wsh. Hi-Lo 1/4 x 1/2 unc |
| 175        | 532 19 94-72 | Crossmember                        |
| 176        | 532 40 07-76 | Screw 10-24 x 5/8                  |
| 177        | 532 19 52-28 | Bushing Steering                   |
| 180        | 532 19 42-60 | Chassis                            |
| 182        | 532 40 71-76 | Dash Lower                         |
| 183        | 874 78 05-20 | Bolt 5/16-18 unc x 1-1/4           |
| 189        | 817 00 05-12 | Screw 5/16-18 x 3/4                |
| 191        | 532 41 65-00 | Insert Reflective LH               |
| 194        | 873 90 05-00 | Nut Lock Hex Flange 5/16-18        |
| 195        | 532 41 11-15 | Plug Dash                          |
| 199        | 532 41 34-85 | Plate Deck Lift                    |
| 202        | 532 41 10-74 | Vent Side Hood RH                  |
| 203        | 532 41 10-75 | Vent Side Hood LH                  |
| 204        | 532 41 11-16 | Vent Top Hood                      |
| 205        | 532 41 10-76 | Skirt Side RH                      |
| 206        | 532 41 10-77 | Skirt Side LH                      |
| 214        | 532 19 91-45 | Clip Retainer                      |
| 217        | 532 40 91-67 | Rod Pivot Hood                     |
| 228        | 532 19 51-61 | Stud Fastener                      |
| 234        | 532 40 47-42 | Bumper Hood                        |
| 235        | 532 40 61-29 | Spacer Fender                      |
| 236        | 873 93 05 00 | Nut Center Lock 5/16-18 unc        |
| 238        | 532 41 11-19 | Trim                               |
| 282        | 532 41 41-10 | Clip Retainer                      |
| 283        | 532 41 63-16 | Console Deck Lift                  |
| 284        | 532 41 63-14 | Console Shift                      |
| 285        | 532 41 63-15 | Console Insrt. RH                  |
| 286        | 532 41 63-17 | Console Insrt. LH                  |
| 287        | 817 60 04-06 | Screw Hex Washead. 1/4-20 x 3/8    |
| 297        | 532 40 66-65 | Insert Reflective                  |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17  
 DRIVE **40**



drive-tex\_D6800\_Fender\_41\_r1

**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17  
DRIVE **40****

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | ---          | Transaxle, Dana D6800-1        |
| 2       | 532 12 35-83 | Key Square                     |
| 15      | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga.  |
| 17      | 532 19 72-97 | Spring, Brake                  |
| 22      | 532 19 76-60 | Rod Shift                      |
| 23      | 532 12 12-74 | Knob Duckhead 1/2-13           |
| 26      | 532 19 74-55 | Spring Brake Return            |
| 29      | 532 19 72-67 | Rod, Brake                     |
| 33      | 812 00 00-01 | Ring E                         |
| 35      | 532 40 10-31 | Rod, Brake, Park               |
| 37      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.  |
| 42      | 532 12 48-72 | Cover, Foot Pedal              |
| 49      | 872 11 06-14 | Bolt                           |
| 50      | 532 19 43-27 | Pulley Idler Flat              |
| 51      | 873 90 06-00 | Lock Nut 3/8-16                |
| 52      | 532 19 43-26 | Idler V-Groove 910" Offset     |
| 56      | 532 41 12-45 | V-Belt, Drive                  |
| 61      | 532 12 36-66 | Pulley Transaxle               |
| 64      | 532 19 62-00 | Shaft Asm. Pedal Brake Control |
| 73      | 874 49 05-44 | Bolt Hex Flghd. 5/16-18 Gr. 5  |
| 116     | 873 90 05-00 | Nut Lock Hex Flange 5/16-18    |
| 125     | 817 00 05-12 | Screw 5/16-18 x 3/4            |
| 134     | 532 40 24-30 | Asm. Shift                     |
| 139     | 874 55 04-12 | Bolt 1/4-28 unf Gr. 8 w/Patch  |
| 140     | 810 04 04-00 | Washer Lock Hvy. Helical 1/4   |
| 141     | 819 09 12-10 | Washer 9/32 x 3/4 x 10 Ga.     |
| 155     | 812 00 00-28 | Ring Retainer                  |
| 157     | 532 10 57-01 | Washer Plate Shift             |
| 158     | 532 19 43-52 | Belt Keeper                    |
| 159     | 876 02 04-12 | Pin Cotter 1/8 x 3/4           |
| 160     | 532 16 94-84 | Retainer Clip                  |

| KEY NO. | PART NO.     | DESCRIPTION                      |
|---------|--------------|----------------------------------|
| 161     | 532 10 57-09 | Spring, Return, Clutch           |
| 165     | 532 19 62-12 | Bushing Shaft Brake Hand Control |
| 166     | 532 19 72-90 | Nut Push .625                    |
| 167     | 532 40 52-57 | Latch Brake Parking              |
| 172     | 532 19 76-57 | Strap Torque LH                  |
| 174     | 532 19 72-89 | Nut Push                         |
| 175     | 532 19 89-81 | Shaft Asm. Shift                 |
| 176     | 532 19 62-14 | Arm Clevis Rod Shift             |
| 178     | 532 19 74-56 | Spring Shift                     |
| 184     | 532 40 97-47 | Knob                             |
| 185     | 872 11 06-20 | Bolt                             |
| 186     | 532 19 43-21 | Spacer Retainer                  |
| 187     | 819 13 32-10 | Washer                           |
| 188     | 532 19 43-23 | Link Clutch Ground Drive         |
| 189     | 532 19 43-17 | Bellcrank Ground Drive           |
| 190     | 532 19 43-18 | Keeper Bellcrank Ground Drive    |
| 192     | 532 15 03-60 | Nut Lock Center 1/4-28 Fnthd.    |
| 193     | 817 06 05-12 | Screw 5/16-18 x 3/4              |
| 195     | 532 19 73-32 | Bracket Brake Rod                |
| 202     | 532 19 95-89 | Link Transaxle                   |
| 203     | 819 11 11-16 | Washer 11/32 x 11/16 x 16 Ga.    |
| 205     | 532 12 17-48 | Washer 25/32 x 1-5/8 16 Ga.      |
| 221     | 532 40 31-87 | Retainer Spring Clip Handle      |
| 232     | 874 78 07-16 | Bolt Fin. Hex 7/16-14 x 1 Gr. 5  |
| 233     | 532 40 52-96 | Washer Serrated                  |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm




engine-tex\_34-kohl

**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17  
ENGINE 24**

| <b>KEY<br/>NO.</b> | <b>PART<br/>NO.</b> | <b>DESCRIPTION</b>             |
|--------------------|---------------------|--------------------------------|
| 1                  | -----               | Engine Kohler Model No. SV470  |
| 2                  | 532 18 86-55        | Muffler                        |
| 9                  | 532 19 43-19        | Keeper Belt Engine             |
| 12                 | 532 40 19-85        | Pulley Engine                  |
| 15                 | 532 40 75-45        | Tank Fuel 1.5                  |
| 18                 | 532 19 77-25        | Cap Asm.                       |
| 20                 | 532 18 38-97        | Control Throttle               |
| 21                 | 532 41 63-58        | Screw #10 x 0.750 BOS Thread   |
| 28                 | 532 13 70-40        | Fuel Line                      |
| 29                 | 532 13 71-80        | Spark Arrester Kit             |
| 37                 | 532 12 34-87        | Clamp Hose                     |
| 42                 | 810 04 07-00        | Bolt 5/16-18 unc x 3/4 w/Sems. |
| 43                 | 532 17 39-37        | Bolt Hex 7/16-20 x 4 Gr. 5     |
| 44                 | 817 67 04-12        | Screw 1/4-20 x 3/4             |
| 45                 | 873 51 04-00        | Nut Keps Hex 1/4-20 unc        |
| 46                 | 819 09 14-16        | Washer 9/32 x 7/8 x 16 Ga.     |
| 69                 | 532 18 59-09        | Gasket                         |
| 81                 | 532 14 84-56        | Tube Drain Oil Easy            |
| 82                 | 532 18 16-54        | Plug Drain Oil                 |
| 83                 | 532 17 18-77        | Bolt 5/16-18 unc x 3/4 w/Sems. |
| 90                 | 817 00 06-16        | Screw 3/8-16 x 1               |
| 92                 | 817 12 06-16        | Screw 3/8-16 x 1               |
| 94                 | 532 18 86-54        | Tube Exhaust                   |
| 95                 | 532 19 23-34        | Screw Socket HD 5/16-18 x .75  |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17  
STEERING ASSEMBLY **41**



**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17**  
**STEERING ASSEMBLY [41]**

| KEY NO. | PART NO.     | DESCRIPTION                         |
|---------|--------------|-------------------------------------|
| 1       | 532 41 64-80 | Wheel, Steering Husq SR             |
| --      | 532 19 36-51 | Wheel, Steering Prem 2              |
| 2       | 532 41 81-68 | Axle Asm., Front                    |
| 4       | 532 40 30-87 | Spindle Asm., LH                    |
| 5       | 532 40 30-88 | Spindle Asm., RH                    |
| 6       | 532 12 49-31 | Bearing, Race Thrust Hardened       |
| 7       | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.       |
| 8       | 812 00 00-29 | Ring, Clip #T5304-75                |
| 9       | 532 12 12-32 | Cap, Spindle                        |
| 13      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.       |
| 14      | 810 04 06-00 | Washer, Lock Hvy. Hlcl. Spr. 3/8    |
| 15      | 873 54 06-00 | Nut, Crown Lock 3/8-24 unf          |
| 16      | 532 19 60-74 | Shaft Steering                      |
| 19      | 532 19 47-29 | Plate Steering                      |
| 20      | 532 41 11-39 | Boot, Steering                      |
| 21      | 532 18 67-37 | Adapter, Wheel Steering             |
| 22      | 532 19 48-45 | Bushing, Strg. Blk.                 |
| 26      | 532 41 59-87 | Insert, Wheel Steering Husq SR      |
| --      | 532 19 36-52 | Insert, Wheel Steering Prem 2       |
| 28      | 817 00 06-12 | Screw 3/8-16 x 3/4                  |
| 33      | 810 04 05-00 | Washer Lock 5/16                    |
| 35      | 532 19 47-32 | Gear, Sector Plate                  |
| 45      | 819 11 38-12 | Washer 11/32 x 3/8 x 12 Ga.         |
| 50      | 873 90 06-00 | Nut Lock 3/8-16 unc                 |
| 53      | 532 18 89-67 | Washer Hardened .793 x 1.637 x .060 |
| 54      | 874 76 06-36 | Bolt Hex 3/8-16 unc x 2-1/4         |
| 55      | 532 41 47-36 | Spacer Brace Axle                   |
| 57      | 532 40 74-65 | Bracket Upstop                      |
| 58      | 532 19 47-47 | Bolt Shoulder Sector Pivot CFM      |
| 59      | 532 19 47-48 | Washer Thrust Sector Steering       |
| 60      | 873 97 10-00 | Nut Flange Lock 5/8-11              |
| 61      | 532 19 47-40 | Draglink, LH                        |
| 62      | 532 19 47-41 | Draglink, RH                        |
| 63      | 817 00 05-12 | Screw 5/16-18 x 3/4                 |
| 64      | 532 19 98-49 | Retainer Clip Spring Steering       |
| 65      | 532 19 47-34 | Brace Axle Front                    |
| 66      | 871 02 07-48 | Bolt Hex Fghd. 7/16-14 x 3 Serr.    |
| 67      | 532 19 47-37 | Bushing PM Front Axle               |
| 68      | 873 90 07-00 | Nut Lock Flange 7/16-14 Gr. 5       |
| 69      | 532 19 91-62 | Washer 1.5 x .505 x .118            |
| 70      | 532 19 61-97 | Bracket Deck Susp. Front            |
| 71      | 532 19 60-75 | Shaft Extension Steering            |
| 72      | 874 78 05-72 | Bolt 5/16-18 unc x 4.5. Gr. 5       |
| 74      | 532 12 49-37 | Bearing Col. STRG                   |
| 78      | 532 05 70-79 | Washer Thrust 515.750 x .033        |
| 228     | 532 40 44-84 | Decal Wheel Steering                |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

## 44



44



**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17  
MOWER DECK 44**


| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                         |
|------------|--------------|-------------------------------------|
| 1          | 532 19 42-51 | Mower Housing                       |
| 6          | 532 19 51-86 | Arm Suspension                      |
| 7          | 532 41 63-58 | Screw #10 x BOS Thread              |
| 8          | 532 19 30-03 | Bolt/Washer Asm. 7/16-20 unf        |
| 11         | 532 19 39-57 | Blade 38" 3NI Premium               |
| 13         | 532 19 28-72 | Shaft Assembly, Mandrel             |
| 14         | 532 18 72-81 | Housing, Mandrel                    |
| 15         | 532 11 04-85 | Bearing, Ball, Mandrel              |
| 19         | 532 19 65-39 | Bolt, Shoulder                      |
| 21         | 873 68 05-00 | Nut, Crownlock 5/16-18 unc          |
| 23         | 532 19 25-57 | Bracket, Deflector                  |
| 24         | 532 10 53-04 | Cap, Sleeve                         |
| 25         | 532 19 70-26 | Spring, Torsion, Deflector          |
| 26         | 532 11 04-52 | Nut, Push                           |
| 27         | 532 40 14-72 | Shield, Deflector                   |
| 29         | 532 13 14-91 | Rod, Hinge                          |
| 30         | 532 17 39-84 | Screw Thdrol. Rolling Wsh. Hd.      |
| 31         | 532 18 76-90 | Washer, Spacer                      |
| 32         | 532 19 97-89 | Pulley, Mandrel                     |
| 33         | 532 40 02-34 | Nut, Toplock, Flanged               |
| 34         | 872 11 06-12 | Bolt Carr. Sh. 3/8-16 x 1-1/2 Gr. 5 |
| 37         | 819 13 13-16 | Washer                              |
| 38         | 532 19 95-41 | Keeper Belt LH Mandrel              |
| 40         | 873 90 06-00 | Nut, Lock Flg. 3/8-16 unc           |
| 42         | 532 19 84-10 | Spring Torsion Brake                |
| 43         | 532 19 72-56 | Spring Torsion Retainer             |
| 46         | 532 13 77-29 | Screw 1/4-20 x 5/8                  |
| 55         | 532 19 72-49 | Arm, Idler                          |

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                                                                                     |
|------------|--------------|-------------------------------------------------------------------------------------------------|
| 56         | 532 19 90-92 | Spacer, Retainer                                                                                |
| 57         | 817 00 06-16 | Screw 3/8-16 x 1                                                                                |
| 59         | 532 14 10-43 | Guard, Tuv. Idler                                                                               |
| 60         | 532 19 94-71 | Arm Brake Mower                                                                                 |
| 63         | 532 19 94-70 | Arm Brake Mower                                                                                 |
| 64         | 532 19 97-90 | Link Brake                                                                                      |
| 67         | 532 40 30-12 | Handle Clutch Cable                                                                             |
| 68         | 532 40 83-81 | V-Belt                                                                                          |
| 69         | 872 14 05-05 | Bolt                                                                                            |
| 70         | 532 40 12-46 | Clutch Asm. Manual                                                                              |
| 122        | 532 19 72-58 | Keeper Belt Engine LH                                                                           |
| 123        | 532 19 72-59 | Keeper Belt Engine RH                                                                           |
| 144        | 532 19 34-14 | Keeper Belt                                                                                     |
| 145        | 532 19 31-97 | Pulley, Idler, Flat                                                                             |
| 147        | 532 40 18-72 | Spring Return                                                                                   |
| 152        | 532 40 87-14 | Manual Clutch Cable                                                                             |
| 188        | 532 19 51-61 | Stud Fastener                                                                                   |
| 189        | 873 90 05-00 | Nut Lock Hex Flange                                                                             |
| 195        | 817 00 06-12 | Screw 3/8-16 x 3/4                                                                              |
| 199        | 532 40 00-95 | Baffle Vortex                                                                                   |
| 209        | 819 13 32-10 | Washer 13/32 x 2 x 10                                                                           |
| - -        | 532 19 28-70 | Mandrel Assembly (Includes hous-<br>ing, shaft and shaft hardware only-<br>pulley not included) |
| - -        | 532 40 04-22 | Replacement Mower, Complete                                                                     |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17**  
**SEAT ASSEMBLY 42**




seat-tex\_6.5SL\_2

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 19 75-18 | Seat                           |
| 2       | 532 18 01-66 | Bracket Pivot Fender           |
| 3       | 532 14 06-75 | Strap, Asm. Fender             |
| 6       | 873 80 06-00 | Nut, Lock w/Ins. 3/8-16 unc    |
| 7       | 532 12 41-81 | Spring, Seat Cprsn.            |
| 8       | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems. |
| 10      | 532 19 69-77 | Pan, Seat                      |
| 21      | 532 17 18-52 | Bolt, Shoulder 5/16-18         |

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 37      | 873 80 05-00 | Nut, Lock 5/16-18 unc         |
| 40      | 532 19 76-61 | Handle                        |
| 41      | 532 19 82-00 | Spring                        |
| 43      | 874 76 06-12 | Bolt 3/8-16 unc x 3/4         |
| 44      | 819 13 38-12 | Washer 13/32 x 2-3/8 x 12 Ga. |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LT151 (96041001707), PRODUCT NO. 960 41 00-17**  
**MOWER LIFT 45**



| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 2       | 532 19 52-23 | Shaft Asm., Lift             |
| 3       | 532 19 52-31 | Lever Asm., Lift RH          |
| 7       | 532 41 15-55 | Grip, Lever                  |
| 10      | 532 19 63-14 | Spring Torsion               |
| 87      | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock |
| 88      | 532 41-07-10 | Spring Lift Assist           |
| 89      | 819 19 19-12 | Washer Clear Zinc            |
| 90      | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock |

| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 91      | 532 19 51-81 | Link Lift Susp. Mower Rear        |
| 97      | 817 00 06-12 | Screw 3/8-16 x .75 Smgml. Tap/R.Z |
| 98      | 532 19 52-70 | Link Lift Susp. Front Mower       |
| 100     | 873 93 06-00 | Nut Centerlock 3/8-16             |
| 101     | 532 40-70-03 | Link Asm. Lift FXD                |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm