





65022ES

Illustrated Parts List / 96143002302

ROTARY LAWN MOWER - - MODEL NUMBER 65022ES (96143002302) - PRODUCT NUMBER 961 43 00-23



ROTARY LAWN MOWER - - MODEL NUMBER 65022ES (96143002302) - PRODUCT NUMBER 961 43 00-23

17


KEY NO.	PART NO.	DESCRIPTION
1	532 19 99-83	Upper Handle (Includes Foam Grip)
2	532 18 96-86	Key Start Switch (Includes Key)
3	532 12 51-62	Bracket, Upstop
4	532 16 66-49	Mulcher Plug
5	532 06 64-26	Wire Tie
6	532 19 18-56	Handle Knob
7	532 75 06-34	Screw
8	532 41 31-85	Control Bar
9	532 40 84-92	Rear Door Assembly
10	532 12 84-15	Pop Rivet
11	532 15 00-50	Screw, Self-Tapping #10-24 x 5/8
12	532 05 45-83	Screw, Hex Hex Head, Sems 1/4-20 x 1/2
14	532 19 70-76	Back Plate
15	532 41 13-34	Side Baffle
16	532 17 71-33	Discharge Baffle
17	532 14 89-41	Rear Baffle
18	532 13 20-04	Keps Locknut 1/4-20
19	532 19 47-88	Rope Guide
20	532 41 31-60	Rear Skirt
21	532 40 54-21	Spring, Rear Door, LH
24	532 40 54-23	Spring, Rear Door, RH
25	532 40 91-48	Nut, Hex, Flanged
26	532 18 41-93	Bolt, Rear Door
27	532 41 31-83	Wheel & Tire Assembly, Rear
28	532 14 27-48	Bolt, Shoulder 3/8-16 x 1
29	532 40 16-30	Washer, Belleville
30	532 40 78-71	Axle Arm Assembly
31	532 19 64-01	Selector Knob
32	532 40 64-28	Selector Spring
33	532 19 70-29	Mulcher Door
34	532 40 16-29	Spacer
35	532 41 06-24	Wheel Adjusting Bracket, RH
36	532 17 57-35	Hinge Bracket Assembly
37	532 15 00-78	Screw, Sems, Thread Cutting 5/16-18 x 3/4

KEY NO.	PART NO.	DESCRIPTION
38	532 40 38-19	Discharge Deflector
39	532 41 91-93	Handle Bracket Assembly, LH
40	532 41 91-92	Handle Bracket Assembly, RH
41	532 15 04-06	Screw, Hex Head, Threaded, Rolled 3/8-16 x 1-1/8
42	532 19 30-00	Spring, Torsion
43	873 80 04-00	Nut, Hex, Nylock
44	532 41 74-05	Kit, Lawn Mower Housing (Includes Key Numbers 14, 15 and 51)
45	532 17 56-50	Rod, Hinge
46	532 18 91-79	Blade Adapter / Pulley
47	532 40 67-13	Blade, 22"
48	532 85 10-74	Washer, Hardened
49	532 85 02-63	Washer, Helical
50	532 85 10-84	Screw, Machine, Hex Head 3/8-24 x 1-3/8 Grade 8
51	532 17 00-31	Front Baffle
52	532 40 47-63	Danger Decal
53	817 60 04-06	Screw
55	873 93 06-00	Nut, Hex
56	532 08 86-52	Screw, Hinge 1/4-20 x 1-1/4
57	532 05 17-93	Hairpin Cotter
58	532 40 34-33	Lower Handle
59	532 19 15-74	Handle Bolt
61	532 19 09-39	Bracket Debris Shield
62	532 40 58-43	Debris Shield
63	532 19 23-25	Screw, Debris Shield
64	- - -	Engine, Briggs & Stratton, Model Number 124T05 (Order parts from Engine manufacturer)
67	532 40 16-07	Clip, Packaging
68	532 41 06-23	Wheel Adjusting Bracket, LH
69	532 19 79-91	Clip, Cable
75	532 18 61-59	Screw
76	532 18 03-31	Key
79	532 18 63-62	Foam Grip
- -	532 40 47-64	Warning Decal (not shown)
- -	532 41 91-41	Owner's Manual, English / French

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

ROTARY LAWN MOWER - - MODEL NUMBER 65022ES (96143002302) - PRODUCT NUMBER 961 43 00-23



ROTARY LAWN MOWER - - MODEL NUMBER 65022ES (96143002302) - PRODUCT NUMBER 961 43 00-23

KEY NO.	PART NO.	DESCRIPTION
1	532 19 46-53	Drive Control Cable
6	532 15 04-95	Retainer, Spring
7	532 19 90-93	Bar, Drive Control
11	532 41 10-81	Wheel & Tire Assembly
12	812 00 00-58	E-Ring
13	532 40 38-49	Gear, Pinion
14	532 18 94-03	Dust Cover
15	532 40 48-45	Pawl, Drive
16	532 06 77-25	Washer, Flat 3/8
17	532 19 10-39	Ball Bearing
18	532 19 64-01	Selector Knob
27	532 17 52-62	Pan Head Tapping Screw #10-24 x 2-3/4
28	532 41 91-95	Drive Cover
29	532 40 91-48	Locknut, Hex
31	532 14 18-41	Screw, Torx Pan Head #20
33	532 14 65-27	V-Belt
34	532 41 11-90	Trimplate
35	532 40 88-62	Kit, Wheel Adjuster, LH (Includes Knob and Bearing)
36	532 41 52-26 *	Gear Case Assembly, Complete
37	532 18 95-89	Battery
38	873 80 04-00	Locknut, Hex 1/4-20
39	532 18 62-37	Box, Battery
40	532 13 70-90	Spring
41	532 40 88-61	Kit, Wheel Adjuster, RH (Includes Knob and Bearing)
42	817 41 13-08	Screw, Hex Head #13 x 1/2

KEY NO.	PART NO.	DESCRIPTION
44	532 17 55-51	Screw, Shoulder, Hex Head #10-28 x 5/8
45	532 19 00-97	Charger, Battery
54	532 41 06-83	Grassbag Assembly
56	532 19 12-52	Trimplate / Battery / Battery Box Assembly
57	532 41 19-52	Frame, Grassbag
60	532 18 34-97	Case, Lower
61	532 18 34-98	Case, Upper
62	532 18 34-99	Gear, 27 Teeth
63	532 18 35-00	Lever, Clutch
64	532 18 35-01	Spring, Return
65	532 41 69-88	Worm
66	532 18 35-03	Dog, Movable
67	532 18 35-04	Dog, Fixed
68	532 18 35-05	Wire, Formed
69	532 18 35-06	Bearing, Ball
70	532 18 35-07	Fork, Shift
71	532 18 35-08	Seal, Output Shaft
72	532 18 35-09	Washer
73	532 18 35-10	Seal, Case
74	532 18 35-11	Bushing
75	532 19 65-61	Shaft, Output
76	532 18 35-13	Screw
77	532 18 35-14	Seal, Input Shaft
78	532 41 69-87	Pulley, Drive
79	532 41 69-86	Nut

* **NOTE:** We advise Total Multis EP00 semi-liquid grease or a comparable grade (quantity 1.15 oz)

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.