

# LT151

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**


---

# ILLUSTRATED PARTS LIST

MODEL NO. 96041001805

CUSTOMER CATALOG NO. LT151


PRODUCT NO. 960 41 00-18



47

408771


**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18**  
**DECALS 27**



| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 1       | 532 40 03-89 | Decal, Operators            |
| 2       | 532 42 20-12 | Decal, Hood RH/LH           |
| 3       | 532 19 68-41 | Decal, Warning Eng. Symbols |
| 4       | 532 40 85-96 | Decal, Hood Panel           |
| 5       | 532 15 97-36 | Decal, Chassis Hot Muffler  |
| 6       | 532 18 04-32 | Decal, Fender 100 DB/CE     |
| 7       | 532 18 21-66 | Decal, Cutfinger CE         |
| 9       | 532 14 50-05 | Decal, Battery Dan./Poi.    |
| 10      | 532 14 08-37 | Decal, Saddle Brake Parking |

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 11      | 532 19 63-57 | Decal, Warning                |
| 12      | 532 19 43-02 | Decal, Mower V-Belt Schematic |
| 13      | 532 15 97-37 | Decal, Brake/Clutch Symbol    |
| 14      | 532 40 11-46 | Decal, Warning Service/Fire   |
| 15      | 532 41 30-01 | Decal, Repl.                  |
| --      | 532 41 08-05 | Pad, Footrest, LH             |
| --      | 532 41 10-56 | Pad, Footrest, RH             |
| --      | 532 16 25-98 | Decal, Drawbar Load Limit     |
| --      | 532 43 22-44 | Manual Oper. Euro             |

## WHEELS AND TIRES




| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                    |
| 2       | 532 06 51-39 | Stem Valve                        |
| 3       | 532 13 83-36 | Rim Asm 6" Front                  |
| 4       | 532 05 99-04 | Tube Front (Service Item Only)    |
| 5       | 532 10 62-22 | Tire FT 15 x 6 0 - 6              |
| 6       | 532 12 49-57 | Fitting Grease (Front Wheel Only) |
| 7       | 532 12 49-59 | Bearing Flange (Front Wheel Only) |
| 8       | 532 17 50-39 | Cap Axle Blk. 1 50 x 1 00         |
| 9       | 532 42 05-31 | Tire R 18 x 9.5-8 Turf Saver LT   |
| 10      | 532 12 49-26 | Tube Rear (Service Item Only)     |
| 11      | 532 13 83-37 | Rim Asm. 8" Rear                  |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. Tube)       |


**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18  
SCHEMATIC 38

SCH10



TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18  
ELECTRICAL **32**




**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18**  
**ELECTRICAL 32**

| <b>KEY<br/>NO.</b> | <b>PART<br/>NO.</b> | <b>DESCRIPTION</b>               |
|--------------------|---------------------|----------------------------------|
| 1                  | 532 16 34-65        | Battery                          |
| 2                  | 874 76 04-12        | Bolt Hex Head 1/4-20 x 3/4       |
| 8                  | 532 19 32-28        | Box Battery                      |
| 16                 | 532 17 61-38        | Switch Interlock Push-In         |
| 21                 | 532 40 02-52        | Harness Socket Light w/4152J     |
| 22                 | 532 00 41-52        | Bulb Light                       |
| 25                 | 532 41 28-94        | Cable Starter                    |
| 26                 | 532 17 51-58        | Fuse                             |
| 27                 | 873 51 04-00        | Nut Keps Hex 1/4-20 unc          |
| 28                 | 532 19 88-85        | Cable, Ground                    |
| 29                 | 532 40 15-45        | Switch, Seat                     |
| 30                 | 532 19 33-50        | Switch, Ign.                     |
| 33                 | 532 41 19-35        | Key/Chain                        |
| 34                 | 532 11 07-12        | Switch Light/Reset               |
| 40                 | 532 40 10-98        | Harness Ign. Dash                |
| 41                 | 817 72 04-08        | Screw Thd. Cut 1/4-20 x 1/2      |
| 42                 | 532 13 15-63        | Cover, Terminal                  |
| 43                 | 532 19 25-07        | Solenoid                         |
| 55                 | 817 06 05-12        | Screw Thdrol. 5/16-18 x 3/4 TYTT |
| 71                 | 532 40 04-49        | Harness Ign.                     |
| 79                 | 532 17 52-42        | Socket Asm.                      |
| 87                 | 532 19 78-02        | Switch Interlock Clutch Cable    |
| 90                 | 532 40 07-25        | Cover Terminal                   |
| 92                 | 532 19 66-15        | Harness Pigtail Reverse Switch   |
| 93                 | 532 19 25-40        | Screw Plastite 10-14 x 2.0       |
| 94                 | 532 19 18-34        | Module Reverse ROS               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18**  
**CHASSIS AND ENCLOSURES 39**



chassis-tex\_TEX LT HUSQ\_18\_r1


**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18  
CHASSIS AND ENCLOSURES 39**

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 3       | 532 40 50-12 | Logo                           |
| 5       | 532 40 75-92 | Dash                           |
| 14      | 532 41 10-73 | Hood                           |
| 15      | 532 41 10-79 | Lens LH                        |
| 18      | 532 42 69-63 | Grille                         |
| 25      | 532 41 10-78 | Lens RH                        |
| 34      | 532 19 61-25 | Plate Engine                   |
| 36      | 817 06 05-12 | Screw 5/16-18 x 3/4            |
| 37      | 532 41 63-07 | Fender                         |
| 52      | 873 68 05-00 | Nut Crown Lock 5/16-18         |
| 58      | 532 41 22-80 | Drawbar Upper                  |
| 68      | 817 49 05-08 | Screw Thdrol. 5/16-18 x 1/2    |
| 130     | 532 41 63-58 | Screw #10 x 0.750 BOS Thread   |
| 137     | 532 40 75-90 | Bumper Dash                    |
| 150     | 532 40 75-37 | Air Duct                       |
| 151     | 532 40 78-07 | Bracket Pivot                  |
| 152     | 532 19 95-35 | Shield Browning                |
| 159     | 817 00 06-12 | Screw 3/8 - 16 x 3/4           |
| 162     | 532 14 24-32 | Screw Hex Wsh. Hi-Lo 1/4 x 1/2 |
| 175     | 532 19 94-72 | Crossmember                    |
| 176     | 532 40 07-76 | Screw 10-24 x 5/8              |
| 177     | 532 19 52-28 | Bushing Steering               |
| 180     | 532 41 50-63 | Chassis                        |
| 182     | 532 40 71-76 | Dash Lower                     |
| 183     | 874 52 05-20 | Bolt 5/16-18 unc x 1-1/4       |
| 189     | 817 00 05-12 | Screw 5/16-18 x 3/4            |
| 191     | 532 41 65-00 | Insert Reflective RH           |
| 194     | 873 90 05-00 | Nut Lock Hex Flange 5/16-18    |
| 195     | 532 41 11-15 | Plug Dash                      |
| 199     | 532 41 34-85 | Plate Deck Lift                |

| KEY NO. | PART NO.     | DESCRIPTION                      |
|---------|--------------|----------------------------------|
| 202     | 532 41 10-74 | Vent Side Hood RH                |
| 203     | 532 41 10-75 | Vent Side Hood LH                |
| 204     | 532 41 11-16 | Vent Top Hood                    |
| 205     | 532 41 10-76 | Skirt Side RH                    |
| 206     | 532 41 10-77 | Skirt Side LH                    |
| 213     | 874 76 05-12 | Bolt 5/16-18 unc x 3/4           |
| 214     | 532 19 91-45 | Clip Retainer                    |
| 217     | 532 40 91-67 | Rod Pivot Hood                   |
| 218     | 532 19 63-95 | X-Piece Hood Stop                |
| 228     | 532 19 51-61 | Stud Fastener                    |
| 234     | 532 40 47-42 | Bumper Hood                      |
| 235     | 532 40 61-29 | Spacer Fender                    |
| 236     | 873 93 05-00 | Nut Lock 5/16-18 unc             |
| 238     | 532 41 11-19 | Trim                             |
| 239     | 532 40 48-83 | Clip Tinnerman                   |
| 282     | 532 41 41-10 | Clip Retainer Console            |
| 283     | 532 41 63-16 | Console Deck Lift Husq. N/FR. GR |
| 284     | 532 41 63-14 | Console Shft Hyd HUSQ. LT.       |
| 285     | 532 41 63-15 | Console Insrt. RH HUSQ.          |
| 286     | 532 41 63-17 | Console Insrt. LH HUSQ.          |
| 287     | 817 60 04-06 | Screw Hex WASHEAD 1/4-20 x 3/8   |
| 297     | 532 40 66-65 | Insert Reflective LH             |
| 303     | 532 42 09-59 | Shield Chassis French LH         |
| 304     | 532 42 15-09 | Shield Chassis French RH         |
| 305     | 872 11 06-06 | Bolt RDHD SHT SQNK 3/8-16 x 3/4  |
| 306     | 873 90 06-00 | Nut Lock FLG 3/8-16 unc          |
| 312     | 532 42 09-60 | Shield Drawbar French            |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18  
 DRIVE **40**




drive-tex\_peerless\_fender\_38

**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18  
DRIVE **40****

| KEY NO. | PART NO.     | DESCRIPTION                    | KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|--------------------------------|---------|--------------|-----------------------------------|
| 1       | -----        | Transaxle, Peerless 206-565    | 165     | 532 19 62-12 | Bushing Shaft Brake Hand Control  |
| 2       | 532 12 35-83 | Key Square                     | 166     | 532 42 83-05 | Nut Push .625                     |
| 15      | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga.  | 167     | 532 40 52-57 | Latch Brake Parking               |
| 17      | 532 19 72-97 | Spring, Brake                  | 172     | 532 19 76-57 | Strap Torque LH                   |
| 22      | 532 19 76-60 | Rod Shift                      | 174     | 532 19 72-89 | Nut Push                          |
| 23      | 532 12 12-74 | Knob Duckhead 1/2-13           | 175     | 532 19 78-58 | Shaft Asm. Shift                  |
| 26      | 532 19 74-55 | Spring Brake Return            | 176     | 532 19 62-14 | Arm Clevis Rod Shift              |
| 29      | 532 19 72-67 | Rod, Brake                     | 178     | 532 19 74-56 | Spring Shift                      |
| 33      | 812 00 00-01 | Ring E                         | 183     | 532 13 70-57 | Spacer Axle                       |
| 35      | 532 40 10-31 | Rod, Brake, Park               | 184     | 532 40 97-47 | Knob                              |
| 37      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.  | 185     | 872 11 06-22 | Bolt                              |
| 42      | 532 12 48-72 | Cover, Foot Pedal              | 186     | 532 19 43-21 | Spacer Retainer                   |
| 49      | 872 11 06-14 | Bolt                           | 187     | 819 13 32-10 | Washer                            |
| 50      | 532 19 43-27 | Pulley Idler Flat              | 188     | 532 19 43-23 | Bellcrank Ground Drive            |
| 51      | 873 90 06-00 | Lock Nut 3/8-16                | 189     | 532 19 43-17 | Bellcrank Ground Drive            |
| 52      | 532 19 43-26 | Idler V-Groove                 | 190     | 532 19 43-18 | Keeper Bellcrank Ground Drive     |
| 56      | 532 19 43-46 | V-Belt, Drive                  | 192     | 532 15 03-60 | Nut Lock Center 1/4-28 Fnthd.     |
| 61      | 532 12 36-66 | Pulley transaxle               | 193     | 817 06 05-12 | Screw 5/16-18 x 3/4               |
| 64      | 53219 62-00  | Shaft Asm. Pedal Brake Control | 195     | 532 19 73-32 | Bracket Brake Rod                 |
| 73      | 874 49 05-44 | Bolt Hex Flghd. 5/16-18 Gr. 5  | 202     | 532 19 78-59 | Link Transaxle                    |
| 116     | 873 90 05-00 | Nut Lock Hex Flange 5/16-18    | 203     | 819 11 11-16 | Washer 11/32 x 11/16 x 16 Ga.     |
| 125     | 817 00 05-12 | Screw 5/16-18 x 3/4            | 205     | 532 12 17-48 | Washer 25/32 x 1-5/8 16 Ga.       |
| 134     | 532 19 78-57 | Asm. Shift                     | 221     | 532 40 31-87 | Retainer Spring Clip Handle       |
| 139     | 874 55 04-12 | Bolt 1/4-28 unf Gr. 8 w/Patch  | 232     | 874 78 07-16 | Bolt Fin. Hex 7/16 - 14 x 1 Gr. 5 |
| 140     | 810 04 04-00 | Washer Lock Hvy. Helical 1/4   | 233     | 532 40 52-96 | Washer Serrated                   |
| 141     | 819 09 12-10 | Washer 9/32 x 3/4 x 10 Ga.     |         |              |                                   |
| 155     | 812 00 00-28 | Ring Retainer                  |         |              |                                   |
| 157     | 532 10 57-01 | Washer Plate Shift             |         |              |                                   |
| 158     | 532 19 43-52 | Belt Keeper                    |         |              |                                   |
| 159     | 876 02 04-12 | Pin Cotter 1/8 x 3/4           |         |              |                                   |
| 160     | 532 16 94-84 | Retainer Clip                  |         |              |                                   |
| 161     | 532 10 57-09 | Spring, Return, Clutch         |         |              |                                   |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm




**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18  
ENGINE 24**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                        |
|------------|--------------|------------------------------------|
| 1          | ---          | Engine Kohler Model No. SV470-0212 |
| 2          | 532 18 86-55 | Muffler                            |
| 9          | 532 19 43-19 | Keeper Belt Engine                 |
| 12         | 532 40 19-85 | Pulley Engine                      |
| 15         | 532 40 75-45 | Tank Fuel 1.5                      |
| 18         | 532 42 51-62 | Cap Fuel                           |
| 20         | 532 18 38-97 | Control Throttle                   |
| 21         | 532 41 63-58 | Screw #10 x 0.750 BOS Thread       |
| 28         | 532 13 70-40 | Fuel Line                          |
| 29         | 532 13 71-80 | Spark Arrester Kit                 |
| 37         | 532 12 34-87 | Clamp Hose                         |
| 41         | 810 04 07-00 | Bolt 5/16-18 unc x 3/4 w/Sems.     |
| 43         | 532 17 39-37 | Bolt Hex 7/16-20 x 4 Gr. 5         |
| 45         | 873 51 04-00 | Nut Keps Hex 1/4-20 unc            |
| 69         | 532 18 59-09 | Gasket                             |
| 72         | 532 19 23-34 | Screw 5/16 - 18 x .75              |
| 81         | 532 42 82-87 | Valve Drain Oil                    |
| 82         | 532 18 16-54 | Plug Drain Oil                     |
| 83         | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems.     |
| 90         | 817 00 06-16 | Screw 3/8-16 x 1                   |
| 92         | 817 12 06-16 | Screw 3/8-16 x 1                   |
| 94         | 532 18 86-54 | Tube Exhaust                       |
| 96         | 819 09-14-16 | Washer 9/32 x 7/8 x 16 Ga.         |
| 97         | 817 67 04-12 | Screw 1/4-20 x 3/4                 |
| 102        | 817 00 05-12 | Screw 5/16                         |
| 105        | 532 41 05-28 | Shield Side LH                     |
| 106        | 532 41 05-29 | Shield Side RH                     |
| 107        | 532 13 77-29 | Screw 1/4 - 20 x 5/8               |
| 108        | 532 42 17-94 | Cover Asm. Engine                  |
| 115        | 532 42 30-62 | Palnut 1/4"                        |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18  
STEERING ASSEMBLY **41**




steering-tex\_HUSQSR\_10\_r1

**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18**  
**STEERING ASSEMBLY 41**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                      |
|------------|--------------|----------------------------------|
| 1          | 532 41 64-80 | Wheel, Steering Husq SR          |
| 2          | 532 41 81-68 | Axle Asm., Front                 |
| 4          | 532 40 30-87 | Spindle Asm., LH                 |
| 5          | 532 40 30-88 | Spindle Asm., RH                 |
| 6          | 532 12 49-31 | Washer Thrust                    |
| 7          | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.    |
| 8          | 812 00 00-29 | Ring, Clip #T5304-75             |
| 9          | 532 12 12-32 | Cap, Spindle                     |
| 13         | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.    |
| 14         | 810 04 06-00 | Washer, Lock Hvy. Hlcl. Spr. 3/8 |
| 15         | 873 54 06-00 | Nut, Crown Lock 3/8-24 unf       |
| 16         | 532 42 93-73 | Shaft Steering                   |
| 19         | 532 19 47-29 | Plate Steering                   |
| 20         | 532 41 11-39 | Boot, Steering                   |
| 21         | 532 18 67-37 | Adapter, Wheel Steering          |
| 22         | 532 42 05-37 | Supt. Strg. Lower                |
| 26         | 532 41 59-87 | Insert, Wheel Steering Husq SR   |
| 28         | 817 00 06-12 | Screw 3/8-16 x 3/4               |
| 33         | 810 04 05-00 | Washer Lock 5/16                 |
| 35         | 532 19 47-32 | Gear, Sector Plate               |
| 45         | 819 11 38-12 | Washer 11/32 x 3/8 x 12 Ga.      |
| 53         | 532 18 89-67 | WasherHardened.793x1.637x.060    |
| 57         | 532 40 74-65 | Bracket Upstop                   |
| 58         | 532 19 47-47 | Bolt Shoulder Sector Pivot CFM   |
| 59         | 532 19 47-48 | Washer Thrust Sector Steering    |
| 60         | 873 97 10-00 | Nut Flange Lock 5/8-11           |
| 61         | 532 19 47-40 | Draglink LH                      |
| 62         | 532 19 47-41 | Draglink, RH                     |
| 63         | 817 00 05-12 | Screw 5/16-18 x 3/4              |
| 64         | 532 19 98-49 | Retainer Clip Spring Steering    |
| 66         | 871 02 07-48 | Bolt Hex Fghd. 7/16-14 x 3 Serr. |
| 67         | 532 19 47-37 | Bushing PM Front Axle            |
| 68         | 873 90 07-00 | Nut Lock Flange 7/16-14 Gr. 5    |
| 69         | 532 19 91-62 | Washer 1.5 x .505 x .118         |
| 70         | 532 19 61-97 | Bracket Deck Susp. Front         |
| 71         | 532 19 07-52 | Shaft Extension Steering         |
| 72         | 532 42 89-82 | Bolt 5/16-18 x 4 w/Patch         |
| 74         | 532 12 49-37 | Bearing                          |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18**  
**MOWER DECK 44**




38-7\_Tex-LT\_15\_r1

**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18  
MOWER DECK 44**

| KEY NO. | PART NO.     | DESCRIPTION                         | KEY NO. | PART NO.     | DESCRIPTION                                                                                                                   |
|---------|--------------|-------------------------------------|---------|--------------|-------------------------------------------------------------------------------------------------------------------------------|
| 1       | 532 19 42-51 | Mower Housing                       | 69      | 872 14 05-05 | Bolt                                                                                                                          |
| 6       | 532 19 51-86 | Arm Suspension                      | 70      | 532 40 12-46 | Clutch Asm. Manual                                                                                                            |
| 7       | 532 41 63-58 | Screw #10 x 0.750 BOS Thread        | 122     | 532 19 72-58 | Keeper Belt Engine LH                                                                                                         |
| 8       | 532 19 30-03 | Bolt/Washer Asm. 7/16-20 unf        | 123     | 532 19 72-59 | Keeper Belt Engine RH                                                                                                         |
| 11      | 532 19 39-57 | Blade 38" 3NI Premium               | 144     | 532 19 34-14 | Keeper Belt                                                                                                                   |
| 13      | 532 19 28-72 | Shaft Assembly, Mandrel             | 145     | 532 19 31-97 | Pulley Idler                                                                                                                  |
| 14      | 532 18 72-81 | Housing, Mandrel                    | 147     | 532 40 18-72 | Spring Return                                                                                                                 |
| 15      | 532 11 04-85 | Bearing, Ball, Mandrel              | 152     | 532 40 87-14 | Manual Clutch Cable                                                                                                           |
| 19      | 532 19 65-39 | Bolt, Shoulder                      | 188     | 532 19 51-61 | Stud Fastener                                                                                                                 |
| 21      | 873 68 05-00 | Nut, Crownlock 5/16-18 unc          | 189     | 873 90 05-00 | Nut Lock Hex Flange                                                                                                           |
| 23      | 532 19 25-57 | Bracket, Deflector                  | 195     | 817 00 06-12 | Screw 3/8-16 x 3/4                                                                                                            |
| 24      | 532 10 53-04 | Cap, Sleeve                         | 199     | 532 40 00-95 | Baffle Vortex                                                                                                                 |
| 25      | 532 19 70-26 | Spring, Torsion, Deflector          | 205     | 817 49 04-16 | Screw 1/4 - 20 x 1.00 77                                                                                                      |
| 26      | 532 11 04-52 | Nut, Push                           | 206     | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.                                                                                                    |
| 27      | 532 40 16-18 | Shield, Deflector                   | 208     | 817 67 06-08 | Screw 3/8 - 16 x 1/2                                                                                                          |
| 29      | 532 13 14-91 | Rod, Hinge                          | 209     | 819 13 32-10 | Washer 13/32 x 2 x 10                                                                                                         |
| 30      | 532 17 39-84 | Screw Thdrol. Rolling Wsh. Hd.      | 241     | 532 15 29-27 | Screw TT # 10-32.5 3/8 Flange                                                                                                 |
| 31      | 532 18 76-90 | Washer, Spacer                      | 242     | 532 41 55-98 | Port Washout                                                                                                                  |
| 32      | 532 19 97-89 | Pulley, Mandrel                     | 243     | 532 40 65-10 | Cover Deck 38-7                                                                                                               |
| 33      | 532 40 02-34 | Nut, Toplock, Flanged               | 244     | 532 42 30-62 | Palnut 1/4"                                                                                                                   |
| 34      | 872 11 06-12 | Bolt Carr. Sh. 3/8-16 x 1-1/2 Gr. 5 | 247     | 532 43 02-58 | Shield Deck RH                                                                                                                |
| 35      | 532 13 38-35 | Fastener, Christmas Tree            | 248     | 532 43 02-59 | Shield Deck LH                                                                                                                |
| 37      | 819 13 13-16 | Washer                              | 249     | 532 40 65-14 | Cover Cable Clutch                                                                                                            |
| 38      | 532 19 95-41 | Keeper Belt LH Mandrel              | 250     | 532 42 73-50 | Rivet Tulflok 25 x 24                                                                                                         |
| 40      | 873 90 06-00 | Nut, Lock Flg. 3/8-16 unc           | 251     | 532 43 60-87 | Kit Bungee (Includes Phillips head screw, weld nut, screw, bungee latch, and bungee strap)                                    |
| 42      | 532 19 72-56 | Spring Torsion Retainer             |         |              |                                                                                                                               |
| 43      | 532 19 84-10 | Spring Torsion Brake                | - -     | 532 19 28-70 | Mandrel Assembly (Includes housing, shaft assembly, and bearing only - pulley/nut/washer and blade bolt/washers not included) |
| 46      | 532 13 77-29 | Screw 1/4 - 20 x 5/8                |         |              |                                                                                                                               |
| 55      | 532 19 72-49 | Arm, Idler                          | - -     | 532 43 16-91 | Replacement Mower, Complete                                                                                                   |
| 56      | 532 19 90-92 | Spacer, Retainer                    |         |              |                                                                                                                               |
| 57      | 817 00 06-16 | Screw 3/8-16 x 1                    |         |              |                                                                                                                               |
| 59      | 532 14 10-43 | Guard, Tuv. Idler                   |         |              |                                                                                                                               |
| 60      | 532 19 94-71 | Arm Brake Mower                     |         |              |                                                                                                                               |
| 63      | 532 19 94-70 | Arm Brake Mower                     |         |              |                                                                                                                               |
| 64      | 532 19 97-90 | Link Brake                          |         |              |                                                                                                                               |
| 67      | 532 40 30-12 | Handle Clutch Cable                 |         |              |                                                                                                                               |
| 68      | 532 40 83-81 | V-Belt                              |         |              |                                                                                                                               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18**  
**SEAT ASSEMBLY 42**




| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 19 75-18 | Seat                           |
| 2       | 532 18 01-66 | Bracket Pivot Fender           |
| 3       | 532 14 06-75 | Strap, Asm. Fender             |
| 6       | 873 80 06-00 | Nut, Lock w/Ins. 3/8-16 unc    |
| 7       | 532 12 41-81 | Spring, Seat Cprsn.            |
| 8       | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems. |
| 10      | 532 19 69-77 | Pan, Seat                      |
| 21      | 532 17 18-52 | Bolt, Shoulder 5/16-18         |

| KEY NO. | PART NO.     | DESCRIPTION                      |
|---------|--------------|----------------------------------|
| 37      | 873 80 05-00 | Nut, Lock 5/16-18 unc            |
| 40      | 532 19 76-61 | Handle Slide                     |
| 41      | 532 19 82-00 | Spring Latch Seat                |
| 43      | 874 76 06-12 | Bolt Fin. Hex 3/8 - 16 unc x 3/4 |
| 44      | 819 13 38-12 | Washer 13/32 x 2-3/8 x 12 Ga     |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LT151 (96041001805), PRODUCT NO. 960 41 00-18**  
**MOWER LIFT 45**



| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 2       | 532 42 20-27 | Shaft Asm., Lift             |
| 3       | 532 19 52-31 | Lever Asm., Lift RH          |
| 7       | 532 41 15-55 | Grip, Lever                  |
| 10      | 532 19 63-14 | Spring Torsion               |
| 87      | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock |
| 88      | 532 41 07-10 | Spring Lift Assist           |
| 89      | 819 19 19-12 | Washer Clear Zinc            |
| 90      | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock |

| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 91      | 532 19 51-81 | Link Lift Susp. Mower Rear        |
| 97      | 817 00 06-12 | Screw 3/8-16 x .75 Smgml. Tap/R.Z |
| 98      | 532 19 52-70 | Link Lift Susp. Front Mower       |
| 100     | 873 93 06-00 | Nut Centerlock 3/8-16             |
| 101     | 532 40 70-03 | Link Asm. Lift FXD                |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

