


REPAIR PARTS FOR 966674301 130 LB. TOW SPREADER



REPAIR PARTS FOR 966674301 130 LB. TOW SPREADER

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	577 15 75-01	Hopper	33	1	576 84 55-01	Pin, Cotter 1/8 x 1-1/4
2	1	577 15 76-01	Tube, RH Hitch Support	34	1	577 16 01-01	Gear, Large (Cast)
3	1	577 15 78-01	Tube, LH Hitch Support	35	1	577 16 02-01	Gear, Small (Cast)
4	1	577 15 79-01	Flow Control (incl. items 50 - 54)	36	1	577 16 03-01	Shaft, Axle Spreader
5	1	577 15 80-01	Tube, Hitch	37	1	577 16 04-01	Plate, Flow
6	1	577 15 81-01	Tube, Control	38	2	577 16 05-01	Spring, Flow Plate
7	1	531 00 27-72	Bracket, Hitch	39	1	531 00 76-18	Pin, Spring, 3/16 x 1
8	2	577 15 83-01	Wheel	40	1	531 00 46-19	Bushing, Hopper Bottom Black
9	1	531 00 81-18	Pin, Hitch 3/8" x 3" Flat Hd	41	1	577 16 06-01	Clip, Hairpin 5/8
10	2	501 34 78-01	Bolt, Hex 1/4-20 x 2-1/2	42	2	577 16 07-01	Bearing, Flat Sided Flange
11	7	577 15 84-01	Bolt, Hex 1/4-20 x 1-3/4	43	1	531 00 76-93	Hairpin, Agitator
12	3	577 15 85-01	Bolt, Hex 1/4-20 x 1-1/2	44	2	531 00 27-77	Pin, Spring 1/8 x 1
13	2	531 00 81-17	Bolt, Hex 5/16-18 x 1-1/4	45	1	531 00 27-55	Spreader Impeller
14	1	531 00 28-41	Bolt, Hex 1/4-20 x 1-1/4	46	4	506 62 63-01	Washer, Nylon .3281 x .75
15	2	501 02 11-01	Nut, Hex 5/16-18 Nylock	47	2	577 16 08-01	Clip, Hairpin 7/8
16	14	504 06 60-01	Nut, Hex 1/4-20 Nylock	48	5	522 83 59-01	Washer, 1/4 Std .312 x .734
17	1	531 00 76-29	Nut, Hex 1/4-20 Lock	49	2	531 00 76-83	Plug, 1/4" (Christmas Tree)
18	4	577 15 86-01	Washer, .6562 x 1.25 x .0598	50	1	577 16 09-01	Cable, Flow Control (ref. item #4)
19	1	522 75 20-01	Pin, Hair Cotter 3/32 x 2-5/16	51	1	577 16 10-01	Flow Control Dial (ref. item #4)
20	2	577 15 87-01	Spacer, .64 ID x .84 OD x 1.00	52	1	577 16 11-01	Housing, Flow Control (ref. item #4)
21	1	577 15 89-01	Pin, Cotter 3/16 x 2	53	1	577 16 12-01	Spring, Flow Control (ref. item #4)
22	1	577 15 90-01	Knob	54	1	577 16 13-01	Shuttle, Flow Control (ref. item #4)
23	1	577 15 91-01	Lever, Flow Control	55	1	577 16 14-01	Vinyl Cover
24	2	577 15 92-01	Hub Cap	56	2	577 16 15-01	Bolt, Hex 1/4-20 x 2
25	3	577 15 93-01	Plug, 1" Tube	57	1	577 16 16-01	Screw, Lag 5/16" x 3/4"
26	1	577 15 94-01	Conduit Clip	58	1	531 00 46-56	Lock washer, 5/16"
27	1	577 15 95-01	Tube, Hopper Support LH	59	1	577 16 17-01	Cross Brace
28	1	577 15 96-01	Tube, Hopper Support RH	60	2	501 33 73-01	Bushing, 3/8" Plastic
29	1	577 15 97-01	Shaft, Spreader	61	1	522 59 17-01	Spacer
30	2	577 15 98-01	Housing, Large Gear	62	1	577 16 18-01	Lock Washer, 1/4"
31	3	577 15 99-01	Washer, .625 x 1.0 x .03	1		41420	Owners Manual
32	1	577 16 00-01	Yoke, Large				