

Snow Thrower

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar


REPAIR PARTS FOR 45-04791-669 SNOW THROWER



REPAIR PARTS FOR 45-04791-669 SNOW THROWER

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	577 77 79-01	Gearbox Mounting Assembly	46	1	501 34 24-01	Compression Spring
2	8	522 77 03-01	Washer, 5/16"	47	2	501 34 25-01	Washer, .406 x .812 x .062
3	15	501 02 11-01	Nylock Nut, 5/16"	48	6	506 62 26-01	Hex Bolt, 5/16-18 x 3/4"
4	1	577 76 87-01	Gearbox	49	1	501 34 28-01	Spring Pin, 5/16 x 1-3/4"
5	2	506 62 61-01	Hex Bolt, 3/8-16 x 1-1/4"	50	1	501 34 23-01	Spring Pin, 3/16 x 1-3/4"
6	8	501 33 27-01	Nylock Nut, 3/8"	51	1	501 34 32-01	Lift Handle Tube
7	1	577 76 59-01	Gearbox Hub	52	1	501 34 33-01	Trigger & Lift Cable Assembly
8	2	577 15 84-01	Hex Bolt, 1/4-20 x 1-3/4"	53	1	501 34 34-01	Countersink Screw, 10-24 x 1.36"
9	2	531 00 76-29	Lock Nut, 1/4"	54	1	531 00 27-35	Handle Grip
10	1	501 34 06-01	#61 Woodruff Key	55	1	577 76 81-01	Chute Control Tube
11	1	577 76 89-01	6" Pulley	56	1	577 76 82-01	Chute Control Bracket
12	1	577 76 90-01	#6 Woodruff Key	57	4	577 77 97-01	Plastic Bushing, 3/8"
13	1	531 00 76-25	Hex Bolt, 3/8-24 x 1"	58	1	501 33 60-01	Chute Crank Bracket
14	1	577 76 60-01	Pulley Cover	59	1	501 33 78-01	Chute Bracket
15	2	577 77 70-01	Screw, 1/4-20 x 1/2"	60	2	577 77 95-01	U-Joint
16	2	577 76 92-01	Tinnerman Nut, 1/4"	61	1	577 76 84-01	Crank Rod
17	1	577 76 78-01	Mounting Bracket (RH)	62	4	531 00 76-78	Roll Pin, 1/8 x 5/8"
18	1	577 76 79-01	Mounting Bracket (LH)	63	1	577 76 93-01	Crank Rod Chute
19	1	577 76 77-01	Brace Bracket	64	1	501 34 37-01	Crank Knob
20	2	501 34 43-01	Washer, 1.59 x 1.03 x .06	65	2	522 75 58-01	Palnut, 3/8"
21	6	531 00 76-16	Lock Nut, 5/16"	66	1	577 77 89-01	Crank Chute Assembly
22	1	577 77 85-01	Wheel Mounting Bracket	67	1	501 34 40-01	Chute Tilt Bracket
23	1	531 00 76-79	Spacer, 1.03 x 1.25 x 2"	68	1	501 34 38-01	Chute Tilt Handle
24	1	577 77 75-01	Wheel Mounting Hub	69	1	577 15 90-01	Shift Knob
25	1	577 78 00-01	Square Key	70	1	501 33 99-01	Cable Guide
26	1	577 77 93-01	Washer, .41 x 1.25 x .156"	71	1	501 33 86-01	Chute Control Cable
27	4	577 15 71-01	Lock Washer, 3/8"	72	1	501 33 84-01	Chute Control Cable w/ Clip
28	1	577 77 71-01	Hex Bolt, 3/8-16 x 1"	73	2	522 77 02-01	Carriage Bolt, 5/16-18 x 1"
29	1	577 77 87-01	Rear Mounting Frame	74	1	577 77 99-01	Hose Cable Clip, 3/8"
30	1	577 77 86-01	Mounting Shaft	75	1	577 77 69-01	Slotted Bolt, 10-32 x 5/8"
31	6	506 62 49-01	Hex Bolt, 3/8-16 x 1"	76	1	531 00 81-65	Nylock Nut, 10-32
32	2	577 76 53-01	Spacer	77	1	577 76 51-01	Lift Strap
33	2	531 00 74-26	Hex Bolt, 5/16-18 x 1"	78	3	522 76 08-01	Cotter Pin, 1/8 x 3/4"
34	2	577 77 94-01	Washer, .344 x 1.125 x .12"	79	2	501 33 45-01	Washer, .531 x 1 x .059
35	6	522 75 15-01	Hex Bolt, 5/16-18 x 1-3/4"	80	1	577 76 85-01	Position Stop Strap
36	2	577 77 96-01	Wheel	81	1	577 76 54-01	Idler Tension Bracket
37	2	577 76 49-01	Spacer, .75 x .641 x 3.5"	82	4	522 75 93-01	Hex Bolt, 1/4-20 x 3/4"
38	2	577 76 86-01	Hex Bolt, 1/2-13 x 4-3/4"	83	4	504 06 60-01	Nylock Nut, 1/4"
39	2	522 83 55-01	Nylock Nut, 1/2"	84	4	522 83 56-01	Hex Bolt, 1/2-13 x 1-1/4"
40	1	577 77 73-01	Lift Shaft	85	4	501 33 41-01	Lock Nut, 1/2"
41	1	577 77 68-01	Cotter Pin, 1/8 x 1-1/2"	86	1	580 47 44-01	Belt Guide Bracket Assembly
42	2	501 34 14-01	Flange Bearing	87	1	580 47 45-01	Belt Guide Strap
43	1	577 76 55-01	Lift Bracket	88	2	580 47 46-01	Spacer, Belt Guide
44	1	577 77 74-01	Lift Handle Bracket	89	2	531 00 27-32	Hex Bolt, 3/8-16 x 2"
45	1	501 34 22-01	Index Lift Rod				

REPAIR PARTS FOR 45-04791-669 SNOW THROWER



REPAIR PARTS FOR 45-04791-669 SNOW THROWER

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	501 33 54-01	Housing Assembly	31	1	501 33 69-01	Chute Adapter
2	1	501 33 55-01	Worm Drive	32	4	531 00 76-37	Carriage Bolt, 1/4-20 x 3/4"
3	1	501 33 59-01	Shaft, Auger Gearbox	33	4	504 06 60-01	Nylock Nut, 1/4"
4	1	501 34 05-01	Brace, Gearbox Center	34	4	522 83 59-01	Washer, 1/4"
5	1	501 34 06-01	Key, #61 Woodruff	35	4	501 33 76-01	Nylon Washer
6	3	506 62 26-01	Hex Bolt, 5/16-18 x 3/4"	36	1	501 33 62-01	Chute Reinforcement
7	2	531 00 81-17	Hex Bolt, 5/16-18 x 1"	37	1	577 77 72-01	Sprocket & Hub Assembly
8	23	501 02 11-01	Nylock Nut, 5/16"	38	1	501 33 96-01	Washer, .41 x 1.25 x .156"
9	20	522 77 03-01	Washer, 5/16"	39	1	501 34 06-01	#61 Woodruff Key
10	1	501 33 57-01	Impeller Assembly	40	1	577 77 76-01	Sprocket & Shaft Assembly
11	2	501 33 67-01	Roll Pin	41	1	501 34 58-01	Bearing Housing
12	1	501 33 58-01	Scraper Plate	42	1	577 76 91-01	Bore Bearing, 7/8"
13	12	522 77 03-01	Washer, 5/16"	43	3	577 15 84-01	Hex Bolt, 1/4-20 x 1-3/4"
14	8	506 62 55-01	Carriage Bolt, 5/16-18 x 3/4"	44	3	531 00 76-29	Lock Nut, 1/4"
15	1	577 15 71-01	Lock Washer, 3/8"	45	1	577 76 88-01	#40 Roller Chain
16	2	501 33 75-01	Skid Shoe	46	1	577 76 84-01	Chute Rotation Stop Bracket
17	4	522 77 02-01	Carriage Bolt, 5/16-18 x 1"	47	1	501 34 04-01	Lower Chute
18	1	501 33 63-01	Spiral Auger (LH) not shown	48	1	577 77 90-01	Upper Chute
19	1	501 33 64-01	Spiral Auger (RH)	49	1	501 33 99-01	Cable Guide
20	4	501 33 71-01	Spacer, .75 x 1.25 x .5"	50	1	501 33 83-01	Cable Bracket
21	6	501 33 65-01	Hex Bolt, 5/16-18 x 3/4"	51	1	501 33 21-01	Hex Bolt, 5/16-18 x 1-1/2"
22	4	501 33 66-01	Shear Bolt, 5/16-18 x 1-1/2"	52	3	501 34 03-01	Chute Keeper
23	6	522 75 86-01	Lock Washer, 5/16"	53	1	501 34 02-01	Hex Screw, 1/4-14 x 5/8"
24	6	501 33 70-01	Washer, .76 x 1.49 x .06"	54	6	501 33 97-01	Flange Nut, 1/4"
25	2	531 00 76-55	Flange Bearing, 3/4"	55	6	522 76 17-01	Hex Bolt, 1/4-20 x 1"
26	4	501 33 74-01	Split Bearing, 3/4"	56	4	577 77 92-01	Washer, .281 x .625 x .065"
27	2	501 33 77-01	Hex Bearing, 1"	57	2	531 00 76-16	Lock Nut, 5/16"
28	1	501 33 53-01	Bearing Housing	58	4	501 33 41-01	Lock Nut, 1/2"
29	1	501 33 72-01	Ball Bearing		1	42386	Owners Manual
30	1	531 00 76-25	Hex Bolt, 3/8-24 x 1"				