

# Position and turning lights rear

**Spare parts**

**Ersatzteile**

**Pièces détachées**











**Reserve onderdelen**

**Repuestos**

**Reservdelar**

---

**A** P 500-SERIES  
966 79 09-01 Position and turning lights rear



**Page A    P 500-SERIES    966 79 09-01 Position and turning lights rear**

<b>Position</b>	<b>Article</b>	<b>Quantity</b>	<b>Notes</b>	<b>Kit</b>
1	578 34 65-01	1	BRACKET	
2	506 67 54-01	4	SCREW EHHFM	
3	576 64 57-05	4	NUT FLANGE	
4	578 34 79-01	1	TUBE	
5	578 34 79-02	1	TUBE	
6	578 35 93-01	2	KNOB	
7	544 88 51-01	2	LAMP	
8	576 64 57-03	4	NUT FLANGE	
9	544 88 98-01	4	REFLECTOR	
10	579 01 14-01	1	WIRING	
11	544 89 13-01	1	HORN	
12	506 57 01-03	2	SCREW EHHFM	
13	576 64 57-04	2	NUT FLANGE	