






**Assembly Instruction**  
**Rotating Beacon light**  
**500-series**




579 38 53-01




x 1



x 1




x 1




x 1




x 1




x 1




x 4








x 1




x 1




x 1





6



7



8



 **Husqvarna**

[www.husqvarna.com](http://www.husqvarna.com)

579 38 53-01

2012-05-03