




SPARE PARTS LIST

ACCESSORIES AND TOOLS


REAR TINE CULTIVATOR, 590366101,
2017-12



TRANSMISSION

REAR TINE CULTIVATOR, 590366101, 2017-12


Ref	Part No	Description	Remark	QTY KIT
2	589 91 14-01	WASHER	Alu plug 15x10x2	1
4	593 60 14-41	PLUG	Oil plug B	8
5	593 60 14-36	GASKET		1
8	593 60 14-50	PLUG	Rubber plug	1
10	593 60 14-07	BEARING	Bearing 6003	1
11	593 60 14-18	CIRCLIP	Circlip 35	1
12	593 60 14-42	SEAL	Oil Seal 17x35x6	1
13	593 60 14-06	BEARING	Bearing 6203-2Z	1
14	593 60 14-19	CIRCLIP	Circlip 40	3
17	593 60 14-44	PLUG	Oli plug 40x6	1
25	593 60 14-12	CHAIN	1-62-520HF3	1
26	593 60 14-43	SEAL	Oil seal TC6Y25x47x54x13x4	2
27	593 60 14-20	CIRCLIP	Circlip 47	1



TRANSMISSION

REAR TINE CULTIVATOR, 590366101, 2017-12


Ref	Part No	Description	Remark	QTY KIT
13	589 91 80-01	BOLT	M6x60	2



TRANSMISSION

REAR TINE CULTIVATOR, 590366101, 2017-12


Ref	Part No	Description	Remark	QTY KIT
3	593 60 14-10	BLADE	Right	10
5	593 60 14-09	BLADE	Left	10
7	593 60 14-27	CLAMP	Clamp B	2



TRANSMISSION

REAR TINE CULTIVATOR, 590366101, 2017-12

Ref	Part No	Description	Remark	QTY KIT
4	593 60 14-27	CLAMP	Clamp B	1
7	593 60 14-32	ROD	Dragstrut	1



TRANSMISSION

REAR TINE CULTIVATOR, 590366101, 2017-12

Ref	Part No	Description	Remark	QTY KIT
9	593 60 14-54	WASHER	Spring washer 10	1