

ILLUSTRATED PARTS LIST




ROTARY LAWN MOWER

MODEL NUMBER: LC 153-HD

MFG. ID. NUMBER: 96131003901

HUSQVARNA ROTARY LAWN MOWER -- MODEL NUMBER LC 153-HD (MFG. ID. NUMBER 96131003901)



HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER LC 153-HD (MFG. ID. NUMBER 96131003901)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 19 72-03	Control Bar, Molded	44	532 18 41-93	Bolt, Rear Door
2	586 73 76-02	Upper Handle Assembly (Includes Foam Grip)	45	532 15 04-06	Screw, Hex Head, Threaded, Rolled 3/8-16 x 1
3	580 63 86-03	Bar, Lower Handle	46	532 18 21-66	Danger Decal
4	581 90 21-01	Rope Guide	47	873 80 05-00	Nut, Hex
5	581 91 26-01	T-Knob	50	581 00 21-12	Grassbag
6	532 19 15-74	Handle Bolt	52	581 70 83-22	Kit, Housing (Includes Key Number 46)
7	532 06 64-26	Wire Tie	53	532 85 10-84	Screw, Hex Head, Grade 8, 3/8-24 x 1-3/8
10	593 24 11-03	Mulcher Door Kit	54	532 85 02-63	Helical Lockwasher
11	532 44 09-34	Engine Zone Control Cable	55	532 85 10-74	Hardened Washer
12	532 17 88-48	Screw, Hex Washer Head #10-16 x 5/8	56	532 19 93-77	21" Blade
13	532 43 00-34	Up-Stop Bracket	57	581 54 79-01	Blade Adapter
14	532 19 19-38	Handle Knob	59	- - -	Engine, Briggs & Stratton, Model Number 93J02-0090-H5 (order parts from B&S)
15	812 00 00-36	Klip Ring	61	532 40 91-48	Flanged Locknut
18	817 60 04-06	Screw	62	873 80 04-00	Nut, Hex
19	532 40 66-89	Axle Arm Assembly, Front, LH	65	532 08 83-48	Washer, Flat
20	532 40 66-90	Axle Arm Assembly, Front, RH	66	532 19 74-80	O-Ring
21	532 43 61-19	Foot Guard	73	532 40 16-30	Washer, Curved, Cylindrical
22	532 40 64-28	Selector Spring, Front	74	532 12 50-78	Washer, Special, Engine
23	581 42 56-01	Rear Door Assembly	76	589 41 68-04	Baffle, Rear
25	581 71 45-03	Handle Bracket, LH	77	817 41 13-12	Screw, Rear Baffle
26	581 71 46-03	Handle Bracket, RH	83	532 42 85-01	Baffle, Front
28	817 06 04-10	Screw, Hex Washer Head 1/4-20 x 5/8	84	817 00 05-10	Screw, Hex Head 5/8-16
29	532 41 05-94	Wheel Adjusting Bracket, Front	87	532 43 75-16	Plug, Handle Bar
30	532 40 16-29	Spacer	88	586 21 25-01	Bolt, Carriage
31	589 48 24-01	Discharge Deflector	89	873 97 05-00	Nut, Hex
32	532 41 08-88	Selector Spring, Rear	--	532 18 21-91	Warning Decal (not shown)
33	532 08 78-77	Selector Knob	--	581 27 63-01	Bag of Parts (Includes Key No.s 88 and 89)
34	532 41 08-90	Axle Arm Assembly, Rear	--	114 05 05-20	Operator's Manual, Euro
35	532 42 65-89	Nut, Hex	--	114 05 05-10	Operator's Manual, Scan
36	532 40 16-38	Shoulder Bolt 5/16-18	--	114 05 05-50	Operator's Manual, EBloc
37	532 41 08-31	Wheel & Tire Assembly, 8 x 1-3/4	--	114 05 05-40	Operator's Manual, Baltic
40	532 41 19-49	Frame, Grassbag	--	114 05 55-53	Operator's Manual, Turk/ Ukrainian
42	532 40 54-21	Spring, LH			
43	532 40 54-23	Spring, RH			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.