




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS


HU725AWDH, 96143012701, 2018-09



FRAME & ENGINE

HU725AWDH, 96143012701, 2018-09

Ref	Part No	Description	Remark	QTY	KIT
1	585 85 48-06	HANDLE	Upper Handle Assembly	1	
2	532 42 49-83	CABLE	Cable, Engine Zone Control	1	
6	532 18 23-98	KNOB	Handle Knob, Star	2	
8	587 68 93-02	BAIL ARM ASSY	Control Bar, Overmolded	1	
9	585 84 76-04	DOOR	Rear Door Assembly	1	
11	532 42 55-75	HAIR PIN COTTER	Hairpin, Door/Handle Pivot	2	
12	532 19 19-38	KNOB	Handle Knob, Standard	2	
13	532 43 75-16	PLUG	Plug, Lower Handle Bar	2	
17	581 78 21-01	BAFFLE	Rear Baffle	1	
18	581 91 26-01	KNOB	T-Knob	1	
19	581 90 21-01	GUIDE	Rope Guide	1	
20	532 44 45-37	DEFLECTOR	Rear Skirt	1	
21	532 41 99-49	SPRING	Spring, Rear Door, LH, Black	1	
22	532 14 18-41	SCREW	Screw, Panhead, Torx #20	2	
24	532 41 99-48	SPRING	Spring, Rear Door, RH, Grey	1	
26	532 41 99-45	SCREW	Screw, Rear Door/Handle Pivot	2	
28	586 21 25-01	BOLT	Bolt, Carriage 5/16-18 x 5/8	2	
30	580 94 34-08	GRASS BAG ASSY	Grassbag	1	
31	585 05 47-02	BAG FRAME	Frame, Grass Catcher	1	
32	532 44 11-92	LATCH	Latch, Mulcher Door	1	
33	532 41 99-27	MULCH DOOR	Mulcher Door	1	
34	532 43 81-34	BRACKET	Bracket, Grassbag	2	
36	532 17 57-35	HINGE	Bracket, Hinge	1	
38	532 42 61-29	DEFLECTOR	Discharge Deflector	1	
39	585 90 07-03	BRACKET	Handle Bracket, LH	1	
40	585 90 08-03	BRACKET	Handle Bracket, RH	1	
41	532 85 09-99	BOLT	Screw, Dogpoint 3/8-16 x 1-1/8	3	
42	532 19 30-00	HINGE	Spring, Hinge	1	
43	532 43 81-30	NUT	Nut, Hex	2	
44	581 70 83-62	HOUSING ASSY	Kit, Lawn Mower Housing	1	52
45	532 17 56-50	ROD	Rod, Hinge	1	
46	591 34 46-01	ADAPTER	Blade Adapter	1	
47	532 40 67-13	BLADE	"Blade, 22""	1	
48	532 85 10-74	WASHER	Washer, Hardened	1	
49	532 85 02-63	WASHER	Washer, Helical	1	
50	532 17 96-17	SCREW	Bolt, Hex Head, Grade 8 3/8-24 x 1-3/8	1	
51	532 43 05-99	BAFFLE	Front Baffle	1	
52	532 18 21-66	DECAL	Decal, Warning, Cut Finger	1	
53	817 00 05-10	BOLT	Screw	6	
56	817 41 13-12	SCREW	Screw, Hex Washer Head #13 x 3/4	6	
57	532 15 53-77	NUT	Nut, Hex	2	
58	585 90 82-03	HANDLE	Lower Handle	2	
59	532 19 15-74	HANDLE BOLT	Handle Bolt	4	
64	000 00 00-00	W/O DESCRIPTION	Engine, Briggs & Stratton, Model Number 104M02-0002-F1 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)	1	
83	532 75 00-97	SCREW HEX HEAD RL508A/B	Screw, Hex Washer Head	2	
84	532 42 81-24	FASTENER	Fastener, Push	3	
85	532 43 45-30	BRACKET	Mounting Bracket, Rear Skirt	2	
96	532 19 79-91	CLIP	Clip, Cable	2	
99	585 66 87-01	FRONT COVER ASSY	Front Shroud Assembly	1	
115	581 33 00-01	SCREW EHHFT	Screw	2	
116	581 74 56-01	SPACER	Spacer, Engine	1	



DRIVE

HU725AWDH, 96143012701, 2018-09

Ref	Part No	Description	Remark	QTY	KIT
1	589 81 88-07	DRIVE CABLE	Drive Control Assembly (Includes Cable)	1	
2	586 07 28-02	BRACKET	Mounting Bracket, Idler Pulleys	1	
4	589 59 92-01	TRANSMISSION	Gearcase Assembly, Front, Complete	1	
8	532 40 48-35	PINION	Pinion, Front	2	
10	587 24 93-02	BACKPLATE	Mounting Bracket, Drive Control	1	
12	580 36 46-03	BELT	Belt, Drive	1	
13	581 97 55-06	TRANSMISSION	Gearcase Assembly, Rear, Complete	1	
14	586 96 30-01	PULLEY	Pulley, Drive	2	
15	587 48 65-02	ADJUSTER	Wheel Adjuster Assembly, RH Rear	1	
16	581 49 79-07	ADJUSTER	Wheel Adjuster Assembly, LH Front	1	
18	532 70 10-37	KNOB	Knob, Wheel Adjuster	4	
20	580 80 69-01	BELT COVER	Debris Shield	1	
22	817 00 05-10	BOLT	Screw, Hex Head 1/4-20	3	
25	532 42 60-65	BRACKET	Mounting Bracket, Debris Shield	1	
26	581 15 25-02	BRACKET	Belt Keeper, Gearcase, Rear	1	
27	532 06 77-25	WASHER	Washer, Flat	2	
28	812 00 00-58	E-CLIP	E-Ring 7/16	4	
29	581 84 04-01	DUST COVER	Cover, Dust, Wheel, Front	2	
30	532 43 81-30	NUT	Nut, Hex	4	
31	532 40 48-45	PAWL, DRIVE	Pawl, Drive	4	
32	501 06 70-01	WHEEL ASSY	"Wheel & Tire Assembly, Rear, 11""	2	
33	532 40 91-48	NUT	Nut, Flangelock 3/8-16	2	
34	532 19 74-80	O-RING	O-Ring	2	
37	532 16 34-09	SCREW	Screw, Hi-Lo Thread, #12 x 5/8	2	
40	580 36 53-01	WHEEL	"Wheel & Tire Assembly, Front, 8""	2	
41	532 43 84-89	KIT	Kit, Water Washout Assembly	1	42, 43, 44
42	532 43 49-94	PORT	Fitting, Water Washout	1	
43	532 41 55-85	LOCKWASHER	Washer, Lock, Internal Tooth	1	
44	532 41 55-86	LOCKING NUT	Locknut, Hex, with O-Ring	1	
45	587 43 82-01	SCREW	Belt Keeper, Gearcase, Front	1	
46	584 29 94-01	SCREW EHHFT	Screw	1	
48	587 97 30-01	PULLEY	Pulley Assembly, Idler	1	
49	581 33 45-01	BOLT	Screw, Mounting, Idler Pulley	1	
55	581 35 13-01	SPRING	Spring, Tension	1	
57	532 40 91-49	NUT	Nut, Flangelock 3/8-16	2	
59	532 44 21-13	BRACKET	Support Bracket	2	
61	532 18 16-98	SCREW	Screw	2	
84	532 41 64-05	COUPLING	Adapter, Quick-Connect Coupling	1	
89	581 49 79-08	ADJUSTER	Wheel Adjuster Assembly, RH Front	1	
90	587 48 65-01	ADJUSTER	Wheel Adjuster Assembly, LH Rear	1	
91	587 23 24-01	PINION	Pinion, Rear	2	
92	587 25 17-01	DUST COVER	Cover, Dust, Wheel, Rear	2	
93	532 19 17-30	NUT	Nut, Hex	4	