


User manual

Snow blade

596 29 00-01








Read the instructions carefully before using the product

















596 29 00-01








1143290-26


P. Olssons i Linderöd AB










































 65 kg (Net)
75 kg (Gross)

