




327 LS, 20090100001-20105299999



SPARE PARTS LIST

S 327LS, LX, LDX, RX, RDX, RJX, 323RII
ACCESSORIES




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	544044210	SAW BLADE GUARD	Captive screws 323Rll. 327Rx	1	
2	573994304	SCREW IHSCFMO	Captive screws	2	1
3	574568001	CLAMP	Captive screws	1	1
4	537293401	ADAPTER		1	1
5	574564902	BLADE GUARD	Captive screws	1	1
6	503200316	SCREW IHSCFM	Captive screws	4	1
7	574039501	LOCK NUT	Captive screws	4	1
8	503977101	TRIMMER GUARD ASSY	327Lx, 327LDx	1	
9	503210716	SCREW IHST		1	8
10	503798801	BLADE		1	8
11	503934202	COMBINATION GUARD	323Rll, 327Rx	1	
12	503210716	SCREW IHST		1	11
13	503798801	BLADE		1	11

A 327LS, LX, LDX, RX, RDX, RJX, 323R11
BEVEL GEAR




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	537199202	BEVEL GEAR ASSY		1	
2	503856301	NUT		1	1
3	537285601	SUPPORT FLANGE		1	1
4	537292601	CUP		1	1
5	537234901	DRIVER ASSY		1	1
6	735312810	CIRCLIP		1	1
7	503252401	BALL BEARING		1	1
8	738219800	BALL BEARING		1	1
9	503201501	SCREW		1	1
10	503201412	SCREW IHSCFMO		1	1
11	503200725	SCREW IHSCFM		1	1
12	738219900	BALL BEARING		1	1
13	738219902	BALL BEARING		1	1
14	735311100	CIRCLIP		1	1
15	735312510	CIRCLIP		1	1
16	725237051	SCREW		1	18
17	503200712	SCREW IHSCFM		1	18
18	574306901	CLAMP	Captive screws	1	
20	537333701	GEAR HOUSING		1	

H3 327LS COVERS





REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	505142001	FILTER COVER		1	
2	505142201	COVER		1	
3	574477003	SCREW IHSCFMO		4	
4	503213512	SCREW CCRPANT		2	
5	502481601	ARM PROTECTION		1	
6	544848102	HEAT PROTECTOR		1	
7	574181501	SCREW IHSCFMO		1	
8	503222401	LOCK NUT		1	
10	574477003	SCREW IHSCFMO		1	
11	503961301	SCREW		1	
12	740420600	O-RING		1	
13	740420600	O-RING		2	
14	503961301	SCREW		1	
15	502481501	COVER		1	
16	505141802	CYLINDER COVER ASSY		1	
17	505271001	FILTER		1	
18	537387201	SNAP LOCKING		2	

H3 327LS COVERS




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	505142001	FILTER COVER		1	
2	505142201	COVER		1	
3	503200316	SCREW IHSCFM	M5x16	4	
4	503213512	SCREW CCRPANT		2	
5	502481601	ARM PROTECTION		1	
6	544848101	HEAT PROTECTOR		1	
7	503216820	SCREW IHSCFT		1	
8	503222401	LOCK NUT		1	
10	503200316	SCREW IHSCFM	M5x16	1	
11	503961301	SCREW		1	
12	740420600	O-RING		1	
13	740420600	O-RING		1	
14	503961301	SCREW		1	
15	502481501	COVER		1	
16	505141802	CYLINDER COVER ASSY		1	
17	505271001	FILTER		1	
18	537387201	SNAP LOCKING		2	

P 327LS, LX, LDX, RX, RDX, RJX, 323RII
CRANK CASE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	537309601	SLEEVE		1	
2	503216825	SCREW IHSCFT		1	1
3	503216825	SCREW IHSCFT		1	1
4	537041209	CLUTCH COVER		1	
5	537425001	PROTECTIVE PLATE		1	4
6	503200316	SCREW IHSCFM	M5x16	1	4
7	537073601	SPRING		1	
8	503250501	BALL BEARING		1	4
9	537336701	CIRCLIP		1	4
10	537085202	CRANKCASE		1	
11	503200316	SCREW IHSCFM	M5x16	1	10
12	537066901	GASKET		1	10
13	537088501	GASKET		1	10
14	537066801	INSERT CRANKCASE		1	10
15	503200316	SCREW IHSCFM	M5x16	1	10
16	503200316	SCREW IHSCFM	M5x16	1	10
17	503216618	SCREW IHST		1	10
18	503200316	SCREW IHSCFM	M5x16	1	10
19	503216618	SCREW IHST		1	10
20	503200316	SCREW IHSCFM	M5x16	1	10
21	503217716	SCREW IHST		1	10
22	503201412	SCREW IHSCFMO	M5x12	1	10
23	503200316	SCREW IHSCFM	M5x16	1	10

Q 327LS, LX, LDX, RX, RDX, RJX, 323RII
CRANK SHAFT




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	503852474	CRANKSHAFT ASSY		1	
2	503940203	BEARING CAGE		2	1
3	503940501	CUP		2	1
4	503712201	BEARING		1	1

N 327LS, LX, LDX, RX, RDX, RJX, 323R11
CYLINDER PISTON & MUFFLER




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	537221704	MUFFLER ASSY	Cat.	1	
2	537221801	SPARK ARRESTER SCREEN		1	1
3	537014101	GASKET		1	
4	502078101	SCREW EHIHFH		3	
5	537085103	CYLINDER	Ø=34mm	1	
6	503200735	SCREW IHSCFM		4	5
7	537405902	PISTON		1	5
8	537406201	PISTON RING		1	7
9	737440800	CIRCLIP		1	7
10	503712201	BEARING		1	7

L 327LS, LX, LDX, RX, RDX, RJX, 323RII
FUEL TANK




G 327LS, Lx, LDx, RJx
THROTTLE CONTROLS




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	544143604	CONTROL		1	
2	537419001	SWITCH		1	1
3	503216618	SCREW IHSCT		5	1
4	544100202	HANDLE HALF		1	1
5	503878001	THROTTLE LOCKOUT		1	1
6	503918101	THROTTLE LEVER		1	1
7	503961401	ABSORBER		1	1
8	544100302	HANDLE HALF		1	1
9	544100801	RECOIL SPRING		1	1
10	503877903	THROTTLE TRIGGER		1	1
11	544101702	DAMPER		1	1
12	731231401	HEXAGON NUT		1	1
13	544112101	RETAINER		1	1
14	503200320	SCREW IHSCFM		1	1
15	544101702	DAMPER		1	1
16	502651301	WIRING		1	1
17	502531601	SHORT CIRCUIT CABLE		1	1,16
18	544171703	THROTTLE CABLE ASSY		1	1,16

T Duo Balance
HARNESS




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	537275701	HARNESS		1	
1	537275703	HARNESS	US	1	1
2	503996101	BAND		3	1
3	503996103	BAND		1	1
4	537113501	RETAINER		1	1
5	537288401	BUCKLE		1	1
6	537288301	BUCKLE		1	1
7	537275901	HIP PAD		1	1
8	502022801	HOOK		1	1
9	502023002	LOCK		1	1.8
10	502023801	SPRING		1	1.8
11	502022902	HOOK		1	1.8
12	735310920	E-CLIP		1	1.8
13	537175401	HIP PAD		3	1

K6 327LS STARTER




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	503873305	STARTER PAWL		1	
2	735310820	E-CLIP		2	1
3	503873601	SPRING		1	1
4	503873502	STARTER PAWL		2	1
5	505198301	STARTER ASSY		1	
6	503218876	SCREW IHSCST		1	5
7	537332303	STARTER PULLEY		1	5
8	537379302	SPACING SLEEVE		2	5
9	505305125	STARTER ROPE		1	5
10	537008401	STARTER HANDLE		1	5
11	505141301	STARTER ASSY		1	5
12	537379302	SPACING SLEEVE		3	5
13	503200316	SCREW IHSCFM	M5x16	3	
15	503216618	SCREW IHSCST		2	
16	503201412	SCREW IHSCFMO	M5x12	1	
17	537034101	PROTECTIVE PLATE		1	
18	505141601	BRACKET		1	5
19	574477003	SCREW IHSCFMO	Captive screws	2	5
20	503215316	SCREW ITXSCM		1	5
21	537322410	LABEL		1	
22	537325003	STARTER PULLEY		1	5
23	503859901	RECOIL SPRING		1	5

S2 327LX, LDX, RX, RDX, RJX, 323R11, 327LS
ACCESSORIES






REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	502285901	STOP		1	
2	502114602	SOCKET WRENCH		1	
3	501600203	SCREWDRIVER		1	
4	502215801	WRENCH		1	
5	531009248	FILTER OIL		1	
6	501691701	COMBINATION WRENCH		1	
7	503976401	GREASE		1	
8	537353601	LOOP		1	
9	537130402	KNOB		1	
10	537350101	LOOP		1	
11	725233151	SCREW		1	
12	537312901	TRANSPORT GUARD	200-275 mm	1	
13	537216201	HARNESS		1	
13	537216202	HARNESS	USA	1	
14	537216301	HARNESS		1	
14	537216302	HARNESS	USA	1	
15	503734001	FRONT PIECE		1	14
16	503734102	BUCKLE		1	14
17	502022802	WELT HOOK		1	14

H4 327LS COVERS




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	505142001	FILTER COVER		1	
2	505142201	COVER		1	
3	574477003	SCREW IHSCFMO	Captive screws	4	16
4	503213512	SCREW CCRPANT		2	
5	502481601	ARM PROTECTION		1	
6	544848102	HEAT PROTECTOR	Captive screws	1	
7	574181501	SCREW IHSCFMO	Captive screws	1	6
8	503222401	LOCK NUT		1	
10	574477003	SCREW IHSCFMO	Captive screws	1	6
11	503961301	SCREW		1	
12	740420600	O-RING		1	
13	740420600	O-RING		1	
14	503961301	SCREW		1	
15	502481501	COVER		1	
16	505141802	CYLINDER COVER ASSY	Captive screws	1	
17	505271001	FILTER		1	
18	537387201	SNAP LOCKING		2	

B 327LX, RJX
SHAFT & HANDLE



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	503997801	HANDLE	RJx	1	
1	503997804	HANDLE	Captive screws	1	
2	503888801	TUBE	L=1483mm Ø=24mm	1	
2	540053801	TUBE DRIVESHAFT ASSY	RJx L=1483mm Ø=24mm France	1	
3	725237851	SCREW EHHM	L. LS. M6X40	1	
3	725238051	SCREW EHHM	Lx. RJxM6X50	1	
4	503879001	KNOB	Lx	1	
5	503230061	WASHER	L. LS	1	
6	503871903	HANDLE		1	
6	503871908	HANDLE	Captive screws	1	
7	503940301	DISTANCE		1	
8	503200716	SCREW IHSCFM	RJx	1	
9	503941001	HOOK	RJx	1	
10	731231401	HEXAGON NUT	RJx	1	
11	503216816	SCREW IHSCFT	RJx	3	
11	574181501	SCREW IHSCFTO	Captive screws	3	
12	502197101	SQUARE NUT		1	
13	537234801	DRIVE SHAFT	L=1525mm Ø=7mm	1	
14	735311200	CIRCLIP		1	
15	537237501	CLUTCH DRUM ASSY		1	
16	537294801	LABEL		1	
17	503795601	LABEL		1	
18	537101001	LABEL	RJx	1	
19	537085501	HANDLE	France	1	

K5 327LS STARTER



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	503873305	STARTER PAWL		1	
2	735310820	E-CLIP		2	1
3	503873601	SPRING		1	1
4	503873502	STARTER PAWL		2	1
5	505198301	STARTER ASSY		1	
6	503217716	SCREW IH SCT		1	5
7	537332303	STARTER PULLEY		1	5
8	537379302	SPACING SLEEVE		2	5
9	505305125	STARTER ROPE		1	5
10	537008401	STARTER HANDLE		1	5
11	505141301	STARTER ASSY		1	5
12	537379302	SPACING SLEEVE		3	5
13	503200316	SCREW IHSCFM	M5x16	3	
14	503216618	SCREW IH SCT		1	
15	503216618	SCREW IH SCT		1	
16	503201412	SCREW IHSCFMO	M5x12	1	
17	537034101	PROTECTIVE PLATE		1	
18	505141601	BRACKET		1	
19	503200316	SCREW IHSCFM	M5x16	2	
20	503215316	SCREW ITXSCM		1	
21	537322410	LABEL		1	
	PART NO.		REMARK		KIT