

LT120, HCLT120A, 954140047 1998-01


---

# **SPARE PARTS LIST**

# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47

## ELECTRICAL




---

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532144925	BATTERY		1	
2	874760412	BOLT		1	
3	819091016	WASHER		1	
4	810040400	WASHER		1	
6	873220400	NUT		1	
8	532156417	BOX		1	
16	532153664	SWITCH		1	
19	810090400	WASHER		1	
20	873350400	NUT		1	
21	532136850	HARNESS		1	
22	532004152	BULB		1	
24	532124780	CABLE		1	
25	532146147	CABLE		1	
26	532108824	FUSE		1	
28	532124773	CABLE		1	
29	532121305	SWITCH		1	
30	532140301	SWITCH		1	
31	532124211	NUT		1	
32	532141226	COVER		1	
33	532122147	KEY		1	
40	532156442	CABLE ASSY		1	
41	871110408	BOLT		1	
42	532131563	COVER		1	
43	532145673	SOLENOID		1	
44	873640400	NUT		1	
48	532140844	ADAPTER		1	
52	532141940	WIRE		1	
70	532140413	HARNESS		1	

# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47

## DRIVE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
2	532146682	SPRING		1	
3	532123666	PULLEY		1	
4	812000028	CLIP		1	
5	532121520	BRACKET		1	
6	817490512	SCREW		1	
7	532162240	BRACKET		1	
8	532131679	LEVER		1	
10	876020416	SPLIT PIN		1	
11	532105701	WASHER		1	
12	819151216	WASHER		1	
13	874550412	BOLT		1	
14	810040400	WASHER		1	
15	874490544	SCREW		1	
18	874780616	BOLT		1	
19	873800600	NUT		1	
21	532121274	KNOB		1	
22	532130804	ROD		1	
24	873350600	NUT		1	
25	532106888	SPRING		1	
26	819131316	WASHER		1	
27	876020412	SPLIT PIN		1	
28	532145204	ROD		1	
29	532071673	COVER		1	
30	532130807	BRACKET		1	
31	532127275	GUIDE		1	
32	874760512	BOLT		1	
34	532155071	SHAFT		1	
35	532120183	BEARING		1	
36	819211616	WASHER		1	
37	532124963	PIN RETAINING SCREW		1	
39	874760644	BOLT		1	
40	532124965	SPACER		1	
41	532154777	TENSIONER		1	
42	819131312	WASHER		1	
47	532127783	PULLEY		1	
48	532154407	GUIDE		1	
49	532123205	BELT GUIDE		1	
50	874760624	BOLT		1	
51	873680600	NUT		1	
52	873680500	NUT		1	
53	532105710	LINK		1	
55	532105709	SPRING		1	
56	874760620	BOLT		1	
57	532130801	V-BELT		1	
58	532127274	KEEPER		1	
59	532140312	BELT GUIDE		1	
61	817490612	SCREW		1	
62	532124872	PEDAL RUBBER		1	
63	532140186	PULLEY		1	
64	871170764	BOLT		1	
65	810040700	WASHER		1	
66	532154778	TENSIONER		1	
70	532134683	BELT GUIDE		1	
72	819132012	WASHER		1	
74	532109502	SPACER		1	
75	532121749	WASHER		1	
76	812000001	RETAINER RING		1	
77	532123583	KEY		1	
78	532121748	WASHER		1	
112	819091210	WASHER		1	
116	872110610	BOLT		1	
148	532159103	GUIDE		1	
149	532122052	SPACER		1	
150	532150935	BUSHING		1	
151	819133210	WASHER		1	

# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47


## ENGINE



29

**OPTIONAL EQUIPMENT**

**Spark Arrester**



---


REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532140310	CONTROL		1	
2	817720410	SCREW		1	
4	532137348	MUFFLER, CPL.		1	
13	532272293	GASKET		1	
14	813280324	PIPE		1	
15	813200300	ELBOW		1	
16	811050600	WASHER		1	
23	532159880	PROTECTOR		1	
29	532137180	SPARK ARRESTER KIT		1	
31	532109202	TANK		1	
32	532140527	FUEL CAP		1	
33	532123487	HOSE CLAMP		1	
35	817490512	SCREW		1	
37	532137040	HOSE		1	
40	532124028	BUSHING		1	
44	817490412	SCREW		1	
46	819091416	WASHER		1	
62	810040500	WASHER		1	
72	871070512	BOLT		1	
78	817490620	SCREW		1	
81	532128861	NUT		1	



# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47

## DECALS




---

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532101892	DECAL		1	
3	532272440	DECAL		1	
5	532159713	DECAL		1	
6	532157140	DECAL		1	
8	532150617	DECAL		1	
10	532137259	DECAL		1	
15	532145005	DECAL		1	
16	532157163	LABEL		1	
17	532136832	DECAL		1	
--	532138311	DECAL		1	
--	LSB42			1	
--	LBD48	SNOW BLADE		1	
--	LC05	WHEEL WEIGHTS (PAIR)		1	

## REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47

### WHEELS & TIRES




---

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532059192	CAP VALVE		1	
2	532065139	NIPPLE		1	
3	532106222	TIRE		1	
4	532059904	HOSE		1	
5	532141446	RIM SPROCKET		1	
6	532124957	FITTING		1	
7	532124959	BEARING		1	
8	532141447	RIM SPROCKET		1	
9	532124635	TIRE		1	
10	532124926	HOSE		1	
11	532104757	HUB CAP		1	
--	532144334	SEALING FOAM		1	

# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 1400-47  
DANA TRANSAXLE - MODEL NUMBER 4360-112




---

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
11	134793	BEILAGSCHEIBENSATZ LR120		1	
12	148268	FLANGE		1	
14	142674	WEDGE		1	
15	138234	SHAFT		1	
22	138236	ZIEHKEIL 1PAAR		1	
24	142676	GETRIEBEWELLE LR120		1	
29	142677	GEAR WHEEL		1	
33	134796	GEAR WHEEL		1	
34	134797	SPACING BLOCK		1	
43	134394	BEILAGSCHEIBENSATZ LR120		1	
45	142678	GEAR WHEEL		1	
52	134401	SEALING RING		1	
61	142680	GETRIEBEGEH[USEUNTERTEIL LR120		1	

# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47

## SEAT ASSEMBLY



---


REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532127426	SEAT		1	
2	532140551	BRACKET		1	
3	874760616	BOLT		1	
4	819131610	WASHER		1	
5	532145006	CLIP		1	
6	873800600	NUT		1	
7	532124181	SPRING		1	
8	817490616	SCREW		1	
9	819131614	WASHER		1	
10	532155925	BRACKET		1	
12	532121246	BRACKET		1	
13	532121248	BUSHING		1	
14	872050412	BOLT		1	
15	532134300	SPACER		1	
16	532121250	SPRING		1	
17	532123976	LOCKNUT		1	
21	532153236	SCREW		1	
22	873800500	LOCK NUT		1	
23	874780814	BOLT		1	
24	819171912	WASHER		1	
25	532127018	BOLT		1	
26	810040800	WASHER		1	



# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47

## MOWER LIFT




---

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532159460	WIRE		1	
2	532159471	LEVER		1	
3	532105767	PIN RETAINING SCREW		1	
4	812000002	RETAINER RING		1	
5	819211621	WASHER		1	
6	532120183	BEARING		1	
7	532109413	GRIP		1	
8	532124526	KNOB		1	
11	532139865	LINK		1	
12	532139866	LINK		1	
13	532124670	RETAINER RING		1	
15	532127218	LINK		1	
16	873350800	NUT		1	
17	532130171	BRACKET		1	
18	873800800	NUT		1	
19	532139868	LEVER		1	
20	532124660	CIRCLIP		1	
31	532140302	BEARING		1	
32	873540600	NUT		1	

# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47

## MOWER DECK




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532142829	CUTTER DECK		1	
2	872140506	BOLT		1	
3	532138017	BRACKE		1	
4	532138440	BRACKET		1	
5	532124670	RETAINER RING		1	
6	532130832	LEVER		1	
8	532850857	BOLT		1	
9	810030600	WASHER		1	
10	532140296	WASHER		1	
11	532134148	RIDE ON BLADE		1	
12	532129895	BEARING		1	
13	532137645	SHAFT		1	
14	532128774	BEARING HOUSING		1	
15	532110485	BEARING		1	
16	532140329	STRIPPER		1	
19	532132827	SPEC. BOLT		1	
21	873680500	NUT		1	
23	532137607	BRACKET		1	
24	532105304	HUB CAP		1	
25	532123713	SPRING		1	
26	532110452	NUT		1	
27	532106736	DEFLECTOR		1	
28	819111016	WASHER		1	
29	532106735	ROD		1	
30	532157722	SCREW		1	
31	532129963	WASHER		1	
32	532153532	PULLEY		1	
36	532131494	PULLEY		1	
40	873680600	NUT		1	
41	532133551	LINK		1	
43	532133504	LINK		1	
45	532124788	RETAINER RING		1	
53	532130840	BRAKE LEVER		1	
54	532133943	WASHER		1	
55	532133840	LEVER		1	
56	532122052	SPACER		1	
67	532162132	KNOB		1	
68	532144200	BELT		1	
69	876020312	SPLIT PIN		1	
71	532142427	ROD		1	
72	532131870	SPRING		1	
73	532127847	LEVER		1	
74	532121748	WASHER		1	
75	812000029	RETAINER RING		1	
76	532128903	BOLT		1	
77	532127845	BRACKET		1	
78	532160570	LEVER		1	
79	532127498	BUSHING		1	
80	532153701	SPRING		1	
81	873350600	NUT		1	
82	532142028	BRACKET		1	
86	532125074	RUNNER L/H		1	
87	532128772	SUPPORT		1	
88	819111216	WASHER		1	
89	819131612	WASHER		1	
92	873800600	NUT		1	
107	532133502	SPACER		1	
108	532133503	LEVER		1	
109	874760640	BOLT		1	
110	532142587	UPSTOP DECK FRONT 38"		1	
113	817490512	SCREW		1	
122	532131289	BRAKE LEVER		1	
123	532131288	BRAKE LEVER		1	
124	872110614	BOLT		1	
128	532153390	GASKET		1	
141	532124931	WASHER		1	
--	532142820	SHEARING UNIT		1	
--	532130794	MANDREL		1	

# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47


## STEERING ASSEMBLY



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532140044	STEERING WHEEL		1	
2	532154427	SHAFT		1	
3	532156483	SPINDLE		1	
4	532157473	SPINDLE		1	
5	532124931	WASHER		1	
6	532121748	WASHER		1	
7	819272016	WASHER		1	
8	812000029	RETAINER RING		1	
9	532124937	BEARING COL. STRG.		1	
10	532156438	LINK		1	
11	810040600	WASHER		1	
13	532154779	SPACER		1	
15	873901000	NUT		1	
17	532156546	SHAFT		1	
18	532057079	WASHER		1	
19	532124035	BRACKET		1	
20	532126684	SHIM		1	
22	871200410	SCREW		1	
23	532127501	SHAFT		1	
25	532154406	BRACKET		1	
26	532126847	BUSHING		1	
27	532136874	ECCENTRIC DISC		1	
28	819131416	WASHER		1	
29	817490612	SCREW		1	
30	876020412	SPLIT PIN		1	
32	532130465	ROD		1	
36	532155099	BUSHING		1	
37	532152927	SCREW		1	
38	532140045	INSERT		1	
39	819133808	WASHER		1	
40	532124701	NUT		1	
41	532100711	ADAPTER		1	
42	532145054	SLEEVE		1	
43	532121749	WASHER		1	
44	532153720	STEERING PINION		1	
46	532121232	HUB CAP		1	
47	532124836	NIPPLE		1	
51	873800500	LOCK NUT		1	
54	874780520	BOLT		1	
62	532156594	STEERING GEAR, KIT		1	
63	874780616	BOLT		1	
65	532154780	BUSHING		1	
66	532154404	BUSHING		1	
67	874781044	SCREW		1	
68	532154429	SHAFT		1	

# REPAIR PARTS

TRACTOR - MODEL NO. LT120 (HCLT120A), PRODUCT NO. 954 14 00-47  
CHASSIS AND ENCLOSURES



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
2	532140356	DRAWBAR		1	
3	817490612	SCREW		1	
4	819131216	WASHER		1	
5	532155272	DAMPER		1	
8	532155138	CLIP		1	
9	532162717	REPLACE PAR 532161937011		1	
10	872140608	BOLT		1	
11	532155927	PLATE		1	
12	532145660	CLIP		1	
13	532157262	PLATE		1	
14	817490608	SCREW		1	
15	874180512	SCREW		1	
16	873510500	NUT		1	
17	532162237	HOOD		1	
18	532126938	DAMPER		1	
24	874780616	BOLT		1	
25	819131312	WASHER		1	
26	873800600	NUT		1	
28	532157373	GRILL		1	
29	532140273	LENS		1	
31	532136619	ROD		1	
35	872110606	BOLT		1	
37	817490508	SCREW		1	
38	532139886	BRACKET		1	
39	532139887	BRACKET		1	
51	873800400	NUT		1	
52	819091416	WASHER		1	
53	532144697	BRACKET		1	
54	817030814	SCREW		1	
55	532144696	BRACKET		1	
57	874780412	BOLT		1	
58	532150127	AIR CONDUCTOR		1	
140	532158418	BRACKET		1	
145	532156524	SHAFT		1	
--	532005479	PLUG		1	