



Operator's manual
Automower® Connect

Read the operator's manual carefully and make sure that you understand the instructions before you use the product.



EN, English

Contents

1 Introduction.....	2	4 Operation.....	3
2 Getting started.....	2	5 Technical data.....	4
3 Settings.....	3		

1 Introduction

1.1 Description

Automower® Connect brings the menu system to your mobile device, making it easy to read and change the product settings remotely. Through this application, you can receive the current status of the product and send commands to the product from anywhere in

the world. In case of theft, you get an alarm and can monitor the position of the product.

1.2 Installation

The Automower® Connect accessory must be installed by a dealer. The installation includes a software update of the product.

2 Getting started

You can communicate with your product through the mobile application Automower® Connect. With Automower® Connect activated, new symbols will show on the display of the product.

Note: All countries do not support Automower® Connect because of legal reasons and regional specified cellular systems. The included Automower® Connect lifetime service only applies if there is a third part sub-supplier of 2G/3G/4G available in the operational area. In some countries Bluetooth® is not available due to legal reasons.

2.1 Download the Automower® Connect app

Download the Automower® Connect app from App Store or Google Play to your mobile device.

2.2 Create an Automower® Connect account

When you have downloaded the app, you can enter your e-mail address and a password to

make an Automower® Connect account. You will receive a validation e-mail to your e-mail address. Follow the instructions in the e-mail in less than 24 hours to validate your account. If not validated in less than 24 hours, you must make a account again. You can pair the product and your mobile device when the account has been made in the app.

2.3 Pair with Automower® Connect

1. Start the app on your mobile device and log in to your account.
2. Select *Menu > My mowers*.
3. Push + to add a new product. Follow the instructions in the app.
4. Select *Menu > Accessories > Automower® Connect*.
5. Enter the PIN code.
6. Select *Pairing > New pairing* in the menu of the product.
7. Enter the 6-digit code shown on the display of the product.

3 Settings

Display and change the settings of the product from everywhere in the world. For security reasons you must use short-range communication (Bluetooth®) if you change *General* and *Security* settings, or disable the Automower® Connect module on the product.

3.1 To set the GeoFence center

The GeoFence function makes it possible to monitor the product, for example in case of theft. Before GeoFence can be used, its center point and sensitivity must be set. This can only be done from the menu in the product.

1. Put the product in the center of the work area.
2. Select *Accessories > Automower® Connect*.
3. Enter the PIN code.
4. Select *GeoFence*.
5. Select *Activate GeoFence* and push **OK**.
6. Select *New center point* to set the source for GeoFence.

GeoFence sensitivity can be changed. Sensitivity can be set to *Low*, *Medium* or *High*. The higher the sensitivity, the easier the alarm is activated.

Note: When you put the product into storage for a long period, it is recommended to switch off the main switch to save battery power. With the GeoFence function on, a PIN code is necessary to switch off the product. If you switch off the main switch, the Automower® Connect stays on for 12 hours. After that it is not possible to communicate with the product and the GeoFence function is not on.

3.2 Symbols on the display

These symbols are shown on the display of the product when Automower® Connect is enabled.



The signal strength of the GPRS reception.



Problem with the connection to the Internet server.



Problem with the SIM card or the module.

4 Operation

4.1 Main menu

- *Dashboard*: Shows the current status of the product. It shows symbols for the battery status and cutting height.
- *Map*: Shows the current position of the product and the set centerpoint for GeoFence. You can monitor the movement of the product with this function, for example in case of theft.
- *Messages* (only available for Bluetooth® short-range connectivity): In this menu the

fault and information messages can be found. For some of the messages, there is information to help you to correct the fault.

4.2 My mowers

My mowers shows the status of the product, you can remove or add products paired to the account.

5 Technical data

5.1 Technical data

Frequency Band Support	
Automower® Connect 2G	GSM 850 MHz, E-GSM 900 MHz, DCS 1800 MHz, PCS 1900 MHz
Automower® Connect 3G	Band 19 (800 MHz), Band 5 (850 MHz), Band 8 (900 MHz), Band 2 (1900 MHz), Band 1 (2100 MHz)
Automower® Connect 4G	Band 12 (700 MHz), Band 17 (700 MHz), Band 28 (700 MHz), Band 13 (700 MHz), Band 20 (800 MHz), Band 26 (850 MHz), Band 5 (850 MHz), Band 19 (850 MHz), Band 8 (900 MHz), Band 4 (1700 MHz), Band 3 (1800 MHz), Band 2 (1900 MHz), Band 25 (1900 MHz), Band 1 (2100 MHz), Band 39 (1900 MHz)

Power Class		
Automower® Connect 2G	Power Class 4 (for GSM/E-GSM)	33 dBm
	Power Class 1 (for DCS/PCS)	30 dBm
Automower® Connect 3G	Power Class 3	24 dBm
Automower® Connect 4G	Power Class 3	23 dBm



Husqvarna[®]

AUTOMOWER[®] is a trademark owned by Husqvarna AB.
Copyright[®] 2020 HUSQVARNA. All rights reserved.

www.husqvarna.com

Original instructions

1141799-28



2020-01-17