


# **SEARS**

## **OPERATOR'S MANUAL**

**MODEL NO.  
944.10108**

**IMPORTANT:**  
Read and follow  
all Safety Rules  
and Instructions  
Before Operating  
This Equipment



# **CRAFTSMAN®**

**26.0 HP\***  
**ELECTRIC START**  
**54" MOWER**  
**AUTOMATIC TRANSMISSION**  
**GARDEN TRACTOR**

- Assembly**
- Operation**
- Maintenance**
- Service and Adjustments**

\* The power rating as declared by the engine manufacturer is the average gross power output at the specified RPM of a typical production engine for the engine model measured using SAE Standards for engine gross power. Please refer to the engine manufacturer for details.

**Sears Canada, Inc., Toronto, Ontario M5B 2B8**

**115817824 Rev. 1**

**01.12.17 BD**  
Printed in the U.S.A.

# SAFETY RULES

## Safe Operation Practices for Ride-On Mowers

**DANGER: THIS CUTTING MACHINE IS CAPABLE OF AMPUTATING HANDS AND FEET AND THROWING OBJECTS. FAILURE TO OBSERVE THE FOLLOWING SAFETY INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.**



**WARNING:** In order to prevent accidental starting when setting up, transporting, adjusting or making repairs, always disconnect spark plug wire and place wire where it cannot contact spark plug.



**WARNING:** Do not coast down a hill in neutral, you may lose control of the tractor.



**WARNING:** Tow only the attachments that are recommended by and comply with specifications of the manufacturer of your tractor. Use common sense when towing. Operate only at the lowest possible speed when on a slope. Too heavy of a load, while on a slope, is dangerous. Tires can lose traction with the ground and cause you to lose control of your tractor.

### ⚠️ WARNING ⚠️

Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

### ⚠️ WARNING ⚠️

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

## I. CHILDREN



**WARNING! CHILDREN CAN BE INJURED BY THIS EQUIPMENT.** The American Academy of Pediatrics recommends that children be a minimum of 12 year of age before operating a pedestrian controlled lawn mower and a minimum of 16 years of age before operating a riding lawn mower.



**WARNING! CHILDREN CAN BE SERIOUSLY INJURED OR KILLED BY THIS EQUIPMENT.** Carefully read and follow all of the safety instructions below.

Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the machine and the mowing activity. Never assume that children will remain where you last saw them.

- Keep children out of the mowing area and in the watchful care of a responsible adult other than the operator.

- Be alert and turn machine off if a child enters the area.
- Before and while backing, look behind and down for small children.
- Never carry children, even with the blades shut off. They may fall off and be seriously injured or interfere with safe machine operation. Children who have been given rides in the past may suddenly appear in the mowing area for another ride and be run over or backed over by the machine.
- Never allow children to operate the machine.
- Use extreme caution when approaching blind corners, shrubs, trees, or other objects that may block your view of a child.

## II. GENERAL OPERATION

- Read, understand, and follow all instructions on the machine and in the manual before starting.
- Do not put hands or feet near rotating parts or under the machine. Keep clear of the discharge opening at all times.
- Only allow responsible adults, who are familiar with the instructions, to operate the machine.
- Clear the area of objects such as rocks, toys, wire, etc., which could be picked up and thrown by the blades.
- Ensure the area is clear of bystanders before operating. Stop machine if anyone enters the area.
- Never carry passengers.
- Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing.
- Never direct discharged material toward anyone. Avoid discharging material against a wall or obstruction. Material may ricochet back toward the operator. Stop the blades when crossing gravel surfaces.
- Do not operate machine without the entire grass catcher, discharge chute, or other safety devices in place and working.
- Slow down before turning.
- Never leave a running machine unattended. Always turn off blades, set parking brake, stop engine, and remove keys before dismounting.
- Disengage blades when not mowing. Shut off engine and wait for all parts to come to a complete stop before cleaning the machine, removing the grass catcher, or unclogging the discharge chute.
- Operate machine only in daylight or good artificial light.
- Do not operate the machine while under the influence of alcohol or drugs.
- Watch for traffic when operating near or crossing roadways.
- Use extreme caution when loading or unloading the machine into a trailer or truck.
- Always wear eye protection when operating machine.
- Use ear protectors to avoid damage to hearing.
- Data indicates that operators, age 60 years and above, are involved in a large percentage of riding mower-related injuries. These operators should evaluate their ability to operate the riding mower safely enough to protect themselves and others from serious injury.
- Follow the manufacturer's recommendation for wheel weights or counterweights.
- Keep machine free of grass, leaves or other debris build-up which can touch hot exhaust / engine parts and burn. Do not allow the mower deck to plow leaves or other debris which can cause build-up to occur. Clean any oil or fuel spillage before operating or storing the machine. Allow machine to cool before storage.



# SAFETY RULES

## Safe Operation Practices for Ride-On Mowers



### III. SLOPE OPERATION



**WARNING!** When loading or unloading this machine, do not exceed the maximum recommended operation angle of 15°.

Slopes are a major factor related to loss of control and tip-over accidents, which can result in severe injury or death. Operation on all slopes requires extreme caution. If you cannot back up the slope or if you feel uneasy on it, do not mow it.

- Mow up and down slopes, not across.
- Watch for holes, ruts, bumps, rocks, or other hidden objects. Uneven terrain could overturn the machine. Tall grass can hide obstacles.
- Choose a low ground speed so that you will not have to stop or shift while on the slope.
- Do not mow on wet grass. Tires may lose traction. Always keep the machine in gear when going down slopes.
- Do not shift to neutral and coast downhill.
- Avoid starting, stopping, or turning on a slope. If the tires lose traction, disengage the blades and proceed slowly straight down the slope.
- Keep all movement on the slopes slow and gradual. Do not make sudden changes in speed or direction, which could cause the machine to roll over.
- Use extreme caution while operating machine with grass catchers or other attachments; they can affect the stability of the machine. Do no use on steep slopes.
- Do not try to stabilize the machine by putting your foot on the ground.
- Do not mow near drop-offs, ditches, or embankments. The machine could suddenly roll over if a wheel is over the edge or if the edge caves in.
- If machine stops while going uphill, disengage blades, shift into reverse and back down slowly.
- Do not turn on slopes unless necessary, and then, turn slowly and gradually downhill, if possible.



### IV. TOWING

- Tow only with a machine that has a hitch designed for towing. Do not attach towed equipment except at the hitch point.
- Follow the manufacturer's recommendation for weight limits for towed equipment and towing on slopes.
- Never allow children or others in or on towed equipment.
- On slopes, the weight of the towed equipment may cause loss of traction and loss of control.
- Travel slowly and allow extra distance to stop.

### V. SERVICE

#### SAFE HANDLING OF GASOLINE

To avoid personal injury or property damage, use extreme care in handling gasoline. Gasoline is extremely flammable and the vapors are explosive.

- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only approved gasoline container.

- Never remove gas cap or add fuel with the engine running.
- Allow engine to cool before refueling.
- Never fuel the machine indoors.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light such as on a water heater or other appliances.
- Never fill containers inside a vehicle or on a truck or trailer bed with plastic liner. Always place containers on the ground away from your vehicle when filling.
- Remove gas-powered equipment from the truck or trailer and refuel it on the ground. If this is not possible, then refuel such equipment with a portable container, rather than from a gasoline dispenser nozzle.
- Keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete. Do not use a nozzle lock-open device.
- If fuel is spilled on clothing, change clothing immediately.
- Never overfill fuel tank. Replace gas cap and tighten securely.

#### GENERAL SERVICE

- Never operate machine in a closed area.
- Keep all nuts and bolts tight to ensure the equipment is in safe working condition.
- Never tamper with safety devices. Never interfere with the intended function of a safety device or reduce the protection provided by a safety device. Check there proper operation regularly. NEVER operate a machine with a safety device that does not function properly.
- Keep machine free of grass, leaves, or other debris build-up. Clean oil or fuel spillage and remove any fuel-soaked debris. Allow machine to cool before storing.
- If you strike a foreign object, stop and inspect the machine. Repair, if necessary, before restarting.
- Never make any adjustments or repairs with the engine running.
- Check grass catcher components and the discharge chute frequently and replace with manufacturer's recommended parts, when necessary.
- Mower blades are sharp. Wrap the blade or wear gloves, and use extreme caution when servicing them.
- Check brake operation frequently. Adjust and service as required.
- Maintain or replace safety and instruction labels, as necessary.



Use ear protectors to avoid damage to hearing.



Always wear eye protection when operating machine.

## PRODUCT SPECIFICATIONS

|   |  |
|---|--|
| Gasoline Capacity and type:   | 4 Gallons/15,14 L<br>Regular Unleaded *  |
| Oil Type:<br>(API: SJ-SN)   | SAE 10W30 (above 32°F/0°C)<br>SAE 5W30 (below 32°F/0°C)<br>SYNTHETIC (below 0°F/-18°C) |
| Your tractor was shipped from the factory with non-synthetic SAE 10W30 motor oil. |  |
| Oil Capacity:   | 64 Oz./1,89 L  |
| Spark Plug:   | Champion 25 132 13<br>(Gap: .030"/0,76 mm)   |
| Charging System:  | 15 Amps @3600 RPM  |
| Battery:  | Amp/Hr: 28<br>Min. CCA: 230<br>Case size: U1R  |
| Blade Bolt Torque:  | 45-55 Ft. Lbs./62-75 Nm  |

\* Gasoline containing up to 10% ethanol (E10) is acceptable for use in this machine. The use of any gasoline exceeding 10% ethanol (E10) will void the product warranty.

**CONGRATULATIONS** on your purchase of a new tractor. It has been designed, engineered and manufactured to give you the best possible dependability and performance. Should you experience any problem you cannot easily remedy, please contact your nearest authorized service center/department. We have competent, well-trained technicians and the proper tools to service or repair this tractor. Please read and retain this manual. The instructions will enable you to assemble and maintain your tractor properly. Always observe the "SAFETY RULES".

## REPAIR AGREEMENT

A Repair Agreement is available on this product. Contact your nearest Sears store for details.

## CUSTOMER RESPONSIBILITIES

- Read and observe the safety rules.
- Follow a regular schedule in maintaining, caring for and using your tractor.
- Follow the instructions in the Maintenance and Storage sections of this manual.
- Wear proper Personal Protective Equipment (PPE) while operating this machine, including (at a minimum) sturdy footwear, eye protection, and hearing protection. Do not mow in shorts and/or open toed footwear.
- Always let someone know you are outside mowing.

**WARNING:** This tractor is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator.

In the state of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester for the muffler is available through your nearest authorized service center/department .

## TABLE OF CONTENTS

|                                |       |
|--------------------------------|-------|
| SAFETY RULES .....             | 2-3   |
| PRODUCT SPECIFICATIONS.....    | 4     |
| CUSTOMER RESPONSIBILITIES..... | 4     |
| ASSEMBLY .....                 | 5-9   |
| OPERATION .....                | 10-17 |
| MAINTENANCE SCHEDULE .....     | 18    |
| MAINTENANCE .....              | 18-22 |
| SERVICE AND ADJUSTMENTS .....  | 23-27 |
| STORAGE.....                   | 28    |
| TROUBLESHOOTING .....          | 29-30 |
| WARRANTY.....                  | 32    |
| SEARS SERVICE .....            | 34    |

# UNASSEMBLED PARTS

|   |   |
|---|---|
| <p><b>Mower</b></p> <p>(5) 1-3/16 O.D. Washers</p> <p>(1) Small Retainer Springs</p> <p>(5) Large Retainer Springs</p> <p>(2) Rear Lift Link Assemblies</p> <p>(1) Front Lift Link Assembly</p> | <p><b>Mower Front Wheel</b></p> <p>(1) Shoulder Bolt</p> <p>(1) Wheel</p> <p>(1) 1-1/4 O.D. Washer</p>      |
| <p><b>If Equipped</b></p> <p>(1) Anti-Sway Bar</p> <p>(1) Small Retainer Springs</p> <p>(1) 3/4 O.D. Washers</p>  | <p><b>Quick Connect</b></p> <p>(1) Oil Drain Tube</p> <p>Keys</p> <p>(2) Keys</p> <p><b>Slope Sheet</b></p> |

# ASSEMBLY

Your new tractor has been assembled at the factory with exception of those parts left unassembled for shipping purposes. To ensure safe and proper operation of your tractor all parts and hardware you assemble must be tightened securely. Use the correct tools as necessary to ensure proper tightness.

## TOOLS REQUIRED FOR ASSEMBLY

A socket wrench set will make assembly easier. Standard wrench sizes are listed.

|                                 |                     |
|---------------------------------|---------------------|
| (2) 7/16" wrenches              | Utility knife       |
| (1) 1/2" wrench                 | Tire pressure gauge |
| (1) 3/4" wrench                 | Pliers              |
| (1) 3/4" socket w/drive ratchet |                     |
| (1) 9/16" wrench                | Flashlight          |

When right or left hand is mentioned in this manual, it means when you are in the operating position (seated behind the steering wheel).

## TO REMOVE TRACTOR FROM CARTON UNPACK CARTON

- Remove all accessible loose parts and parts cartons from carton .
- Cut along dotted lines on all four panels of carton. Remove end panels and lay side panels flat.
- Check for any additional loose parts or cartons and remove.

## BEFORE REMOVING TRACTOR FROM SKID

# ASSEMBLY

## CONNECT BATTERY (See Fig. 1)



**WARNING:** Do not short battery terminals by allowing a wrench or any other object to contact both terminals at the same time. Before connecting battery, remove metal bracelets, wristwatch bands, rings, etc. Positive terminal must be connected first to prevent sparking from accidental grounding.

**NOTE:** If this battery is put into service after month and year indicated on label (label is located between terminals) charge battery for minimum of one hour at 6-10 amps. (See "BATTERY" in the Maintenance section of this manual for charging instructions.)

- Determine battery location. Battery location will be under the seat or the hood.
- Lift seat pan or hood to raised position.
- Remove two terminal caps and discard.
- First connect RED battery cable to positive (+) terminal with bolt and nut as shown. Tighten securely. Slide terminal cover over terminal.
- Connect BLACK grounding cable to negative (-) terminal with remaining bolt and nut. Tighten securely.
- Lower seat pan or hood.

**NOTE:** For battery installation see "REPLACING BATTERY" in the Service and Adjustments section in this manual.




Fig. 1

## ADJUST SEAT (See Fig. 2)

- Sit in seat.
- Lift up adjustment lever (A) and slide seat until a comfortable position is reached which allows you to press clutch/brake pedal all the way down.
- Release lever to lock seat in position.




Fig. 2

**NOTE:** You may now roll your tractor off the skid. Continue using the instructions that follow to remove the tractor from the skid.

**WARNING:** Before starting, read, understand and follow all instructions in the Operation section of this manual. Ensure tractor is in a well-ventilated area. Ensure the area in front of tractor is clear of other people and objects.

## TO ROLL TRACTOR OFF SKID (See Operation section for location and function of controls)

- Raise attachment lift lever to its highest position.
- Release parking brake by depressing clutch/brake pedal.
- Place freewheel control in "TRANSMISSION DISENGAGED" position. (See "TO TRANSPORT" in the Operation section of this manual.)
- Roll tractor forward off skid.

Continue with the instructions that follow.

## TO INSTALL MOWER AND DRIVE BELT (See Figs. 3 - 15)

### 1. SET PARKING BRAKE LEVER AND LOWER ATTACHMENT LIFT LEVER (See Fig. 3 & 4)

- Depress clutch/brake pedal all the way down and hold.
- Pull parking brake lever up and hold, release pressure from clutch/brake pedal, then release parking brake lever. Pedal should remain in brake position. Ensure parking brake will hold tractor secure.



Fig. 3



**CAUTION:** Lift lever is spring loaded. Have a tight grip on lift lever, lower it slowly and engage in lowest position. Lift lever is located on left side of fender.

# ASSEMBLY





Fig. 4

## 2. ASSEMBLE FRONT GAUGE WHEEL (W) TO FRONT OF MOWER (See Fig. 5)



- H. FRONT MOWER BRACKET
- W. FRONT GAUGE WHEEL
- X. SHOULDER BOLT
- Y. 1-1/4 O.D. WASHER
- Z. 3/8-16 LOCKNUT

Fig. 5

## 3. TURN STEERING WHEEL LEFT AND POSITION MOWER (See Fig. 6)

- Turn steering wheel to the left as far as it will go and position mower on right side of tractor with deflector shield (Q) to the right.




Fig. 6

## 4. SLIDE MOWER UNDER TRACTOR (See Fig. 8)

- Bring belt forward and check belt for proper routing in all mower pulley grooves.

**NOTE:** Be sure mower side suspension arms (A) are pointing forward before sliding mower under tractor.

- Slide mower under tractor until it is centered under tractor.




Fig. 8

## 5. INSTALL ANTI-SWAY BAR (S) (IF EQUIPPED) (See Fig. 9 - 11)





Fig. 9

- From right side of mower, first insert 90° end of anti-sway bar (S) into hole in transaxle bracket (T), located near left rear tire in front of transaxle.


**NOTE:** Flashlight may be helpful.



- A. MOWER SIDE SUSPENSION ARMS
- B. RETAINER SPRING
- C. REAR LIFT LINK(S)
- D. RIGHT SIDE REAR MOWER BRACKET
- E. FRONT LIFT LINK ASSEMBLY
- F. FRONT SUSPENSION BRACKET
- H. FRONT MOWER BRACKET
- I. LEFT SIDE REAR MOWER BRACKET
- K. BELT TENSION ROD
- L. LOCKING BRACKET
- M. ENGINE CLUTCH PULLEY
- Q. DEFLECTOR SHIELD
- S. ANTI-SWAY BAR
- W. FRONT GAUGE WHEEL

Fig. 7


# ASSEMBLY



**Fig. 10**

**NOTE:** Depending on model, bracket (T) may be different than shown but hole for anti-sway bar will be in same position/location.


- Pivot the integrated washer end of anti-sway bar (S) towards mower deck bracket on right side of mower. Insert integrated washer end of bar into hole in rear mower bracket (D). Move mower as needed to insert integrated washer end of bar into rear mower bracket (D).
- Secure with small washer and small retainer spring as shown.



**Fig. 11**

## 6. ATTACH MOWER SIDE SUSPENSION ARMS (A) TO CHASSIS (See Fig. 12)


- Position front hole in side suspension arm (A) over pin on outside of tractor chassis and secure with large washer and large retainer spring (B).
- Repeat on opposite side of tractor.



**Fig. 12**

## 7. ATTACH REAR LIFT LINKS (C) (See Fig. 13)

- Insert rod end of rear lift link (C) into hole (U) in tractor lift shaft suspension arm and pivot link down to mower.
- Lift rear corner of mower and position slot in link assembly over pin on rear mower bracket (D) and secure with large washer and large retainer spring.
- Repeat on opposite side of tractor.




**Fig. 13**

## 8 ATTACH FRONT LINK (E) (See Fig. 14)

- Turn steering wheel to position wheels straight forward.
- From front of tractor, insert rod end of front link (E) through front hole in tractor front suspension bracket (F).
- Move to left side of mower and insert large retainer spring (G) through hole in front link (E) behind front suspension bracket (F).
- Insert other end of link (E) into hole in front mower bracket (H) and secure with washer and small retainer spring (J).

**NOTE:** Requires deck lifting.



**Fig. 14**

# ASSEMBLY

## 9 INSTALL BELT ON ENGINE CLUTCH PULLEY (M) (See Fig. 15 & 7)

- Disengage belt tension rod (K) from locking bracket (L).
- Install belt onto engine clutch pulley (M).




Fig. 15

**IMPORTANT:** Check belt for proper routing in all mower pulley grooves and under mandrel covers.

- Engage belt tension rod (K) on locking bracket (L).



**CAUTION: Belt tension rod is spring loaded.  
Have a tight grip on rod and engage slowly.**

- Raise attachment lift lever to highest position.
- If necessary, adjust gauge wheels before operating mower as shown in the Operation section of this manual.

## MOWER DRIVE BELT INSTALLATION

Follow procedure described in "TO REPLACE MOWER BLADE DRIVE BELT" in the "Service and Adjustments" section of this manual.

## CHECK TIRE PRESSURE

The tires on your tractor were overinflated at the factory for shipping purposes. Correct tire pressure is important for best cutting performance.

- Reduce tire pressure to PSI shown on tires.

## CHECK DECK LEVELNESS

For best cutting results, mower housing should be properly leveled. See "TO LEVEL MOWER HOUSING" in the Service and Adjustments section of this manual.

## CHECK FOR PROPER POSITION OF ALL BELTS

See the figures that are shown for replacing motion and mower blade drive belts in the Service and Adjustments section of this manual. Verify that the belts are routed correctly.

## CHECK BRAKE SYSTEM

After you learn how to operate your tractor, check to see that the brake is operating properly. See "TO CHECK BRAKE" in the Service and Adjustments section of this manual.

## ✓ CHECKLIST

BEFORE YOU OPERATE YOUR NEW TRACTOR, WE WISH TO ASSURE THAT YOU RECEIVE THE BEST PERFORMANCE AND SATISFACTION FROM THIS QUALITY PRODUCT.

PLEASE REVIEW THE FOLLOWING CHECKLIST:

- ✓ All assembly instructions have been completed.
- ✓ No remaining loose parts in carton.
- ✓ Battery is properly prepared and charged.
- ✓ Seat is adjusted comfortably and tightened securely.
- ✓ All tires are properly inflated. (For shipping purposes, the tires were overinflated at the factory).
- ✓ Be sure mower deck is properly leveled side-to-side/front-to-rear for best cutting results. (Tires must be properly inflated for leveling).
- ✓ Check mower and drive belts. Be sure they are routed properly around pulleys and inside all belt keepers.
- ✓ Check wiring. See that all connections are still secure and wires are properly clamped.
- ✓ Before driving tractor, be sure freewheel control is in "transmission engaged" position (see "TO TRANSPORT" in the Operation section of this manual).

WHILE LEARNING HOW TO USE YOUR TRACTOR, PAY EXTRA ATTENTION TO THE FOLLOWING IMPORTANT ITEMS:

- ✓ Engine oil is at proper level.
- ✓ Fuel tank is filled with fresh, clean, regular unleaded gasoline.
- ✓ Become familiar with all controls, their location and function. Operate them before you start the engine.
- ✓ Be sure brake system is in safe operating condition.
- ✓ Be sure Operator Presence System and Reverse Operation System (ROS) are working properly (See the Operation and Maintenance sections in this manual).
- ✓ It is important to purge the transmission before operating your tractor for the first time. Follow proper starting and transmission purging instructions (See "TO START ENGINE" and "PURGE TRANSMISSION" in the Operation section of this manual).

# OPERATION

These symbols may appear on your tractor or in literature supplied with the product. Learn and understand their meaning.

**R**

REVERSE

**N**

NEUTRAL

**H**

HIGH

**L**

LOW



CHOKE



FAST



SLOW



IGNITION  
SWITCH



ENGINE  
OFF



ENGINE  
START



ENGINE  
ON



DIFFERENTIAL  
LOCK



CLUTCH/  
BRAKE PEDAL



PARKING  
BRAKE



MOWER  
HEIGHT



MOWER  
LIFT




REVERSE  
OPERATION  
SYSTEM (ROS)



REVERSE



FORWARD




CRUISE CONTROL



LIGHTS ON



FUEL



BATTERY



EAR  
PROTECTION  
RECOMMENDED



ATTACHMENT  
CLUTCH  
DISENGAGED



ATTACHMENT  
CLUTCH  
ENGAGED




DANGER, KEEP  
HANDS AND  
FEET AWAY



KEEP AREA CLEAR  
(SEE SAFETY RULES SECTION)



SLOPE HAZARDS



FREE WHEEL  
(Automatic Models only)



Failure to follow instructions could result in serious injury or death. The safety alert symbol is used to identify safety information about hazards which can result in death, serious injury and/or property damage.

**DANGER** indicates a hazard which, if not avoided, will result in death or serious injury.



**WARNING** indicates a hazard which, if not avoided, could result in death or serious injury.



**CAUTION** indicates a hazard which, if not avoided, might result in minor or moderate injury.



**CAUTION** when used without the alert symbol, indicates a situation that could result in damage to the tractor and/or engine.



**HOT SURFACES** indicates a hazard which, if not avoided, could result in death, serious injury and/or property damage.

**FIRE** indicates a hazard which, if not avoided, could result in death, serious injury and/or property damage.

# OPERATION

## KNOW YOUR TRACTOR

### READ THIS MANUAL AND SAFETY RULES BEFORE OPERATING YOUR TRACTOR

Compare the illustrations with your tractor to familiarize yourself with the locations of various controls and adjustments. Save this manual for future reference.




Fig. 16

Our tractors conform to the applicable safety standards of the American National Standards Institute.

- (A) **ATTACHMENT LIFT LEVER** - Used to raise and lower the mower or other attachments mounted to your tractor.
- (B) **BRAKE PEDAL** - Used for braking the tractor and starting the engine.
- (C) **PARKING BRAKE** - Locks clutch/brake pedal into the brake position.
- (D) **THROTTLE CONTROL** - Used to control engine speed.
- (E) **ATTACHMENT CLUTCH SWITCH** - Used to engage the mower blades or other attachments mounted to your tractor.
- (F) **IGNITION SWITCH** - Used for starting and stopping the engine.
- (G) **REVERSE OPERATION SYSTEM (ROS) "ON" POSITION** - Allows operation of mower or other powered attachment while in reverse.

- (H) **LIGHT SWITCH** - Turns the headlights on and off.
- (J) **CRUISE CONTROL LEVER** - Used to set forward movement of tractor at desired speed without holding the forward drive pedal.
- (K) **FORWARD DRIVE PEDAL** - Used for forward movement of tractor.
- (L) **REVERSE DRIVE PEDAL** - Used for reverse movement of tractor.
- (M) **FREEWHEEL CONTROL** - Disengages transmission for pushing or slowly towing the tractor with the engine off.
- (N) **CHOKE CONTROL** - Used when starting a cold engine.
- (P) **HOURMETER** - Indicates hours of operation.
- (Z) **AMMETER** - Indicates charging (+) or discharging (-) of battery.

# OPERATION



The operation of any tractor can result in foreign objects thrown into the eyes, which can result in severe eye damage. Always wear safety glasses or eye shields while operating your tractor or performing any adjustments or repairs. We recommend standard safety glasses or a wide vision safety mask worn over spectacles.

## HOW TO USE YOUR TRACTOR

### TO SET PARKING BRAKE (See Fig. 17)

Your tractor is equipped with an operator presence sensing switch. When engine is running, any attempt by the operator to leave the seat without first setting the parking brake will shut off the engine.

- Depress brake pedal (B) all the way down and hold.
- Pull parking brake lever (C) up and hold, release pressure from brake pedal (B), then release parking brake lever. Pedal should remain in brake position. Make sure parking brake will hold tractor secure.




Fig. 17

### STOPPING (See Fig. 18)

#### MOWER BLADES -

- To stop mower blades, place attachment clutch control in the "DISENGAGED" position (★).




Fig. 18

#### GROUND DRIVE -

- To stop ground drive, depress brake pedal into full "BRAKE" position.

**IMPORTANT:** FORWARD AND REVERSE DRIVE PEDALS RETURN TO NEUTRAL POSITION WHEN NOT DEPRESSED.

#### ENGINE -

- Move throttle control (D) between half and full speed (fast) position.

**NOTE:** Failure to move throttle control between half and full speed (fast) position, before stopping may cause engine to "backfire".

- Turn ignition key (F) to "STOP" position and remove key. Always remove key when leaving tractor to prevent unauthorized use.

- Never use the choke to stop the engine.

**IMPORTANT:** LEAVING THE IGNITION SWITCH IN ANY POSITION OTHER THAN "STOP" WILL CAUSE THE BATTERY TO DISCHARGE AND GO DEAD.

**NOTE:** Under certain conditions when tractor is standing idle with the engine running, hot engine exhaust gases may cause "browning" of grass. To eliminate this possibility, always stop engine when stopping tractor on grass areas.



**CAUTION:** Always stop tractor completely, as described above, and set parking brake before leaving the operator's position.

### TO USE THROTTLE CONTROL (D) (See Fig. 19)

Always operate engine at full speed (fast).

- Operating engine at less than full speed (fast) reduces engines operating efficiency.
- Full speed (fast) offers the best bagging and mower performance.




Fig. 19

# OPERATION

## TO USE CHOKE CONTROL (N) (See Fig. 19)

Use choke control whenever you are starting a cold engine. Do not use to start a warm engine.

- To engage choke control, pull knob out. Slowly push knob in to disengage.

## TO MOVE FORWARD AND BACKWARD (See Fig. 20)

The direction and speed of movement is controlled by the forward and reverse drive pedals.

- Start tractor and release parking brake.
- Slowly depress forward (K) or reverse (L) drive pedal to begin movement. Ground speed increases the further down the pedal is depressed.




Fig. 20

## TO USE CRUISE CONTROL (J) (See Fig. 20)

The cruise control feature can be used for forward travel only.

### SYSTEM CHARACTERISTICS

The cruise control should only be used while mowing or transporting on relatively smooth, straight surfaces. Other conditions such as trimming at slow speeds may cause the cruise control to disengage. Do not use the cruise control on slopes, rough terrain or while trimming or turning.

- With forward drive pedal depressed to desired speed, pull cruise control lever (J) up and hold while lifting your foot off the pedal, then release the lever.

To disengage the cruise control, depress the brake pedal or tap on forward drive pedal.

## TO ADJUST MOWER CUTTING HEIGHT (See Fig. 21)

The position of the attachment lift lever (A) determines the cutting height.




Fig. 21

- Put attachment lift lever in desired cutting height slot.
- Slide pointer tab (T) to desired cutting height as a reminder for next time you mow.

The cutting height range is approximately 1 to 4" (25,4 to 101,6 mm). The heights are measured from the ground to the blade tip with the engine not running. These heights are approximate and may vary depending upon soil conditions, height of grass and types of grass being mowed.

- The average lawn should be cut to approximately 2-1/2" (63,5 mm) during the cool season and to over 3" (76,2 mm) during hot months. For healthier and better looking lawns, mow often and after moderate growth.
- For best cutting performance, grass over 6" (152,4 mm) in height should be mowed twice. Make the first cut relatively high; the second to desired height.

## TO ADJUST GAUGE WHEELS (See Fig. 22)

Gauge wheels are properly adjusted when they are slightly off the ground when mower is at the desired cutting height in operating position. Gauge wheels then keep the deck in proper position to help prevent scalping in most terrain conditions.

**NOTE:** Adjust gauge wheels with tractor on a flat level surface.

- Adjust mower to desired cutting height (See "TO ADJUST MOWER CUTTING HEIGHT" in this section of manual).
- With mower in desired height of cut position, gauge wheels should be assembled so they are slightly off the ground. Install gauge wheel in appropriate hole. Tighten securely.
- Repeat for all, installing gauge wheel in same adjustment hole.




Fig. 22

# OPERATION

## TO OPERATE MOWER

Your tractor is equipped with an operator presence sensing switch. Any attempt by the operator to leave the seat with the engine running and the attachment clutch engaged will shut off the engine. You must remain fully and centrally positioned in the seat to prevent the engine from hesitating or cutting off when operating your equipment on rough, rolling terrain or hills.

- Select desired height of cut. (See "TO ADJUST MOWER CUTTING HEIGHT".)
- Start mower blades by engaging attachment clutch control.

## TO STOP MOWER BLADES

Disengage attachment clutch control.



**CAUTION:** Do not operate the mower without either the entire grass catcher, on mowers so equipped, or the deflector chute in place (See Fig. 23).




Fig. 23

## REVERSE OPERATION SYSTEM (ROS) (See Fig. 24)

Your tractor is equipped with a Reverse Operation System (ROS). Any attempt by the operator to travel in the reverse direction with the attachment clutch engaged will shut off the engine unless ignition key is placed in the ROS "ON" position.

**WARNING:** Backing up with the attachment clutch engaged while mowing is strongly discouraged. Turning the ROS "ON", to allow reverse operation with the attachment clutch engaged, should only be done when the operator decides it is necessary to reposition the machine with the attachment engaged. **Do not mow in reverse unless absolutely necessary.**

**USING THE REVERSE OPERATION SYSTEM (See Fig. 24)**  
Only use if you are certain no children or other bystanders will enter the mowing area.

- Depress brake pedal all the way down.
- With engine running, turn ignition key counterclockwise to ROS "ON" position.
- Look down and behind before and while backing.
- Slowly depress reverse drive pedal to start movement.
- When use of the ROS is no longer needed, turn the ignition key clockwise to engine "ON" position.




Fig. 24

## TO OPERATE ON HILLS



**CAUTION:** Do not drive up or down hills with slopes greater than 15° and do not drive across any slope.

- Choose the slowest speed before starting up or down hills.
- Avoid stopping or changing speed on hills.
- If stopping is absolutely necessary, push brake pedal quickly to brake position and engage parking brake.
- To restart movement, slowly release parking brake and brake pedal.
- Slowly depress appropriate drive pedal to slowest setting.
- Make all turns slowly.

## TO TRANSPORT (See Fig. 25)

When pushing or towing your tractor, ensure transmission is disengaged by placing freewheel control in freewheeling position. Free wheel control is located at the rear drawbar of tractor.

- Raise attachment lift to highest position with attachment lift control.
- Pull freewheel control out and into the slot and release so it is held in the disengaged position.
- Do not push or tow tractor at more than two (2) mph (3,2 km/h).
- To reengage transmission, reverse above procedure.




Fig. 25

**NOTE:** To protect hood from damage when transporting your tractor on a truck or a trailer, ensure hood is closed and secured to tractor. Use an appropriate means of tying hood to tractor (rope, cord, etc.).

# OPERATION

## TOWING CARTS AND OTHER ATTACHMENTS

Tow only the attachments that are recommended by and comply with specifications of the manufacturer of your tractor. Use common sense when towing. Too heavy of a load, while on a slope, is dangerous. Tires can lose traction with the ground and cause you to lose control of your tractor.

## HOURMETER

The hourmeter shows the total number of hours the engine has run. To service engine and mower, see the Maintenance section of this manual.

## BEFORE STARTING THE ENGINE

### CHECK ENGINE OIL LEVEL

The engine in your tractor has been shipped from the factory already filled with summer weight oil.

- Check engine oil with tractor on level ground.
- Pull up and remove oil fill cap/dipstick; wipe oil off. Reinsert the dipstick into the tube and push down firmly into place. Remove and read oil level. If necessary, add oil until "FULL" mark on dipstick is reached. Do not overfill.
- For cold weather operation you should change oil for easier starting. (See "OIL VISCOSITY CHART" in the Maintenance section of this manual.)
- To change engine oil, see the Maintenance section in this manual.

### ADD GASOLINE

- Fill fuel tank to bottom of filler neck. Do not overfill. Use fresh, clean, regular gasoline with a minimum of 87 octane. Do not mix oil with gasoline. Purchase fuel in quantities that can be used within 30 days to ensure fuel freshness.



**CAUTION:** Wipe off any spilled oil or fuel. Do not store, spill or use gasoline near an open flame.

**IMPORTANT:** WHEN OPERATING IN TEMPERATURES BELOW 32°F (0°C), USE FRESH, CLEAN WINTER GRADE GASOLINE TO HELP ENSURE GOOD COLD WEATHER STARTING.

**CAUTION:** Alcohol blended fuels (called gasohol or using ethanol or methanol) can attract moisture which leads to separation and formation of acids during storage. Acidic gas can damage the fuel system of an engine while in storage. To avoid engine problems, the fuel system should be emptied before storage of 30 days or longer. Drain the gas tank, start the engine and let it run until the fuel lines and carburetor are empty. Use fresh fuel next season. See Storage Instructions for additional information. Never use engine or carburetor cleaner products in the fuel tank or permanent damage may occur. Fuel stabilizer is an acceptable alternative in minimizing the formation of fuel gum deposits during storage. Add stabilizer to gasoline in fuel tank or storage container. Always follow the mix ratio found on stabilizer container. Run engine at least 10 minutes after adding stabilizer to allow the stabilizer to reach the carburetor. Do not empty the gas tank and carburetor if using fuel stabilizer.

### RESERVE FUEL VALVE OPERATION (See Fig. 26)

1. Raise seat to access reserve fuel valve.
2. In normal operation, valve should be set to primary (as shown in view)
3. If tractor runs out of fuel, rotate valve handle to reserve.
4. Drive tractor to be refueled.
5. After refueling, return valve to primary position.




Fig. 26

# OPERATION

## TO START ENGINE (See Fig. 16)

When starting the engine for the first time or if the engine has run out of fuel, it will take extra cranking time to move fuel from the tank to the engine.

- Ensure freewheel control is in the transmission engaged position.
- Sit on seat in operating position, depress brake pedal and set parking brake.
- Move attachment clutch to "DISENGAGED" position.
- Move throttle control to fast position
- Pull choke control out for a cold engine start attempt. For a warm engine start attempt the choke control may not be needed.

**NOTE:** Before starting, read the warm and cold starting procedures below.

- Insert key into ignition and turn key clockwise to "START" position and release key as soon as engine starts. Do not run starter continuously for more than fifteen seconds per minute. If the engine does not start after several attempts, push choke control in, wait a few minutes and try again. If engine still does not start, pull the choke control out and retry.

### WARM WEATHER STARTING (50°F/10°C and above)

- When engine starts, slowly push choke control in until the engine begins to run smoothly. If the engine starts to run roughly, pull the choke control out slightly for a few seconds and then continue to push the control in slowly.
- The attachments and ground drive can now be used. If the engine does not accept the load, restart the engine and allow it to warm up for one minute using the choke as described above.

### COLD WEATHER STARTING (50°F/10°C and below)

- When engine starts, slowly push choke control in until the engine begins to run smoothly. Continue to push the choke control in small steps allowing the engine to accept small changes in speed and load, until the choke control is fully in. If the engine starts to run roughly, pull the choke control out slightly for a few seconds and then continue to push the control in slowly. This may require an engine warm-up period from several seconds to several minutes, depending on the temperature.

### AUTOMATIC TRANSMISSION WARM UP

- Before driving the unit in cold weather, the transmission should be warmed up as follows:
  - Be sure the tractor is on level ground.
  - Release the parking brake and let the brake slowly return to operating position.
  - Allow one minute for transmission to warm up. This can be done during the engine warm up period.
- The attachments can be used during the engine warm-up period after the transmission has been warmed up and may require the choke control be pulled out slightly.

## PURGE TRANSMISSION



**CAUTION:** Never engage or disengage free-wheel lever while the engine is running.

To ensure proper operation and performance, it is recommended that the transmission be purged before operating tractor for the first time. This procedure will remove any trapped air inside the transmission which may have developed during shipping of your tractor.

**IMPORTANT:** SHOULD YOUR TRANSMISSION REQUIRE REMOVAL FOR SERVICE OR REPLACEMENT, IT SHOULD BE PURGED AFTER REINSTALLATION BEFORE OPERATING THE TRACTOR.

1. Place tractor safely on a level surface - that is clear and open - with engine off and parking brake set.
2. Disengage transmission by placing freewheel control in disengaged position. (See "TO TRANSPORT" in this section of manual.)
3. Sitting in the tractor seat, start engine. After the engine is running, move throttle control to slow position. Disengage parking brake



**CAUTION:** At any time, during step 4, there may be movement of the drive wheels.

4. Depress forward drive pedal to full forward position, hold for five (5) seconds and release pedal. Depress reverse drive pedal to full reverse position, hold for five (5) seconds and release pedal. Repeat this procedure three (3) times.
5. Shut-off engine and set parking brake.
6. Engage transmission by placing freewheel control in engaged position. (See "TO TRANSPORT" in this section of manual.)
7. Sitting in the tractor seat, start engine. After the engine is running, move throttle control to half (1/2) speed. Disengage parking brake.
8. Drive tractor forward for approximately 5 feet (1,5 m) then backwards for 5 feet (1,5 m). Repeat this driving procedure three times.

Your transmission is now purged and now ready for normal operation.

# OPERATION

## MOWING TIPS

- DO NOT use tire chains when the mower housing is attached to tractor.
- Mower should be properly leveled for best mowing performance. See "TO LEVEL MOWER HOUSING" in the Service and Adjustments section of this manual.
- The left hand side of mower should be used for trimming.
- Drive so that clippings are discharged onto the area that has been cut. Have the cut area to the right of the tractor. This will result in a more even distribution of clippings and more uniform cutting.
- When mowing large areas, start by turning to the right so that clippings will discharge away from shrubs, fences, driveways, etc. After one or two rounds, mow in the opposite direction making left hand turns until finished (See Fig. 27).




Fig. 27

- If grass is extremely tall, it should be mowed twice to reduce load and possible fire hazard from dried clippings. Make first cut relatively high; the second to the desired height.
- Do not mow grass when it is wet. Wet grass will plug mower and leave undesirable clumps. Allow grass to dry before mowing.
- **Always operate engine at full throttle when mowing** to ensure better mowing performance and proper discharge of material. Regulate ground speed by selecting a low enough gear to give the mower cutting performance as well as the quality of cut desired.
- When operating attachments, select a ground speed that will suit the terrain and give best performance of the attachment being used.

# MAINTENANCE

| MAINTENANCE SCHEDULE |   | BEFORE EACH USE | EVERY 8 HOURS | EVERY 25 HOURS   | EVERY 50 HOURS   | EVERY 100 HOURS  | EVERY SEASON | BEFORE STORAGE |
|----------------------|---|-----------------|---------------|------------------|------------------|------------------|--------------|----------------|
| TRACTOR              | Check Brake Operation                         | ✓               | ✓             |                  |                  |                  |              |                |
|                      | Check Tire Pressure                           | ✓               | ✓             |                  |                  |                  |              |                |
|                      | Check Operator Presence and ROS Systems       | ✓               |               |                  |                  |                  |              |                |
|                      | Check for Loose Fasteners                     | ✓               |               |                  |                  | ✓                |              | ✓              |
|                      | Check/Replace Mower Blades                    |                 |               | ✓ <sup>3</sup>   |                  |                  |              |                |
|                      | Lubrication Chart                             |                 |               | ✓                |                  |                  |              | ✓              |
|                      | Check Battery Level                           |                 |               | ✓ <sup>4</sup>   |                  |                  |              |                |
|                      | Clean Battery and Terminals                   |                 |               | ✓                |                  |                  |              | ✓              |
|                      | Clean Debris off Steering Plate               |                 |               | ✓ <sup>5</sup>   |                  |                  |              |                |
|                      | Check Transaxle Cooling                       |                 |               | ✓                |                  |                  |              |                |
|                      | Check Mower Levelness                         |                 |               |                  | ✓                |                  |              |                |
|                      | Check V-Belts                                 |                 |               |                  |                  | ✓                |              |                |
| ENGINE               | Check Engine Oil Level                        | ✓               | ✓             |                  |                  |                  |              |                |
|                      | Change Engine Oil (models with oil filter)    |                 |               |                  | ✓ <sup>1,2</sup> |                  |              | ✓              |
|                      | Change Engine Oil (models without oil filter) |                 |               | ✓ <sup>1,2</sup> |                  |                  |              | ✓              |
|                      | Clean Air Filter                              |                 |               | ✓ <sup>2</sup>   |                  |                  |              |                |
|                      | Clean Air Screen                              |                 |               | ✓ <sup>2</sup>   |                  |                  |              |                |
|                      | Inspect Muffler/Spark Arrester                |                 |               |                  | ✓ <sup>6</sup>   |                  |              |                |
|                      | Replace Oil Filter (If equipped)              |                 |               |                  |                  | ✓ <sup>1,2</sup> |              |                |
|                      | Clean Engine Cooling Fins                     |                 |               |                  |                  | ✓ <sup>2</sup>   |              |                |
|                      | Replace Spark Plug                            |                 |               |                  |                  | ✓                | ✓            |                |
|                      | Replace Air Filter Paper Cartridge            |                 |               |                  |                  | ✓ <sup>2</sup>   |              |                |
|                      | Replace Fuel Filter                           |                 |               |                  |                  |                  | ✓            |                |

1 - Change more often when operating under a heavy load or in high ambient temperatures.  
 2 - Service more often when operating in dirty or dusty conditions.  
 3 - Replace blades more often when mowing in sandy soil.

4 - Not required if equipped with maintenance-free battery  
 5 - See Cleaning in Maintenance Section.

6 - Inspect the muffler every 50 hours of operation or six months for signs of damage. If damage is found, refer to the repair parts list or contact your local dealer to order a replacement.

## GENERAL RECOMMENDATIONS

The warranty on this tractor does not cover items that have been subjected to operator abuse or negligence. To receive full value from the warranty, operator must maintain tractor as instructed in this manual.


Some adjustments will need to be made periodically to properly maintain your tractor.

At least once a season, check to see if you should make any of the adjustments described in the Service and Adjustments section of this manual.

- At least once a year you should replace the spark plug, clean or replace air filter, and check blades and belts for wear. A new spark plug and clean air filter ensure proper air-fuel mixture and help your engine run better and last longer.

## BEFORE EACH USE

- Check engine oil level.
- Check brake operation.
- Check tire pressure.
- Check operator presence and ROS systems for proper operation.
- Check for loose fasteners.



① General Purpose Grease

② Refer to Maintenance "ENGINE" Section

**IMPORTANT:** DO NOT OIL OR GREASE THE PIVOT POINTS WHICH HAVE SPECIAL NYLON BEARINGS. VISCOUS LUBRICANTS WILL ATTRACT DUST AND DIRT THAT WILL SHORTEN THE LIFE OF THE SELF-LUBRICATING BEARINGS. IF YOU FEEL THEY MUST BE LUBRICATED, USE ONLY A DRY, POWDERED GRAPHITE TYPE LUBRICANT SPARINGLY.

# MAINTENANCE

## TRACTOR

Always observe safety rules when performing any maintenance.

### BRAKE OPERATION

If tractor requires more than five (5) feet (1.5 m) to stop at highest speed in highest gear on a level, dry concrete or paved surface, then brake must be checked and adjusted. (See "TO CHECK BRAKE" in the Service and Adjustments section of this manual.)

### TIRES

- Maintain proper air pressure in all tires. (See the sides of tires for proper PSI.)
- Keep tires free of gasoline, oil, or insect control chemicals which can harm rubber.
- Avoid stumps, stones, deep ruts, sharp objects and other hazards that may cause tire damage.

**NOTE:** To seal tire punctures and prevent flat tires due to slow leaks, tire sealant may be purchased from your local parts dealer. Tire sealant also prevents tire dry rot and corrosion.

### OPERATOR PRESENCE SYSTEM AND REVERSE OPERATION SYSTEM (ROS) (See Fig. 28)

Be sure operator presence and reverse operation systems are working properly. If your tractor does not function as described, repair the problem immediately.

- The engine should not start unless the brake pedal is fully depressed, and the attachment clutch control is in the disengaged position.

### CHECK OPERATOR PRESENCE SYSTEM

- When the engine is running, any attempt by the operator to leave the seat without first setting the parking brake should shut off the engine.
- When the engine is running and the attachment clutch is engaged, any attempt by the operator to leave the seat should shut off the engine.
- The attachment clutch should never operate unless the operator is in the seat.

### CHECK REVERSE OPERATION (ROS) SYSTEM

- When the engine is running with the ignition switch in the engine "ON" position and the attachment clutch engaged, any attempt by the operator to shift into reverse should shut off the engine.
- When the engine is running with the ignition switch in the ROS "ON" position and the attachment clutch engaged, any attempt by the operator to shift into reverse should NOT shut off the engine.



ROS "ON"  
POSITION



ENGINE "ON" POSITION  
(NORMAL OPERATING)

Fig. 28

## BLADE CARE

For best results mower blades must be kept sharp. Replace bent or damaged blades.



**CAUTION: Use only a replacement blade approved by the manufacturer of your tractor. Using a blade not approved by the manufacturer of your tractor is hazardous, could damage your tractor and void your warranty.**

### BLADE REMOVAL (See Fig. 29)

- Raise mower to highest position to allow access to blades.

**NOTE:** Protect your hands with gloves and/or wrap blade with heavy cloth.

- Remove blade bolt by turning counterclockwise.
- Install new or resharpened blade with stamped "GRASS SIDE" facing the ground.

**IMPORTANT:** To ensure proper assembly, center hole in blade must align with star on mandrel assembly.

- Install and tighten blade bolt securely (45-55 Ft. Lbs./62-75 Nm).

**IMPORTANT: SPECIAL BLADE BOLT IS HEAT TREATED.**




Fig. 29

## BATTERY

Your tractor has a battery charging system which is sufficient for normal use. However, periodic charging of the battery with an automotive charger will extend its life.

- Keep battery and terminals clean.
- Keep battery bolts tight.
- Keep small vent holes open.
- Recharge at 6-10 amperes for 1 hour.

**NOTE:** The original equipment battery on your tractor is maintenance free. Do not attempt to open or remove caps or covers. Adding or checking level of electrolyte is not necessary.

### TO CLEAN BATTERY AND TERMINALS

Corrosion and dirt on the battery and terminals can cause the battery to "leak" power.

- Remove terminal guard.
- Disconnect BLACK battery cable first then RED battery cable and remove battery from tractor.
- Rinse the battery with plain water and dry.
- Clean terminals and battery cable ends with wire brush until bright.
- Coat terminals with grease or petroleum jelly.
- Reinstall battery. (See "REPLACING BATTERY" in the Service and Adjustments section of this manual.)

# MAINTENANCE

## V-BELTS

Check V-belts for deterioration and wear after 100 hours of operation and replace if necessary. The belts are not adjustable. Replace belts if they begin to slip from wear.

## TRANSAXLE COOLING

The transmission fan and cooling fins should be kept clean to assure proper cooling.

Do not attempt to clean fan or transmission while engine is running or while the transmission is hot. To prevent possible damage to seals, do not use high pressure water or steam to clean transaxle.

- Inspect cooling fan to be sure fan blades are intact and clean.
- Inspect cooling fins for dirt, grass clippings and other materials. To prevent damage to seals, do not use compressed air or high pressure sprayerto clean cooling fins.


## TRANSAXLE PUMP FLUID

The transaxle was sealed at the factory and fluid maintenance is not required for the life of the transaxle. Should the transaxle ever leak or require servicing, contact your nearest authorized service center/department.

## ENGINE

### LUBRICATION

Only use high quality detergent oil rated with API service classification SG-SL. Select the oil's SAE viscosity grade according to your expected operating temperature. When operating in temperatures below 0° F (-18° C) synthetic oil must be used.



\* **CAUTION:** Air cooled engines run hotter than automotive engines. The use of non-synthetic multi-viscosity oils (5W30, 10W30 etc.) in temperatures above 40° F (4° C) will result in higher than normal oil consumption. When using a multi-viscosity oil, check oil level more frequently.

\*\* **CAUTION:** SAE 30 oil, if used below 40° F (4° C), will result in hard starting and possible engine bore damage due to inadequate lubrication.



**NOTE:** Synthetic oil meeting ILSAC GF-2, API certification mark and API service symbol (shown at left) with "SJ/CF ENERGY CONSERVING" or higher, is an acceptable oil at all temperatures. **Use of synthetic oil does not alter required oil change intervals.**

Change the oil after every 50 hours of operation or at least once a year if the tractor is not used for 50 hours in one year.

Check the crankcase oil level before starting the engine and after each eight (8) hours of operation. Tighten oil fill cap/dipstick securely each time you check the oil level.

## TO CHANGE ENGINE OIL (See Fig. 30 - 32)

Determine temperature range expected before oil change. All oil must meet API service classification SG-SL.

- Ensure tractor is on level surface.
- Oil will drain more freely when warm.
- Catch oil in a suitable container.

### LOWER DASH COVER REMOVAL

- Raise hood.
- Remove fastener from lower dash cover.

**CAUTION:** Remove lower dash cover carefully to ensure cover tabs are not broken.

- Slide lower dash cover up to release cover tabs from tapered slots in lower dash and remove.




Fig. 31

- Remove oil fill cap/dipstick. Be careful not to allow dirt to enter the engine when changing oil.
- Remove yellow cap from end of drain valve and install the drain tube onto the fitting.
- Unlock drain valve by pushing inward and turning counterclockwise.
- To open, pull out on the drain valve.




Fig. 32

- After oil has drained completely, close and lock the drain valve by pushing inward and turning clockwise until the pin is in the locked position as shown.
- Remove the drain tube and replace the cap onto to the bottom fitting of the drain valve.
- Refill engine with oil through oil fill dipstick tube. Pour slowly. Do not overfill. For approximate capacity see "PRODUCT SPECIFICATIONS" section of this manual.

# MAINTENANCE

- Use gauge on oil fill cap/dipstick for checking level. Insert dipstick into the tube and rest the oil fill cap on the tube. Do not thread the cap onto the tube when taking reading. Keep oil at "FULL" line on dipstick. Tighten cap onto the tube securely when finished.

## ENGINE OIL FILTER

Replace the engine oil filter every season or every other oil change if the tractor is used more than 100 hours in one year.

**NOTE:** If needed, remove lower dash covers using steps from "Lower dash cover removal" section of this manual.

## AIR FILTER

Your engine will not run properly using a dirty air filter. Service air cleaner more often under dusty conditions.

## CLEAN AIR SCREEN

The air screen is over the air intake blower located on top of engine. The air screen must be kept free of dirt and chaff to prevent engine damage from overheating. Clean with a wire brush or compressed air to remove dirt and stubborn dried gum fibers.

## MUFFLER

Inspect and replace corroded muffler and spark arrester (if equipped) as it could create a fire hazard and/or damage.

## SPARK PLUGS

Replace spark plugs at the beginning of each mowing season or after every 100 hours of operation, whichever occurs first. Spark plug type and gap setting are shown in "PRODUCT SPECIFICATIONS" section of this manual.

## ENGINE COOLING SYSTEM

To ensure proper cooling, make sure the grass screen, cooling fins, and other external surfaces of the engine are kept clean at all times.

Every 100 hours of operation (more often under extremely dusty, dirty conditions), remove the blower housing and other cooling shrouds. Clean the cooling fins and external surfaces as necessary. Ensure the cooling shrouds are reinstalled.

**NOTE:** Operating the engine with a blocked grass screen, dirty or plugged cooling fins, and/or cooling shrouds removed will cause engine damage due to overheating.

## IN-LINE FUEL FILTER (See Fig. 33)

The fuel filter should be replaced once each season. If fuel filter becomes clogged, obstructing fuel flow to carburetor, replacement is required.

- With engine cool, remove filter and plug fuel line sections.
- Place new fuel filter in position in fuel line with arrow pointing towards carburetor.
- Be sure there are no fuel line leaks and clamps are properly positioned.
- Immediately wipe up any spilled gasoline.




Fig. 33

## CLEANING

- Clean engine, battery, seat, finish, etc. of all foreign matter.
- Clean debris from steering plate. Debris can restrict clutch/brake pedal shaft movement, causing belt slip and loss of drive. See Fig. 34.



**CAUTION: Avoid all pinch points and movable parts.**




Fig. 34

- Keep finished surfaces and wheels free of all gasoline, oil, etc.
- Protect painted surfaces with automotive type wax.

Except for the washout port (if equipped), we do not recommend using a garden hose or pressure washer to clean the outside of your tractor unless the engine and transmission are covered to keep water out. Water in engine or transmission will shorten the useful life of your tractor. Use compressed air or a leaf blower to remove grass, leaves and trash from outside tractor and mower.

# MAINTENANCE

## DECK WASHOUT PORT (See Fig. 35)

Your tractor's deck is equipped with a washout port as part of its deck wash system. It should be utilized after each use.

1. Drive the tractor to a level, clear spot on your lawn, near enough to a water spigot for your garden hose to reach.

**IMPORTANT:** Make certain the tractor's discharge chute is directed AWAY from your house, garage, parked cars, etc. Remove bagger chute or mulch cover if attached.

2. Make sure the attachment clutch control is in the "DISENGAGED" position, set the parking brake, and stop the engine.
3. Pull back the lock collar of the nozzle adapter and push the adapter onto the deck washout port at the left end of the mower deck. Release the lock collar to lock the adapter on the nozzle.




Fig. 35

**IMPORTANT:** Tug hose ensuring connection is secure.

4. Turn the water on.
5. While sitting in the operator's position on the tractor, re-start the engine and place the throttle lever in the Fast "████" position.

**IMPORTANT:** Recheck the area to ensure the area is clear. Ensure no children are in the area while cleaning the deck.

6. Move the tractor's attachment clutch control to the "ENGAGED" position. Remain in the operator's position with the cutting deck engaged until the deck is cleaned.
7. Move the tractor's attachment clutch control to the "DISENGAGED" position. Turn the ignition key to the STOP position to turn the tractor's engine off. Turn the water off.
8. Pull back the lock collar of the nozzle adapter to disconnect the adapter from the nozzle washout port.
9. Move the tractor to a dry area, preferably a concrete or paved area. Place the attachment clutch control in the "ENGAGED" position to remove excess water and to help dry before putting the tractor away.



**WARNING:** A broken or missing washout fitting could expose you or others to thrown objects from contact with the blade.

- Replace broken or missing washout fitting immediately, prior to using mower again.
- Plug any holes in mower with bolts and locknuts.

# SERVICE AND ADJUSTMENTS



**WARNING: TO AVOID SERIOUS INJURY, BEFORE PERFORMING ANY SERVICE OR ADJUSTMENTS:**

- Depress brake pedal fully and set parking brake.
- Place attachment clutch in "DISENGAGED" position.
- Turn ignition key to "STOP" and remove key.
- Make sure the blades and all moving parts have completely stopped.
- Disconnect spark plug wire from spark plug and place wire where it cannot come in contact with plug.

## TO REMOVE MOWER (See Fig. 36)

- Place attachment clutch in "DISENGAGED" position.
- Lower attachment lift lever to its lowest position.
- Disengage belt tension rod (K) from lock bracket (L).



**CAUTION: Belt tension rod is spring loaded. Have a tight grip on rod and release slowly.**

- Remove mower belt from electric clutch pulley (M).
- Disconnect front link (E) from mower - remove retainer spring and washer.
- Go to either side of mower and disconnect mower suspension arm (A) from chassis and rear lift link (C) from rear mower bracket (D) - remove retainers springs and washers.
- Go to other side of mower and disconnect the suspension arm and rear lift link.



**CAUTION: After rear lift links are disconnected, the attachment lift lever will be spring loaded. Have a tight grip on lift lever when changing position of the lever.**

- From right side of mower, disconnect anti-sway bar (S) from right rear mower bracket (D) - remove retainer spring and washer and pull mower toward you until the bar falls from the hole in bracket.
- Turn tractor steering wheel to the left as far as it will go.
- Slide mower out from under right side of tractor.

## TO INSTALL MOWER

Follow procedure described in "INSTALL MOWER AND DRIVE BELT" in the Assembly section of this manual.




Fig. 36

## TO REPLACE MOWER BLADE DRIVE BELT (See Fig. 37)

### MOWER DRIVE BELT REMOVAL

- Park tractor on a level surface. Engage parking brake.
- Lower attachment lift lever to its lowest position.
- Disengage belt tension rod (K) from lock bracket (L).



**CAUTION: Belt tension rod is spring loaded. Have a firm grip on rod and release slowly.**

- Remove screws (P) from mandrel covers (Q) and remove covers.
- Remove any dirt or grass clippings which may have accumulated around mandrels and entire upper deck surface.
- Remove belt from electric clutch pulley (M), both mandrel pulleys (R) and all idler pulleys (V).

### MOWER DRIVE BELT INSTALLATION

- Install belt around all mandrel pulleys (R) and around idler pulleys (V) as shown.
- Install belt onto electric clutch pulley (M).

**IMPORTANT:** Check belt for proper routing in all mower pulley grooves.

- Reassemble mandrel covers (Q). Securely tighten all screws.
- Engage belt tension rod (K) on locking bracket (L).



**CAUTION: Belt tension rod is spring loaded. Have a tight grip on rod and engage slowly.**

- Raise attachment lift lever to highest position.




Fig. 37

# SERVICE AND ADJUSTMENTS

## TO LEVEL MOWER

Ensure tires are properly inflated to the PSI shown on tires. If tires are over or under inflated, it may affect the appearance of your lawn and lead you to think the mower is not adjusted properly.

### VISUAL SIDE-TO-SIDE ADJUSTMENT (See Fig. 38)

- With all tires properly inflated and if your lawn appears unevenly cut, determine which side of mower is cutting lower.

**NOTE:** As desired, you can raise the low side of mower or lower the high side.

- Go to side of mower you wish to adjust.
- With a 3/4" or adjustable wrench, turn lift link adjustment nut (A) to the left to lower the mower, or, to the right to raise the mower.




Fig. 38

**NOTE:** Each full turn of adjustment nut will change mower height about 3/16" (4.7 mm).

- Test your adjustment by mowing some uncut grass and visually checking the appearance. Readjust, if necessary, until you are satisfied with the results.

### PRECISION SIDE-TO-SIDE ADJUSTMENT (See Fig. 39)

- With all tires properly inflated, park tractor on level ground or driveway.



**CAUTION: Blades are sharp. Protect your hands with gloves and/or wrap blade with heavy cloth.**

- Raise mower to its highest position.
- At both sides of mower, position blade at side and measure the distance (A) from bottom edge of blade to the ground. The distance should be the same on both sides.
- If adjustment is necessary, see steps in Visual Adjustment instructions above.




Fig. 39

- Recheck measurements, adjust if necessary until both sides are equal.

### FRONT-TO-BACK ADJUSTMENT (See Figs. 40 & 41)

**IMPORTANT:** Deck must be level side-to-side.

To obtain the best cutting results, the mower blades should be adjusted so the front tip is 1/8" to 1/2" (3,1 to 12,7 mm) lower than the rear tip when the mower is in its highest position.



**CAUTION: Blades are sharp. Protect your hands with gloves and/or wrap blade with heavy cloth.**

- Raise mower to highest position.
- Position any blade so the tip is pointing straight forward. Measure distance (B) to the ground at front and rear tip of the blade.




Fig. 40

- If front tip of blade is not 1/8" to 1/2" (3,1 to 12,7 mm) lower than the rear tip, go to the front of tractor.
- With an 11/16" or adjustable wrench, loosen jam nut A several turns to clear adjustment nut B.
- With a 3/4" or adjustable wrench, turn front link adjustment nut (B) clockwise (↷) (tighten) to raise the front of mower, or, counterclockwise (↶) (loosen) to lower the front mower.




Fig. 41

**NOTE:** Each full turn of the adjustment nut will change mower height about 1/8" (3,1 mm).

- Recheck measurements, adjust if necessary until front tip of blade is 1/8 to 1/2" (3,1 to 12,7 mm) lower than the rear tip.
- Hold adjustment nut in position with wrench and tighten jam nut securely against adjustment nut.

# SERVICE AND ADJUSTMENTS

## TO REPLACE MOTION DRIVE BELT

### (See Fig. 42)

Park the tractor on level surface. Engage parking brake. For assistance, there is a belt installation guide decal on bottom side of left footrest.

#### BELT REMOVAL -

1. Remove mower (See "TO REMOVE MOWER" section in this manual).
2. Disconnect clutch wire harness (A).
3. Remove anti-rotation link (B) on right side of tractor.
4. Remove belt from stationary idler (C) and clutching idler (D).
5. Remove belt from centerspan idler (E).
6. Pull belt slack toward rear of tractor. Carefully remove belt upwards from transmission input pulley and over cooling fan blades (F).
7. Remove belt downward from engine pulley and around electric clutch (G).
8. Slide belt toward rear of tractor, off the steering plate (H) and remove from tractor.

#### BELT INSTALLATION -

1. Install new belt from tractor rear to front, over the steering plate (H) and above clutch brake pedal shaft (J).
2. Pull belt toward front of tractor and roll belt around electric clutch and onto engine pulley (G).
3. Pull belt toward rear of tractor. Carefully work belt down around transmission cooling fan and onto the input pulley (F). Be sure belt is inside the belt keeper.
4. Install belt on centerspan idler (E).
5. Install belt through stationary idler (C) and clutching idler (D).
6. Reinstall anti-rotation link (B) on right side of tractor. Tighten securely.
7. Reconnect clutch harness (A).
8. Make sure belt is in all pulley grooves and inside all belt guides and keepers.
9. Install mower (See "TO INSTALL MOWER" section in this manual).




Fig. 42

## TO CHECK BRAKE

If tractor requires more than five (5) feet to stop at highest speed in highest gear on a level, dry concrete or paved surface, then brake must be serviced.

You may also check brake by:

1. Park tractor on a level, dry concrete or paved surface, depress brake pedal all the way down and engage parking brake.
2. Disengage transmission by placing freewheel control in "transmission disengaged" position. Pull freewheel control out and into the slot and release so it is held in the disengaged position.

The rear wheels must lock and skid when you try to manually push the tractor forward. If the rear wheels rotate, then the brake needs to be serviced. Contact a qualified service center.

## TO REMOVE WHEEL FOR REPAIRS

### (See Fig. 43)

- Block up axle securely.
- Remove axle cover, retaining ring and washers to allow wheel removal (rear wheel contains a square key - Do not lose).
- Repair tire and reassemble.
- On rear wheels only: align grooves in rear wheel hub and axle. Insert square key.
- Replace washers and snap retaining ring securely in axle groove.
- Replace axle cover.

**NOTE:** To seal tire punctures and prevent flat tires due to slow leaks, tire sealant may be purchased from your local parts dealer. Tire sealant also prevents tire dry rot and corrosion.




Fig. 43

## FRONT WHEEL TOE-IN/CAMBER

Your new tractor front wheel toe-in and camber is set at the factory and is normal. The front wheel toe-in and camber are not adjustable. If damage has occurred to affect the factory set front wheel toe-in or camber, contact a qualified service center.

# SERVICE AND ADJUSTMENTS

## TO START ENGINE WITH A WEAK BATTERY (See Fig. 44)



**WARNING:** Lead-acid batteries generate explosive gases. Keep sparks, flame and smoking materials away from batteries. Always wear eye protection when around batteries.

If your battery is too weak to start the engine, it should be recharged. (See "BATTERY" in the MAINTENANCE section of this manual).

If "jumper cables" are used for emergency starting, follow this procedure:

**IMPORTANT:** YOUR TRACTOR IS EQUIPPED WITH A 12 VOLT SYSTEM. THE OTHER VEHICLE MUST ALSO BE A 12 VOLT SYSTEM. DO NOT USE YOUR TRACTOR BATTERY TO START OTHER VEHICLES.

### TO ATTACH JUMPER CABLES -

- Connect one end of the RED cable to the POSITIVE (+) terminal of each battery(A-B), taking care not to short against tractor chassis.
- Connect one end of the BLACK cable to the NEGATIVE (-) terminal (C) of fully charged battery.
- Connect the other end of the BLACK cable (D) to good chassis ground, away from fuel tank and battery.

### TO REMOVE CABLES, REVERSE ORDER -

- BLACK cable first from chassis and then from the fully charged battery.
- RED cable last from both batteries.




Fig. 44

## REPLACING BATTERY (See Fig. 45)



**WARNING:** Do not short battery terminals by allowing a wrench or any other object to contact both terminals at the same time. Before connecting battery, remove metal bracelets, wristwatch bands, rings, etc. Positive terminal must be connected first to prevent sparking from accidental grounding.

- Lift hood to raised position.
- Remove terminal cover.
- Disconnect BLACK battery cable then RED battery cable and carefully remove battery from tractor.
- Install new battery with terminals in same position as old battery.
- Reinstall terminal cover.
- First connect RED battery cable to positive (+) battery terminal with bolt and nut as shown. Tighten securely.
- Connect BLACK grounding cable to negative (-) battery terminal with remaining bolt and nut. Tighten securely
- Close hood.




Fig. 45

# SERVICE AND ADJUSTMENTS

## INTERLOCKS AND RELAYS

Loose or damaged wiring may cause your tractor to run poorly, stop running, or prevent it from starting.

- Check wiring.

## TO REPLACE FUSE

Replace with 20 amp automotive-type plug-in fuse. The fuse holder is located behind the dash.

## TO REPLACE HEADLIGHT BULB

- Raise hood.
- Pull bulb holder out of the hole in the backside of the grill.
- Replace bulb in holder and push bulb holder securely back into the hole in the backside of the grill.
- Close hood.

## TO REMOVE HOOD & GRILL ASSEMBLY

(See Fig. 46)

1. Raise hood.
2. Unsnap headlight wire connector.
3. Remove retainer clip and washer from right hand pivot pin.
4. Stand in front of tractor. Grasp hood at sides and slide left removing hood from pivot pins and lift hood off of tractor.
5. When replacing hood, reconnect the headlight wire connector, and reinstall the washer and retainer clip on the right hand pivot pin.




Fig. 46

## TRANSMISSION

### REMOVAL/REPLACEMENT

Should your transmission require removal for service or replacement, it should be purged after reinstallation and before operating the tractor. See "PURGE TRANSMISSION" in the Operation section of this manual.

## ENGINE

### TO ADJUST THROTTLE CONTROL CABLE

The throttle control has been preset at the factory and adjustment should not be necessary. If adjustment is necessary, see engine manual.

### TO ADJUST CHOKE CONTROL

The choke control has been preset at the factory and adjustment should not be necessary. If adjustment is necessary, see engine manual.

# STORAGE

Immediately prepare your tractor for storage at the end of the season or if the tractor will not be used for 30 days or more.



**WARNING:** Never store the tractor with gasoline in the tank inside a building where fumes may reach an open flame or spark. Allow the engine to cool before storing in any enclosure.

## TRACTOR

Remove mower from tractor for winter storage. When mower is to be stored for a period of time, clean it thoroughly, remove all dirt, grease, leaves, etc. Store in a clean, dry area.

- Clean entire tractor. (See "CLEANING" in the Maintenance section of this manual.)
- Inspect and replace belts, if necessary. (See belt replacement instructions in the Service and Adjustments section of this manual.)
- Lubricate as shown in the Maintenance section of this manual.
- Ensure all nuts, bolts and screws are securely fastened. Inspect moving parts for damage, breakage and wear. Replace if necessary.
- Touch up all rusted or chipped paint surfaces; sand lightly before painting.

## BATTERY

- Fully charge the battery for storage.
- After a period of time in storage, battery may require recharging.
- To help prevent corrosion and power leakage during long periods of storage, battery cables should be disconnected and battery cleaned thoroughly. (See "TO CLEAN BATTERY AND TERMINALS" in the Maintenance section of this manual.)
- After cleaning, leave cables disconnected and place cables where they cannot come in contact with battery terminals.
- If battery is removed from tractor for storage, do not store battery directly on concrete or damp surfaces.
- If unit is equipped with battery indicator/charging plug, an optional charging unit may be purchased and connected to the unit to charge the battery during long term storage. Inspect and clean the battery terminals as needed prior to long term storage with charger connected.

## ENGINE

### FUEL SYSTEM

**IMPORTANT:** IT IS IMPORTANT TO PREVENT GUM DEPOSITS FROM FORMING IN ESSENTIAL FUEL SYSTEM PARTS SUCH AS CARBURETOR, FUEL FILTER, FUEL HOSE, OR TANK DURING STORAGE. ALSO, EXPERIENCE INDICATES THAT ALCOHOL BLENDED FUELS (CALLED GASOHOL OR USING ETHANOL OR METHANOL) CAN ATTRACT MOISTURE WHICH LEADS TO SEPARATION AND FORMATION OF ACIDS DURING STORAGE. ACIDIC GAS CAN DAMAGE THE FUEL SYSTEM OF AN ENGINE WHILE IN STORAGE.

- Empty the fuel tank by starting the engine and let it run until the fuel lines and carburetor are empty.
- Never use engine or carburetor cleaner products in the fuel tank or permanent damage may occur.
- Use fresh fuel next season.

**NOTE:** Fuel stabilizer is an acceptable alternative in minimizing the formation of fuel gum deposits during storage. Add stabilizer to gasoline in fuel tank or storage container. Always follow the mix ratio found on stabilizer container. Run engine at least 10 minutes after adding stabilizer to allow the stabilizer to reach the carburetor. Do not empty the gas tank and carburetor if using fuel stabilizer.

### ENGINE OIL

Drain oil (with engine warm) and replace with clean engine oil. (See "ENGINE" in the Maintenance section of this manual.)

### CYLINDER(S)

- Remove spark plug(s).
- Pour one ounce (29.5 mL) of oil through spark plug hole(s) into cylinder(s).
- Turn ignition key to "START" position for a few seconds to distribute oil.
- Replace with new spark plug(s).

### OTHER

- Do not store gasoline from one season to another.
- Replace your gasoline can if your can starts to rust. Rust and/or dirt in your gasoline will cause problems.
- If possible, store your tractor indoors and cover it to give protection from dust and dirt.
- Cover your tractor with a suitable protective cover that does not retain moisture. Do not use plastic. Plastic cannot breathe which allows condensation to form and will cause your tractor to rust.

**IMPORTANT:** NEVER COVER TRACTOR WHILE ENGINE AND EXHAUST AREAS ARE STILL WARM.

# TROUBLESHOOTING

| PROBLEM                          | CAUSE   | CORRECTION  |
|----------------------------------|---|---|
| Will not start                   | 1. Out of fuel.<br>2. Engine not "CHOKED" properly.<br>3. Engine flooded.<br>4. Bad spark plug.<br>5. Dirty air filter.<br>6. Dirty fuel filter.<br>7. Water in fuel.<br><br>8. Loose or damaged wiring.<br>9. Engine valves out of adjustment.   | 1. Fill fuel tank.<br>2. See "TO START ENGINE" in Operation section.<br>3. Wait several minutes before attempting to start.<br>4. Replace spark plug.<br>5. Clean/replace air filter.<br>6. Replace fuel filter.<br>7. Empty fuel tank and carburetor, refill tank with fresh gasoline and replace fuel filter.<br>8. Check all wiring.<br>9. Contact an authorized service center/department.  |
| Hard to start                    | 1. Dirty air filter.<br>2. Bad spark plug.<br>3. Weak or dead battery.<br>4. Dirty fuel filter.<br>5. Stale or dirty fuel.<br>6. Loose or damaged wiring.<br>7. Engine valves out of adjustment.  | 1. Clean/replace air filter.<br>2. Replace spark plug.<br>3. Recharge or replace battery.<br>4. Replace fuel filter.<br>5. Empty fuel tank and refill tank with fresh, clean gas.<br>6. Check all wiring.<br>7. Contact an authorized service center/department.  |
| Engine will not turn over        | 1. Brake pedal not depressed.<br>2. Attachment clutch is engaged.<br>3. Weak or dead battery.<br>4. Blown fuse.<br>5. Corroded battery terminals.<br>6. Loose or damaged wiring.<br>7. Faulty ignition switch.<br>8. Faulty solenoid or starter.<br>9. Faulty operator presence switch(es).   | 1. Depress brake pedal.<br>2. Disengage attachment clutch.<br>3. Recharge or replace battery.<br>4. Replace fuse.<br>5. Clean battery terminals.<br>6. Check all wiring.<br>7. Check/replace ignition switch.<br>8. Check/replace solenoid or starter.<br>9. Contact an authorized service center/department.   |
| Engine clicks but will not start | 1. Weak or dead battery.<br>2. Corroded battery terminals.<br>3. Loose or damaged wiring.<br>4. Faulty solenoid or starter.   | 1. Recharge or replace battery.<br>2. Clean battery terminals.<br>3. Check all wiring.<br>4. Check/replace solenoid or starter.   |
| Loss of power                    | 1. Cutting too much grass/too fast.<br>2. Throttle in "CHOKE" position.<br>3. Build-up of grass, leaves, trash under mower.<br>4. Dirty air filter.<br>5. Low oil level/dirty oil.<br>6. Faulty spark plug.<br>7. Dirty fuel filter.<br>8. Stale or dirty fuel.<br>9. Water in fuel.<br><br>10. Spark plug wire loose.<br>11. Dirty engine air screen/fins.<br>12. Dirty/clogged muffler.<br>13. Loose or damaged wiring.<br>14. Engine valves out of adjustment. | 1. Raise cutting height/reduce speed.<br>2. Adjust throttle control.<br>3. Clean underside of mower housing.<br>4. Clean/replace air filter.<br>5. Check oil level/change oil.<br>6. Clean and regap or change spark plug.<br>7. Replace fuel filter.<br>8. Empty fuel tank and refill tank with fresh, clean gas.<br>9. Empty fuel tank and carburetor, refill tank with fresh gasoline and replace fuel filter.<br>10. Connect and tighten spark plug wire.<br>11. Clean engine air screen/fins.<br>12. Clean/replace muffler.<br>13. Check all wiring.<br>14. Contact an authorized service center/department. |
| Excessive vibration              | 1. Worn, bent or loose blade.<br>2. Bent blade mandrel.<br>3. Loose/damaged part(s).  | 1. Replace blade. Tighten blade bolt.<br>2. Replace blade mandrel.<br>3. Tighten loose part(s). Replace damaged parts.  |

# TROUBLESHOOTING

| PROBLEM   | CAUSE  | CORRECTION  |
|---|--|---|
| <b>Engine continues to run when operator leaves seat with attachment clutch engaged</b> | 1. Faulty operator-safety presence control system.   | <p>1. Check wiring, switches and connections. If not corrected, contact an authorized service center/department.</p> <p> <b>CAUTION: DO NOT operate machine until problem is corrected.</b></p>  |
| <b>Poor cut - uneven</b>  | <p>1. Worn, bent or loose blade.</p> <p>2. Mower deck not level.</p> <p>3. Buildup of grass, leaves, trash under mower.</p> <p>4. Bent blade mandrel.</p> <p>5. Clogged mower deck vent holes from buildup of grass, leaves, and trash around mandrels.</p>  | <p>1. Replace blade. Tighten blade bolt.</p> <p>2. Level mower deck.</p> <p>3. Clean underside of mower housing.</p> <p>4. Replace blade mandrel.</p> <p>5. Clean around mandrels to open vent holes.</p>   |
| <b>Mower blades will not rotate</b>   | <p>1. Obstruction in clutch mechanism.</p> <p>2. Worn/damaged mower drive belt.</p> <p>3. Frozen idler pulley.</p> <p>4. Frozen blade mandrel.</p>   | <p>1. Remove obstruction.</p> <p>2. Replace mower drive belt.</p> <p>3. Replace idler pulley.</p> <p>4. Replace blade mandrel.</p>  |
| <b>Poor grass discharge</b>   | <p>1. Engine speed too slow.</p> <p>2. Travel speed too fast.</p> <p>3. Wet grass.</p> <p>4. Mower deck not level.</p> <p>5. Low/uneven tire air pressure.</p> <p>6. Worn, bent or loose blade.</p> <p>7. Buildup of grass, leaves, trash under mower.</p> <p>8. Mower drive belt worn.</p> <p>9. Blades improperly installed.</p> <p>10. Improper blades used.</p> <p>11. Clogged mower deck vent holes from buildup of grass, leaves, trash around mandrels.</p> | <p>1. Place throttle control in "FAST" position.</p> <p>2. Shift to slower speed.</p> <p>3. Allow grass to dry before mowing.</p> <p>4. Level mower deck.</p> <p>5. Check tires for proper air pressure.</p> <p>6. Replace blade. Tighten blade bolt.</p> <p>7. Clean underside of mower housing.</p> <p>8. Replace mower drive belt.</p> <p>9. Reinstall blades sharp edge down.</p> <p>10. Replace with blades listed in parts manual.</p> <p>11. Clean around mandrels to open vent holes.</p> |
| <b>Headlight(s) not working<br/>(if so equipped)</b>                                    | <p>1. Switch is "OFF".</p> <p>2. Bulb(s) or lamp(s) burned out.</p> <p>3. Faulty light switch.</p> <p>4. Loose or damaged wiring.</p> <p>5. Blown fuse.</p>  | <p>1. Turn switch "ON".</p> <p>2. Replace bulb(s) or lamp(s).</p> <p>3. Check/replace light switch.</p> <p>4. Check wiring and connections.</p> <p>5. Replace fuse.</p>   |
| <b>Battery will not charge</b>  | <p>1. Bad battery cell(s).</p> <p>2. Poor cable connections.</p> <p>3. Faulty regulator (if so equipped).</p> <p>4. Faulty alternator.</p>   | <p>1. Replace battery.</p> <p>2. Check/clean all connections.</p> <p>3. Replace regulator.</p> <p>4. Replace alternator.</p>  |
| <b>Loss of drive</b>  | <p>1. Freewheel control in "disengaged" position.</p> <p>2. Debris on steering plate (if equipped).</p> <p>3. Motion drive belt worn, damaged, or broken.</p> <p>4. Air trapped in transmission during shipment or servicing.</p> <p>5. Axle key missing.</p>  | <p>1. Place freewheel control in "engaged" position.</p> <p>2. See "CLEANING" in the Maintenance section.</p> <p>3. Replace motion drive belt.</p> <p>4. Purge transmission.</p> <p>5. Install axle key at rear wheel. See "TO REMOVE WHEEL" in the Service and Adjustments section.</p>  |
| <b>Engine "backfires" when turning engine "OFF"</b>                                     | 1. Engine throttle control not set between half and full speed (fast) position before stopping engine.   | 1. Move throttle control between half and full speed (fast) position before stopping engine.  |
| <b>Engine dies when tractor is shifted into reverse</b>                                 | 1. Reverse operation system (ROS) is not "ON" while mower or other attachment is engaged.  | 1. Turn ignition key to ROS "ON" position. See Operation section.   |

---

## **SERVICE NOTES**

---

**GENERAL:** Craftsman products are warranted to be free from defects in materials or workmanship for a specific time period as set-out below (the "Warranty Period"). Warranties extend to the original purchaser of a Craftsman product only. Purchases made through an online auction or through any website other than [www.sears.ca](http://www.sears.ca) are excluded. The relevant Warranty Period commences on the original date of purchase. Within this period, SEARS CANADA, Inc. will, at its sole option, repair or replace any products or components which fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts or labor, provided that the customer shall be responsible for any transportation cost.

**EXCLUSIONS:** This warranty does not cover failures due to normal wear, abuse, misuse, neglect (including but not limited to the use of stale fuel, dirt, abrasives, moisture, rust, corrosion, or any adverse reaction due to improper storage or use habits), improper maintenance or failure to follow maintenance guidelines and/or instructions, failure to operate the product in accordance with the owner's manual or any additional instructions or information provided at the time of purchase or in subsequent communications with the original purchaser, accident or unauthorized alterations or repairs made or attempted by others. Also excluded from warranty coverage - except as provided below - are the following: maintenance, adjustments, components subject to wear including but not limited to: cosmetic components, belts, blades, blade adapters, bulbs, tires, filters, guide bars, lubricants, seats, grips, recoil assy's, saw chains and bars, trimmer lines and spools, spark plugs, starter ropers and tines, and discoloration resulting from ultraviolet light. Any product missing the model and/or serial number identification label will be disqualified from coverage under this warranty.

**REPAIRS:** Repairs have a 90 day warranty. If the defective product is still within the Warranty Period, then the new warranty is 90 days from the date of repair or to the end of the original Warranty Period, whichever period is longer.

**DISCLAIMERS:** THE WARRANTIES AND REMEDIES CONTAINED HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER ORAL OR WRITTEN (OTHER THAN AS STATED HEREIN), AND WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO ANY. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM PROVINCE TO PROVINCE.

IN NO EVENT SHALL SEARS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM THE USE, MISUSE OR INABILITY TO USE THE PRODUCT OR FROM DEFECTS IN THE PRODUCT. THE EXCLUSIONS IN THIS PARAGRAPH SHALL NOT APPLY IN JURISDICTIONS WHERE APPLICABLE LAW DOES NOT ALLOW FOR THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. IN SUCH JURISDICTIONS, THIS PARAGRAPH SHALL NOT APPLY, BUT THE REMAINING PROVISIONS OF THIS DOCUMENT SHALL REMAIN VALID.

SEARS retains the exclusive right to repair or replace the product or offer a full refund of the purchase price at its sole discretion. SUCH REMEDY SHALL BE YOUR SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY.

**CUSTOMER RESPONSIBILITIES:** In addition to complying with all suggested maintenance guidelines and instructions, customers' obligations shall include but shall not be limited to: operating the product in accordance with the owner's manual or any additional instructions or information provided at the time of purchase or in subsequent communications to the purchaser from time to time, exhibit reasonable care in the use, operation, maintenance, general upkeep and storage of the product. Failure to comply with these requirements will void any applicable warranty.


**LIST OF APPLICABLE WARRANTY PERIODS:** The following list contains the applicable Warranty Period for your Craftsman product and is based on a combination of the type of product or component and the intended and actual use of the product or component:

1. **90 DAYS:** Craftsman products intended for use or actually used for commercial, institutional, professional or income-producing purposes
2. **2 YEARS:** Craftsman riding lawn mowers, yard and garden tractors, walk behind mowers, tillers, brush cutters, snow blowers, handheld blowers, backpack blowers, hedge trimmers and electrical products for noncommercial, nonprofessional, non-institutional, or non-income-producing use, except for those components which are part of engine systems manufactured by third party engine manufacturers for which the purchase has received an separate warranty with product information supplied at the time of purchase.
3. **1 YEAR:** Craftsman power cutters, stump grinders, pole pruners, gas chain saws, electric chain saws, trimmer attachments, baggers and pole saws for noncommercial, nonprofessional, non-institutional, or non-income-producing use.
4. **90 DAYS:** All defective batteries, which will be replaced during this 90-day Warranty Period.
5. **60 DAYS:** Additional Warranty Period of 60 days will apply to adjustments and worn products or components BUT DOES NOT INCLUDE WEAR OR ADJUSTMENTS for products used for commercial, institutional, professional or income-producing purposes. Wear items include but are not limited to: belts, blades, tires, spark plugs, air filters, chains, shear bolts, skid plates, scraper bars, drift cutters, ropes, tines, collection bags and pulleys.

As the Warranty Period runs from the date of purchase and NOT from the date that a product is delivered, opened, assembled or first used, please ensure during this time period that your product or component has been assembled and tested for correction operation regardless of when you intend to actually use it. Claims made after the Warranty Period has expired will not be honored.

**PROOF OF PURCHASE/DOCUMENTATION:** Warranty coverage is conditioned upon the original purchaser furnishing SEARS CANADA or its authorized third party service provider if applicable, with the original sales receipt or other adequate written proof of the original purchase date and identification of the product. In the event that the original purchaser is unable to provide a company of the original sales receipt, SEARS CANADA Inc. reserves the right to determine in its sole discretion what other written proof of the original purchase date and identification of the product is acceptable.

# SUGGESTED GUIDE FOR SIGHTING SLOPES FOR SAFE OPERATION



1. Fold this page along dotted line indicated above.
2. Hold page before you so that its left edge is vertically parallel to a tree trunk or other upright structure.
3. Sight across the fold in the direction of hill slope you want to measure.
4. Compare the angle of the fold with the slope of the hill.

# Get it fixed, at your home or ours!

Just Call:

**1-800-4-MY-HOME<sup>®</sup>**

(1-800-469-4663)

24 hours a day, 7 days a week

For the repair of major brand appliances **in your own home...**  
no matter who made it, no matter who sold it!

For your nearest **Sears Parts and Service** location,  
to bring in products like vacuums, lawn equipment and electronics.

For **Sears Parts & Service**, to order the replacement parts,  
accessories and owner's manuals that you need to do-it-yourself.

[www.sears.ca](http://www.sears.ca)

---

To purchase or inquire about a Sears Maintenance Agreement, call:

**1-800-361-6665**

9 a.m. – 11 p.m. Mon. – Fri., EST, 9 a.m. – 4 p.m. Sat.

---

Pour service en français:

**1-800-LE-FOYER<sup>MC</sup>**

(1-800-533-6937)

[www.sears.ca](http://www.sears.ca)



® / ™ Trademarks of Sears Brands Management Corporation used under license by Sears Canada

MD Marque déposée / MC Marque de commerce de Sears Brands Management Corporation utilisée en vertu d'une licence de Sears Canada

® / TM Trademarks of Sears Brands Management Corporation used under license by Sears Canada  
MD Marque déposée / MC Marque de commerce de Sears Brands Management Corporation utilisée en vertu d'une licence de Sears Canada



**www.sears.ca**  
**(1-800-469-4663)**  
**1-800-4-MY-HOME®**  
 For service in English:

de 9 h à 23 h du lundi au vendredi (HNE), de 9 h à 16 h le samedi  
**1-800-361-6665**

Pour acheter ou demander des renseignements  
 sur un contrat d'entretien Sears, téléphonez au:

**www.sears.ca**

Pour connaître le no. de téléphone du **Service des pièces et de l'entretien**  
 Sears afin de commander les pièces de rechange, accessoires et  
 manuels d'instructions requis pour effectuer vous-même les réparations.  
 Pour connaître l'emplacement du **Service des pièces et de l'entretien**  
 Sears le plus proche afin d'apporter à l'atelier des produits tels que  
 des aspirateurs, tondeuses à gazon ou appareils électroniques.



Pour la réparation des appareils électroménagers de grandes marques  
 à votre domicile ... peu importe le fabricant ou le détaillant!

24 heures par jour, 7 jours par semaine  
**(1-800-533-6937)**  
**1-800-LE-FOYER**  
 Téléphonez au:

Faites-le réparer, à domicile ou à l'atelier!

# GUIDE SUGGÈRE POUR L'ÉVALUATION DES PENTES AFIN D'AMÉLIORER LA SÉCURITÉ D'UTILISATION

33



1. Pliez cette page suivant les pointillées, comme précédemment.
2. Tenez cette page devant vous, avec le côté gauche parallèle à un tronc d'arbre ou à tout autre structure verticale.
3. Regardez à travers la pliure dans la direction de la pente que vous entendez mesurer.
4. Comparez l'angle de la pliure avec la pente de la colline.

**PREUVE D'ACHAT ET DOCUMENTS:** La protection de la garantie est conditionnelle à la présentation par l'acheteur initial, à Sears Canada ou à son fournisseur de service autorisé si y a lieu, de la facture ou de toute autre preuve d'achat appropriée indiquant la date de l'achat et désignant l'endroit où il a été fait. Dans le cas où l'acheteur initial se réunit dans l'impossibilité de fournir une copie de sa facture, Sears Canada peut réservé le droit d'établir, à sa seule discrétion, quelle autre preuve écrite de la date d'achat initial et de la désignation du produit est acceptable.

Présentées après l'expérimentation de la garantie ne seront pas acceptées.

Etant donné que la période de garantie débute à la date d'achat et NON à la date à laquelle le produit est livré, l'emballage ouvert et l'appareil asssemblé ou utilisé la première fois, assurez-vous que votre produit ou composant est asssemblé et mis à lessal pour en vérifier le bon fonctionnement, quel que soit le moment où vous prévoyez commencer à utiliser réellement. Les reclamations

barres de racelage, coupe-congères, cordons, dents, sacs collecteurs et pollués.

**5. 60 JOURS** - Une période de garantie additionnelle de 60 jours s'applique pour le remplacement ou l'usure des produits ou de composants MAIS CETTE GARANTIE EXCLUT L'USURE ET LE REGLAGE de produits utilisés à des fins commerciales, institutionnelles, professionnelles ou lucratives. Les articles sujets à l'usure englobent, sans y restreindre : les courroies, lames, pneus, bougies, filtres à air, chaînes, boulons de visaillement, plaques de protection, barres de raccordage, coupe-congères, cordons, dénrs, sacs collecteurs et poules.

4. **90 JOURS** – toutes les personnes déclarées, qui sont dans l'impossibilité pendant une période de 90 jours.

**3. 1 AN** - Produits de mature Craftsmen Survival : outreux électriques, gyroscopes de souche, embranchements, scies à chaîne à essence, scies à chaîne électriques, accessoires de taille-bordures, sacs et sciés à long manche utilisées à des fins non commerciales, non professionnelles, non institutionnelles, non lucratives.

**2. 2 ANS** - Les produits de maturé Craftsmen suivants: tondeuses à conducteur porte, tracteurs de jardin, tondeuses à bordures et produits électriques, souffleuses portatives, souffleuses d'herbes, souffleuses dorsales, taille-bordures et produits à moteurs, débroussailleurs, souffleuses à neige, souffleuses portatives, souffleuses d'herbes, compasants à moteur électrique pour des tirs pour lesquels l'acheteur a régulé une garantie séparée ainsi que des systèmes de moteur fabriqués par le producteur au moment de l'achat.

1. **90 JOURS** - Produits Craftsman devant être ou étant effectivement utilisés à des fins commerciales, institutionnelles, prosessionIduelles ou lucratives.

produits Craftsman qu'elle couvre; la période accordee tient compte du type de produit ou de composants et du type d'utilisation prévue ou effective de l'appareil ou du composant;

**LISTE DES PÉRIODES DE GARANTIE APPLICABLES:** La liste ci-dessous indique la période de garantie applicable aux divers

**RESPONSABILITÉS DU CLIENT:** En plus d'observer toutes les consignes et directives d'entretien, le client doit s'acquitter, entre autres, des obligations suivantes: utiliser le produit conformément à la notice d'entretien et aux directives ou informations additionnelles fournies à l'acheteur au moment de l'achat ou à l'occasion de communications susmentionnées; faire preuve d'un soin raisonnable pour l'utilisation, l'entretenir général, le maintenir en bon état et l'entreposer dans un endroit sûr et stable pour l'utilisation, le fonctionnement, l'entretien général, le maintien en bon état et l'entreposage du produit. Le manquement à ces obligations entraînera une annulation de la garantie applicable.

SEARS NE POURRA, EN AUCUN CAS ÊTRE TENUE RESPONSABLE DE TOUT DOMMAGE ACCÉSsoIRE, SPÉCIAL, INDIRECT OU CONSÉCUTIF, AU RÉSULTAT DE L'UTILISATION, DU MÉSUrage OU DE L'INCAPACITÉ D'UTILISER LE PRODUIT OU QUICoULERAIT DEFFECTUOSITÉS DU PRODUIT. LES EXCLUSIONS DU PRéSENT PARAGRAPH NE S'APPLIQUENT PAS DANS LES TERRITOIRES OU LA LOI NE PERMET PAS LEXCLUSION DES DOMMAGES ACCESSOIRES OU CONSÉCUTIFS. DANS CES TERRITOIRES, LE PRéSENT PARAGRAPHE SERA SANS EFFET, MAIS LES AUTRES DISPOSITIONS DU PRéSENT DOCUMENT RÉGONT VALIDES.

**PAR LA GARNITURE** : Les tapisseries sont garnies par deux garnitures placées de part et d'autre de la date de la garniture. Ces deux garnitures sont placées de part et d'autre de la date de la garniture.

**PRÉPARATIONS** : Les préparations sont garanties pendant une période de 90 jours. Si le produit défectueux est toujours dans la boîte d'origine, il sera échangé contre un autre produit identique.

**EXCLUSIONS:** La présente garantie ne couvre pas les détecteurs dus à l'usure normale, utilisation inappropriate ou abusive, la réglage incorrect (y compris sans y restreindre), utilisation excessive éventuelle, la corrosion ou tout autre effet indésirable, imprévisible à un temps donné ou à des habitudes d'utilisation inhabituelles, un mauvais entretien, le non-respect des consignes d'utilisation, l'utilisation non destinée à l'application des critères de vente, compositions esthétiques courantes, anomalies, déformations de la lame, filtres, barres de guidage, lubrifiants, silex, éléments en plastique, verre et autres, composants sujets à l'usure, qui comprennent les éléments suivants : - les éléments de communication subordonnés avec lui, un accident ou encore une modification de la couleur de la garniture - sauf indication formelle ci-dessous effectuées ou tenues par d'autres. Soit également exclus de la couverture de la garniture - sauf indication formelle ci-dessous effectuées ou tenues par d'autres.

**GENERALITES :** Les produits Craftsman sont garantis contre tout défaut de fabrication pendant une période de temps précis, telle qu'établie ci-dessous (la « Période de garantie »). En outre, cette garantie est offerte uniquement à l'acheteur initial du produit Craftsman. Les achats effectués par l'entremise d'un encan en ligne ou sur tout site Web autre que www.sears.ca sont exclus. La période de garantie débute à la date de l'achat initial. Au cours de cette période, Sears Canada paiera les frais de main-d'œuvre, à sa seule discrétion ou le remplacement sera effectuée pour le client sans frais de pièces ni de main-d'œuvre, à condition que le client prenne à sa charge les frais de transport.



| PROBLEME  | CAUSE  | CORRECTION   |
|---|--|--|
| Le moteur marche-tourneuse avec l'embranchement d'accèssoire engagé                     | ATTENTION : n'utilisez pas la machine avant d'avoir corrigé le problème.   | 1. Verifiez le câblage, les interrupteurs et les connexions. Si le problème n'est pas corrigé, contactez un centre d'entretien autorisé. |
| Les lames de coupe inégale  | 1. La lame est usée, tordue ou lâche.  | 1. Remplacez la lame. Serrez le boulon de lame.  |
| Mauvaise décharge humide  | 1. La vitesse de moteur est trop lente.  | 1. Déplacez la commande des gaz à la position rapide (FAST).   |
| Les lames de tourneuse  | 1. Une obstruction dans le mécanisme d'embranchement.  | 1. Enlevez l'obstruction.  |
| La batterie ne charge pas   | 1. Malvaîs éléments(s) de la batterie.   | 1. Remplacez la batterie.  |
| Une perte de charge pas   | 1. Malvaîs élément(s) de la batterie.  | 1. Remplacez toutes les connexions.  |
| Une perte d'entraînement  | 1. La commande de la roue libre est en position débrayée.  | 1. Mettre la commande de la roue libre en position engagée.  |
| Pétralade au silence  | 1. La commande des gaz de moteur n'est pas dans la position intermédiaire (entre rapide (FAST) et lent) avant de couper le moteur. | 1. Déplacez la commande des gaz comme une commande des gaz dans la position ON.  |
| La tondeuse (ou son accèssoire) s'arrête lorsqu'il est placé avec le siège d'accèssoire | 1. Toumez le ROS dans la position ON.  | 1. Système de fonctionnement en marche arrêtré (ROS) est dans la position OFF.   |

# GUIDE DE DÉPANNAGE

| PROBLEME                                  | CAUSE  | CORRECTION  |
|---|--|---|
| Le moteur refuse de démarrer              | 1. Sans essence.<br>2. Le moteur n'est pas démarré à froid correctement.<br>3. Le moteur est noyé.<br>4. Mauvaise bougie d'allumage.<br>3. Attendre quelques minutes avant d'essayer de démarrer.<br>2. "TEUR", dans la section fonctionnement.<br>1. Remplissez le réservoir d'essence.                                       | 1. Filtre à air sale.<br>2. Batterie faible ou à plat.<br>3. Batterie faible ou à plat.<br>4. Remplacez la bougie d'allumage.<br>5. Nettoyez/remplacez le filtre à air.<br>3. Attendez quelques minutes avant d'essayer de démarrer.<br>2. "TEUR", dans la section fonctionnement.<br>1. Remplissez le réservoir d'essence. |
| Démarrage difficile                       | 1. Filtre à air sale.<br>2. Batterie faible ou à plat.<br>3. Batterie faible ou à plat.<br>4. Remplacez la bougie d'allumage.<br>5. Nettoyez ou remplacez le filtre à air.<br>3. Attendez quelques minutes avant d'essayer de démarrer.<br>2. "TEUR", dans la section fonctionnement.<br>1. Remplissez le réservoir d'essence. | 1. Filtre à air sale.<br>2. Mauvaise batterie.<br>3. Batterie faible ou à plat.<br>4. Remplacez la bougie d'allumage.<br>5. Nettoyez ou remplacez la batterie.<br>3. Débrayez l'embarayage d'accès.<br>2. Débrayez l'embarayage n'est pas basée.<br>1. Appuyez sur la pédale de frein/embrayage.                            |
| Moteur ne tourne pas au ralenti           | 1. La pédale de frein/embrayage n'est pas basée.<br>2. L'embarayage n'est pas basée.<br>3. Batterie faible ou à plat.<br>4. Remplacez ou remplacez la batterie.<br>3. Débrayez l'embarayage d'accès.<br>2. Débrayez l'embarayage d'accès.<br>1. Appuyez sur la pédale de frein/embrayage.                                      | 1. La pédale de frein/embrayage n'est pas basée.<br>2. L'embarayage n'est pas basée.<br>3. Batterie faible ou à plat.<br>4. Remplacez ou remplacez la batterie.<br>3. Débrayez l'embarayage d'accès.<br>2. Débrayez l'embarayage d'accès.<br>1. Appuyez sur la pédale de frein/embrayage.                                   |
| Le moteur ne tourne pas avec essence      | 1. Filtre à air sale.<br>2. Batterie faible ou à plat.<br>3. Batterie faible ou à plat.<br>4. Remplacez la bougie d'allumage.<br>3. Remplacez ou remplacez la batterie.<br>2. Remplacez le filtre à air.<br>1. Remplacez le filtre à air.  | 1. Filtre à air sale.<br>2. Batterie faible ou à plat.<br>3. Batterie faible ou à plat.<br>4. Remplacez la batterie.<br>3. Remplacez la batterie.<br>2. Remplacez le filtre à air.<br>1. Remplacez le filtre à air.   |
| Demarrage difficile                       | 1. Filtre à air sale.<br>2. Batterie faible ou à plat.<br>3. Batterie faible ou à plat.<br>4. Remplacez la bougie d'allumage.<br>3. Remplacez ou remplacez la batterie.<br>2. Remplacez le filtre à air.<br>1. Remplacez le filtre à air.  | 1. Filtre à air sale.<br>2. Mauvaise batterie.<br>3. Batterie faible ou à plat.<br>4. Remplacez la bougie d'allumage.<br>3. Remplacez ou remplacez la batterie.<br>2. Remplacez le filtre à air.<br>1. Remplacez le filtre à air.   |
| Moteur ne tourne pas avec essence         | 1. Filtre à air sale.<br>2. Batterie faible ou à plat.<br>3. Batterie faible ou à plat.<br>4. Remplacez la bougie d'allumage.<br>3. Remplacez ou remplacez la batterie.<br>2. Remplacez le filtre à air.<br>1. Remplacez le filtre à air.  | 1. Filtre à air sale.<br>2. Batterie faible ou à plat.<br>3. Batterie faible ou à plat.<br>4. Remplacez la batterie.<br>3. Remplacez ou remplacez la batterie.<br>2. Remplacez le filtre à air.<br>1. Remplacez le filtre à air.  |
| Il y a un défaut de moteur ne démarre pas | 1. Batterie faible ou à plat.<br>2. Les bornes de batterie sont corrodées.<br>3. Il y a une accumulation d'herbe, de feuilles, etc<br>debris sous la tondueuse.  | 1. Batterie faible ou à plat.<br>2. Les bornes de batterie sont corrodées.<br>3. Il y a une accumulation d'herbe, de feuilles, etc<br>debris sous la tondueuse.   |
| Le moteur manque de puissance             | 1. Vous tondez trop d'herbe/la vitesse de coupe plus haute ou réduisez la vitesse.<br>2. La commande des gaz est à la position étranglée.<br>3. Il y a une accumulation d'herbe, de feuilles, etc<br>debris sous la tondueuse.   | 1. Vous tondez trop rapidement.<br>2. La commande des gaz est à la position étranglée.<br>3. Il y a une accumulation d'herbe, de feuilles, etc<br>debris sous la tondueuse.   |
| Vibrations excessives de la tondueuse     | 1. La lame est usée, torde, ou lâche.<br>2. Un mandrin de lame est tordeu.<br>3. Des pièces sont lâches ou endommagées.  | 1. Remplacez la lame.<br>2. Remplacez le mandrin de lame.<br>3. Serrez les pièces lâches. Remplacez les pièces endommagées.   |

# GUIDE DE DÉPANNAGE



# REVISION ET REGLAGES

POUR REMPLACER L'AMPOULE DES PHABES

# TRANSMISSION

## ENLÈVEMENT/REPLACEMENT

Si votre transmission doit étre reprise pour un autre endroit ou pour être remisée, elle doit étre purgée après avoir éte réinstallée et avant de faire fonctionner le tracteur. Voir "PURGEZ LA TRANSMISSION" dans la section UTILISATION de ce manuel.

MOTEUR

**POUR REGLEER LA COMMANDE DU STARTER**

La commande du starter a été prééglagée à l'usine et un réglage ne devrait pas être nécessaire. Si un réglage est nécessaire, voir le manuel du moteur.

**POUR RÉGLER LE CÂBLE DE LA COMMANDE DES GAZ**

Le manuel du moteur.  
Le communiqué des gars a été prélevé à la suite d'un enregistrement de l'activité des passagers dans le bus. Si un régalage est nécessaire, voilà

#### POUR RÉGLER LA COMMANDE DU STARTER

**POUR REGLEER LA COMMANDE DU STARTER**

La commande du starter a été prééglagée à l'usine et un réglage ne devrait pas être nécessaire. Si un réglage est nécessaire, voir le manuel du moteur.

POUR ENLEVER LE CAPOU ET LA CALANDE (Voir la Fig. 46)

- POUR REMPLACER LE FUSIBLE**

Porte-fusible est situé directement derrière le tableau de bord.

Remplacez par un fusible enfilchable de type automobile, de 20A. Le

**VERROUS ET RELAIS**

  - Soulevez le capot.
  - Dégagiez de la douille d'amphoule de l'orifice à l'arrière de la calandre.
  - Retirez l'amphoule dans la douille et posez à fond la douille d'amphoule dans l'orifice à l'arrière de la calandre.
  - Fermez le capot.
  - Un câblage desserré ou varié peut être la cause du mauvais fonctionnement, de l'arrêt ou du non-démarrage du tracteur.
  - Vérifiez le câblage. Voir le schéma du câblage électrique dans la section Pièces de Rechange.
  - Porte-fusible est située directement derrière le tableau de bord.

VERROUS ET RELAIS

- Degaggez de la douille d'amphoule et l'ommez à l'aide de la calandre.
  - Remisitez l'amphoule dans la douille et posez à fond la douille d'amphoule dans l'orifice à l'arrière de la calandre.
  - Fermez le capot.

## **POOR EMPLOYEE LEADERSHIP**

- Un câblage desserré ou varié peut être la cause du mauvais fonctionnement, de l'arrêt ou du non-démarrage du tracteur.
  - Vérifiez le câblage. Voir le schéma du câblage électrique dans la section Pièces de Rechange.

CALANDRE (Voir la Fig. 46)

- POUR ENI EVERLÉ CAPOT ET LA**  
Remplissez par un tissu démicelable de type automobile, de ZU2. Le porte-fusible est situé derrière le tableau de bord.





Fig. 46

Fig. 45



- Levrez le capot.
- Enlevez le protecteur des bornes.
- Prenez le câble de batterie ROUGE et enlevez la batterie du tracteur.
- Installez la nouvelle batterie en placant les bornes au même endroit que l'ancienne batterie.
- Prenez le câble de batterie ROUGE et enlevez la batterie du tracteur.
- Installez la nouvelle batterie le câble de batterie ROUGE à la borne positive (+) avec un boulon H et écrou à taquets qui restent.
- Branchez le câble de masse de batterie NOIR à la borne négative (-) avec le câble de masse de batteries qui restent.
- Serrez à fond.
- Fermez les portes d'accès aux bornes.
- Fermez le capot.

**Avertissement:** Ne court-circuitez pas les bornes de batterie avec une clé ou autres objets qui toucheraient simultanément deux bornes. Avant d'installer la batterie, enlevez tous les bijoux, les bracelets de montre, les bagues métalliques, etc. Il faut brancher la borne positive en premier pour prévenir les étincelles causées par une mise à la terre accidentelle.



**REPLACER LA BATTERIE (Voir la Fig. 45)**




Fig. 44

- Si votre batterie est trop faible pour démarrer le moteur, elle devrait être rechargée. (Voir "BATTERIE" dans la section Entrien de ce manuel).
- Si vous utilisez des câbles de survoltage pour un démarrage d'urgence, voici le procédé à suivre:
  - ATTACHEZ LES CÂBLES DE DEMARRAGE -
  - BRANCHEZ CHAQUE EXTREMITE DU CÂBLE ROUGE À LA BORNE (A-B) DE NE PAS COURIR CÔTÉ BATTERIE (EN LAISANT BIEN ATTENTIR DE LA MASSÉ).
  - BRANCHEZ UNE EXTREMITE DU CÂBLE NOIR À LA BORNE (C) NEGATIF DE LA BATTERIE COMPLÈTEMENT.
  - BRANCHEZ L'AUTRE EXTREMITE DU CÂBLE NOIR (D) AU CHÂSSIS ET DE LA MASSÉ. MAINTENEZ LES CÂBLES LOIN DU RÉSERVOIR D'ESSANCE ET DE LA BATTERIE.
  - DÉBRANCHEZ ENSUITE LE CÂBLE ROUGE DES DEUX BATTERIES.
  - DÉBRANCHEZ PREMIÈREMENT LE CÂBLE NOIR DU CHÂSSIS ET ENSUITE DE LA BATTERIE CHARGÉE.
  - DÉBRANCHEZ ENFIN LE CÂBLE ROUGE DES DEUX BATTERIES.

**POUR DEMARRER LE MOTEUR AVEC UNE BATTERIE FAIBLE (Voir la Fig. 44)**


**Avertissement:** Les batteries au plomb et à l'acide produisent des gaz explosifs. Gardez les étincelles, les flammes, les cigarettes, etc. loin des batteries. Portez toujours des lunettes protectrices lorsqu'une batterie est prête d'une batterie.



## REVISIION ET RÉGLAGES




Fig. 39



- REMARGUE** : Chaque tour complète de l'écrou de réglage modifie la hauteur de la tondueuse d'environ 3,1 mm (1/8 po.). Verifiez de nouveau les mesures, ajustez si nécessaire jusqu'à ce que la pointe avant de la lame est 3,1 to 12,7 mm (1/8 à 1/2 po), inférieure à la pointe arrière.

Maintenez l'écrou de réglage en place avec la clé et serrez le contre-écrou fermement contre l'écrou de réglage.

Fig. 41




- Si la pointe avant de la lame n'est pas de 3,1 to 12,7 mm (1/8 à 1/2 po), plus basse que la pointe arrière, allez à l'avant du serrage (A) pour dépasser l'écrou de réglage (B).

A l'aide d'une clé ajustable ou de 1 1/16", dévissez l'écrou de serrage (A) pour dépasser l'écrou de réglage (B).

A l'aide d'une clé ajustable ou de 3/4", faites tourner l'écrou de réglage de la bille avant (B) dans le sens horaire (→) (laisser pour soulever l'avant de la lame dans le sens antihoraire (←) pour abaisser l'avant de la lame dans le sens antihoraire (→) (dévisser) pour abaisser l'avant de la lame.

Fig. 4



- Soulevez la tondueuse à sa position la plus haute. Placez n'impose de quelle lame de fagot à ce que la pointe soit vers l'avant. Mesurez la distance (B) au sol à la pointe avant et la pointe arrière de la lame.

**ATTENTION:** Les lames sont tranchantes. Protégez vos mains en portant des gants ou en enveloppez les lames d'un tissu épais.


Pour obtenir de meilleurs résultats, les lames de la tondeuse doi- vent être ajustées de sorte que la pointe avant est 3,1 à 12,7 mm (1/8 à 1/2 po), inférieure à la pointe arrière lorsque la tondue est à sa position la plus élevée.

**IMPORТАНТ:** La plateforme doit être au même niveau qu'un écran de PC.

POUR AJUSTER LE NIVEAU LA TONDEUSE

# REVISION ET REGLAGES

Fig. 37



Soulevez le levier de levage à sa position la plus haute.

**ATTENTION:** La tige de tension de la courroie possède un mécanisme à ressort. Tenez ferme-ment la tige et enclez-la lentement.

- **INSTALLEZ LA COURROIE DE LA LAME DE LA TONDEUSE**
    - Installez la courroie autour des poulies des mandrins (R) et toutes les poulies de tension (V).
  - **PORTANT : Assurez-vous que la courroie est bien en place**
    - Installez la courroie sur la poulie de l'embryagée électrique (M).
    - Autour des poulies des mandrins (R) et tel que montré.
    - Installez la courroie autour des poulies des mandrins (R) et toutes les poulies de tension (V).
  - **DANS LES SILLONS DES POULIES DE LA COURROIE EST EN PLACE**
    - Remplacez les couvercles des mandrins gauche et droit (Q).
    - Vissez fermement toutes les vis.
    - Enclez la tige de tension de la courroie (K) de la manette de verrouillage (L).


**ATTENTION:** La tige de tension de la courroie possède un mécanisme à ressort. Tenez ferme-ment la tige et relaxez-la lentement.

- POUR REMPLACER LA COURROIE DE LA LAME DE LA TONDEUSE
  - LAME DE LA TONDEUSE (Voir la Fig. 37)
  - STATIONNEZ le tracteur sur une surface de niveau. Actionnez le frein de stationnement.
  - Abaissez le levier le levage à sa position la plus basse.
  - Déagarez la tige de tension de la courroie (k) de la manette de verrouillage (l).

POUR REMPLACER LA COURROIE DE LA  
TAMBORIEUSE VIGRÉE 32

POUR EVITER DES DOMMAGES SERIEUX, AVANT DE FAIRE TOUS LES REVIS-  
SAGES OU DEGLACES

Fig. 36



Suivez le procédé décrit dans la section "INSTALLER LA TON-

POUR INSTALLER LA TONDEUSE

- A la droite de la tondueuse, desengagiez la barre anti-tourris (S) du support arrière droit de la tondueuse (D) – retirez le ressort-arrestoir et la rondelle puis tirez vers vous jusqu'à ce que la barre tombe de l'officine du support.
  - Tournez le volant dans le sens inverse pour dégager la clé.
  - Glissez la tondueuse du dessous du tracteur.

**ATTENTION:** Après avoir désengagé les billels, le levier d'accroccharge possède un mécanisme à ressort. Tenez fermement le levier lorsqu'e vous changez sa position.


- **Suspension à bras** : le système de suspension est constitué d'un ressort et d'un amortisseur. Le bras oscillant (A) est fixé au châssis et au ressort. L'autre extrémité du bras est articulée avec l'essieu et la roue. L'amortisseur (B) est fixé entre le bras et le châssis.
  - **Suspension à tondueuse** : le système de suspension est constitué d'un ressort et d'un amortisseur. La tondueuse (C) est fixée au châssis et au ressort. L'autre extrémité de la tondueuse est articulée avec l'essieu et la roue. L'amortisseur (D) est fixé entre la tondueuse et le châssis.
  - **Suspension à bras oscillant et à tondueuse combinée** : ce système combine les deux types précédents. Il utilise un bras oscillant (E) et une tondueuse (F). Le bras oscillant est fixé au châssis et au ressort. L'autre extrémité du bras est articulée avec l'essieu et la roue. La tondueuse est fixée au bras oscillant et au ressort. L'autre extrémité de la tondueuse est articulée avec l'essieu et la roue. L'amortisseur (G) est fixé entre la tondueuse et le châssis.

**ATTENTION:** La tige de tension de la courroie possède un mécanisme à ressort. Tenez fermement la tige et relâchez-la lentement.

- Placez l'embarayage à la position débranchée.
  - Abaissez le levier le levage à sa position la plus basse.
  - Dégaggez la tige de tension de la courroie (k) de la manette de verrouillage (L).


POUR ENLEVER LA TONDEUSE (Voir Fig. 36)

## REVISION ET REGLAGES



9. Assurez-vous que la commande d'embryagée d'accèssoire à la pomme de percer au tracteur de secher avant de remiser.
8. Assurez-vous que la position "DEBRAVÉE". Arrêtez le moteur Couppez l'eau. Coudissez le tracteur vers un endroit sec, de préférence bâtonnée ou pavé. Déplacez-vous le contrebas d'embryagée d'accèssoire à la position "EMBRAVÉE". Pour éliminer l'excès de pression dans le raccord de lavage, appuyez sur la pomme de percer jusqu'à ce qu'il ne soit plus nécessaire de la maintenir.
7. Déplacez-vous le gantole d'embryagée d'accèssoire à la position "DEBRAVÉE". Mettez la clé de contact en position STOP pour couper le moteur. Fermez le robinet d'eau.
6. Assurez-vous le gantole d'embryagée d'accèssoire à la position "EMBRAVÉE". Ne quittez pas le siège de l'opérateur pendant que vous nettoyez le plateau soit nettoyé.
5. Prenez place sur le siège du tracteur, relâchez le moteur et mettez le levier d'accélération en position rapide ( "Fast").
4. Ouvrez le robinet d'eau.
- IMPORTANT : Tirer le tuyau d'arrosage pour vous assurer que le raccordement est sécurisé.

Fig. 35




1. Conduisez le tracteur vers un endroit plat et dégagé de votre pelouse, suffisamment près pour atteindre le robinet d'eau destiné au tuyau d'arrosage de votre jardin.
2. Assurez-vous le gantole d'embryagée d'accèssoire à la position "DEBRAVÉE", serrez le frein de stationnement et coupez le moteur.
3. Tirez sur la collerette de blocage de l'adaptateur de la base de coupe de la tondeuse. Relâchez la collerette de blocage du plateau de coupe située à l'extrême gauche du plateau de lavage du tracteur puis posez l'adaptateur sur le raccord de lavage de la base de lavage puis serrez la collerette de l'adaptateur sur la base de lavage.
- IMPORTANT : Assurez-vous que la goulotte d'évacuation du tracteur N'EST PAS DIRIGÉE vers la maison, les voitures en stationnement etc. Retirez la goulotte du ramasse-heure ou le couvre-pièces événementiel fixe.
5. Prenez place sur le siège du tracteur et dégagé de votre pelouse, suffisamment près pour atteindre le robinet d'eau destiné au tuyau d'arrosage de votre jardin.
- IMPORTANT : Assurez-vous que la goulotte d'évacuation du tracteur N'EST PAS DIRIGÉE vers la maison, les voitures en stationnement etc. Retirez la goulotte du ramasse-heure ou le couvre-pièces événementiel fixe.
2. Assurez-vous le gantole d'embryagée d'accèssoire à la position "DEBRAVÉE", serrez le frein de stationnement et coupez le moteur.
3. Tirez sur la collerette de blocage de l'adaptateur de la base de coupe de la tondeuse. Relâchez la collerette de blocage du plateau de coupe située à l'extrême gauche du plateau de lavage du tracteur puis posez l'adaptateur sur le raccord de lavage de la base de lavage puis serrez la collerette de l'adaptateur sur la base de lavage.
4. Ouvrez le robinet d'eau.
- IMPORTANT : Tirer le tuyau d'arrosage pour vous assurer que le raccordement est sécurisé.

## RACCORD DE LAVAGE DU PLATEAU DE COUPE (Voir Fig. 35)

# ENTRETIEN

- Conservez la propriété de la finition et des routes en élevant  
soligneuvement l'essence, huile etc.
  - Protégez les surfaces peintes avec une cire d'auto.

Fig. 34




**ATTENTION : Evitez les points de princem et les pièces mobiles.**

- Nettoyez le moteur, la batterie, le siège, et la finition, etc. de toutes les matières étrangères.
- Nettoyez tout le trace de débris sur la plaque de direction.
- Les débris peuvent empêcher le mouvement de l'arbre de pédale de frein/dembryagé, provoquant le glissement de la courroie avec perte de neutralité. Voir Fig. 34.

NETTOLYAGE

Fig. 33



- Le filtre d'essence devrait étre remplacé au moins chaque saison.
  - Si le filtre d'essence est bouché et obstrue l'écoulement d'essence au carburateur, il faut le remplacer.
  - Quand le moteur est froid, enlevez le filtre et bouchez les trougous de conduite d'essence.
  - Posez le nouveau filtre dans la conduite d'essence avec la flèche pointant vers le carburateur.
  - Assurez-vous qu'il n'y ait pas défauts de la conduite d'essence et que les brides de serrage soient bien placées.
  - Nettoyez immédiatement l'essence renversée.

## FILTRE D'ESSENCE INSTALLE EN LIGNE

## FILTRE D'ESSENCE INSTALLE EN LIGNE

Remplacez les bougies d'allumage au début de chaque saison ou après toutes 100 heures d'utilisation selon qui présente le meilleur rendement. Pour ce faire, démontez la tête de bougie d'allumage et remplacez-la par une autre de la même tension.

BOUGIE D'ALLUMAGE

**SILENCEUX**

Si vous utilisez le moteur avec un tamis d'air ou des ailettes de refroidissement d'air de refroidissement ou des surfaces extérieures si nécessaires, assurez-vous que les surfaces extérieures sont bien nettoyées et les autres déflecteurs d'air de refroidissement sont bien dégagées.

**REMARQUE:** Si vous utilisez le moteur avec un tamis d'air ou des ailettes de refroidissement d'air de refroidissement ou des surfaces extérieures si nécessaires, assurez-vous que les surfaces extérieures sont bien nettoyées et les autres déflecteurs d'air de refroidissement sont bien dégagées.

Toutefois, les 100 heures d'utilisation (plus souvent dans des conditions possibles) peuvent entraîner une surchauffe du moteur si toutes les surfaces extérieures du moteur sont propres en tout temps.

Pour assurer le refroidissement correct, assurez-vous que le tamis d'air, les ailettes de refroidissement, et les autres surfaces extérieures du moteur sont propres en tout temps.

Assurez-vous que le refroidissement correct est atteint lorsque le moteur fonctionne à température normale.

Si le moteur chauffe excessivement, il peut être nécessaire de remplacer les ailettes de refroidissement ou de remplacer les surfaces extérieures du moteur.

Si le moteur chauffe excessivement, il peut être nécessaire de remplacer les ailettes de refroidissement ou de remplacer les surfaces extérieures du moteur.

SYSTÈME DE VENTILATION

**NETTOYER LE TAMIS D'AIR**

Le tamis à air est placé sur l'arriére d'un séchoir. Il suffit de dépasser du moteur. Le tamis à air doit être nettoyé sans saleté ni saleté pour éviter que la surface de l'air ne se dégrade. Nettoyez avec une brosse métallique ou de l'air comprimé afin de supprimer la saleté et les fibres de gomme séchée tenaces.

NETTOYER LE TAMIS D'AIR

Votre moteur ne fonctionne pas correctement avec un filtre à air sale. Nettoyez le filtre à air plus souvent si il utilise des endroits très poussiéreux ou sales. Voir le manuel du moteur.

**REMARQUE:** Si Y a lieu, enlevez les déposes du tableau de commande interne à l'aide des étapes décrites dans la section "Dépose du couvercle du tableau de commande interne", de

## FILTRE D'HUILE DE MOTEUR

Utilisez de l'huile pour émulsionner le remplissage d'huile avec la jauge d'huile pour nettoyer le niveau d'huile. Insérez la jauge dans le tube et laissez le tube et le bouchon le boucler. Assurez-vous que l'huile soit sur le tube et sur le bouchon. Serrez à fond le bouchon jusqu'à ce qu'il ne défile plus. Assurez-vous que l'huile soit sur la ligne de remplissage d'huile. Utilisez du liquide à la place de l'eau pour nettoyer le tube et le bouchon. Utilisez du liquide à la place de l'eau pour nettoyer le tube et le bouchon.

l'empressez le moins! Ainsi, vous pourrez faire de la page trop. Voir la section de "SPECFICATIONS DU PRODUIT" pour la capacité proximitaire.






**IMPORTANT:** NE METTEZ NI HUILE NI GRASSE SUR LES POINTS DE PIVOT OU LES PAILLES EN NYLON. LES LUBRIFIANTS QUITTENT LA SURFACE DES PARTIES MÉTALLIQUES ET PROVOquent CORROSION ET ENDOMMAGEMENT. UTILISEZ SEMEMENT ET AVEC DES PAILLES D'ALUMINIUM. SI VOUS PENESEZ DÉCESSABLES D'ALUMINIUM AUTOMATIQUE, ATTIRENT LA POSSIBILITÉ DE S'ÉGOUTTER D'UN TUBE D'ALUMINIUM. MODERATION UN LUBRIFIANT SEC, EN POURDETYPE GRAPHTITE.

- ① Lubrifiant tout usage

② Référez-vous le "MOTEUR" à la section Entretien.



#### TABLEAU DE LUBRIFICATION

- 1-Chargéz l'application dans votre smartphone ou tablette et téléchargez l'application avec un chargement journal ou presque tous les jours pour améliorer vos connaissances.
  - 2-Répétez plusieurs fois pour que les informations soient possédées par cœur.
  - 3-Répondez plus souvent si ces dernières sont utilisées sur un tableau noir.

GUIDE D'ENTRETIEN


ENTRETIEN

## CONSEILS DE TONDEUSE

### UTILISATION

- Si le gazon est très long, il faut le tondre deux fois pour réduire la charge et les risques d'incendie de l'herbe sèche.
- La première fois, réglez l'appareil pour une coupe assez haute. La deuxième passe doit faire à la hauteur désirée.
- Netondrez pas l'herbe mouillée. Laissez sécher l'herbe avant de tondre.
- Pour assurer le meilleur rendement et le déchargement correct, choisissez une litière suffisamment basse qui donne le meilleur rendement et la meilleure coupe.
- Quand vous utilisez les accessoires, choisissez toujours une vitesse qui convient au terrain et à l'accessoire utilisé.

Fig. 27



- Pour tonder une grande surface, on vous conseille de commencer par tourner à droite, de faire un tour dans l'herbe ne soit pas déversée sur les arbustes, les clôtures, les allées, etc.
- Après un ou deux tours, tondez en sens inverse en tournant à gauche jusqu'à ce que le travail soit achevé (Voir la Fig. 27).
- Pour débroussailler une zone qui a été tondue, la zone coupée doit être située à la droite du tracteur. Vous obtiendrez ainsi une coupe plus uniforme et une meilleure répartition de l'herbe coupée.
- Utilisez de manière à ce que l'herbe coupée soit déversée sur la zone qui a été tondue. La zone coupée doit être située à la droite du tracteur. Vous obtiendrez ainsi une coupe plus uniforme et une meilleure répartition de l'herbe coupée.
- Vous devrez utiliser le côté gauche de la tondeuse pour la taille.
- Pour tonder une grande surface avec une meilleure répartition de l'herbe coupée, on vous conseille de commencer par tourner à droite, de faire un tour dans l'herbe ne soit pas déversée sur les arbustes, les clôtures, les allées, etc.
- Pour le meilleur rendement. Voir la section de "POUR NIVEAUX REGLAGES DE CE MANUEL".
- Assurez-vous que votre tondeuse soit correctement nivelle et régalez de ce manuel.
- LER LE CARTER DE TONDEUSES dans la section Revision pour le meilleur rendement. Voir la section de "POUR NIVEAU DE CARTE DE TONDEUSES de chaînes pour pneus quand le carter de tondeuse est attaché au tracteur.
- UTILISEZ PAS de chaînes pour pneus quand le carter de tondeuse est attaché au tracteur.

## PURGER LA TRANSMISSION

# UTILISATION

|     |  |
|-----|--|
| 7.  | <p>Placez le tracteur sur une superficie nivellee, libre de tout obstacle et ouverte, avec le moteur couper et le frein de stationnement mis en place.</p>   |
| 8.  | <p>Débrayez la transmission en mettant la commande de la roue libre dans la position de la dégagée, (Référez-vous à la section de ce manuel.)</p>  |
| 9.  | <p>Lorsque vous asséchez sur le siège du tracteur, démarrez le moteur. Après que le moteur marche, déplacez la commande des gaz à la position lente. Dégagiez le frein à main.</p>   |
| 10. | <p>Dans cette position pendante clign (5) secondes et relâchez-la ensuite. Appuyez à fond sur la pédale de marche arrière, maintenez-la dans cette position pendant cinq (5) secondes et relâchez-la ensuite. Appuyez à fond sur la pédale de marche arrière, maintenez-la dans cette position pendant cinq (5) secondes et relâchez-la ensuite. Répétez ces opérations trois (3) fois de suite.</p> |
| 11. | <p>Coupez le moteur et engagez le frein de stationnement.</p>  |
| 12. | <p>Embrayez la transmission en déplaçant la commande de la roue libre en position de marche. Référez-vous à la section de ce manuel.)</p>  |
| 13. | <p>“POUR TRANSPORTER”, dans cette section de la roue libre la transmission en position de marche. (Référez-vous à la section de ce manuel.)</p>  |
| 14. | <p>Lorsque vous asséchez sur le siège du tracteur, démarrez</p>  |
| 15. | <p>“POUR TRANSPORTER”, dans cette section de la roue libre la transmission en position de marche. (Référez-vous à la section de ce manuel.)</p>  |
| 16. | <p>“POUR TRANSPORTER”, dans cette section de la roue libre la transmission en position de marche. (Référez-vous à la section de ce manuel.)</p>  |



**ATTENTION:** N'engagerez jamais une dégâts que le moteur fonctionne.

Pour assurer l'utilisation correcte et le rendement, il est recommandé que la transmission soit purgée avant d'utiliser le tracteur pour la première fois. Ce procédé éliminera l'air emprisonné à l'intérieur de la transmission qui se développerait pendant l'expédition ou lorsque le tracteur est rangé.

IMPORTANT : SI VOTRE TRANSMISSION DOIT ÊTRE RETIRÉE POUR REMPLACEMENT OU REMPLACEMENT, ELLE DEVRAIT ÊTRE PURGÉE APRÈS LA RÉINSTALLATION ET AVANT D'UTILISER LE TRACTEUR.



que jamais le levier de la route libre pendait que le moteur fonctionne.

**ATTENTION: N'engagiez jamais ou ne déga-**

- DEMARAGE PAR TEMPS CHAUD (50°F/10°C et plus)
  - Quand vous démarrez le moteur, enfonchez doucement la commande d'entraînement, les accessoires et la commande d'entraînement.
  - Alors maintenez, la commande d'entraînement jusqu'à ce que le moteur se mette à tourner. Si le moteur ne peut pas accéder à cette charge, démarrez-le une autre fois et permettez qu'il se chauffe pendant une minute en utilisant l'étrangleur comme décret-chauft.
- DEMARAGE PAR TEMPS FROID (50°F/10°C et moins)
  - Quand vous démarrez le moteur, enfonchez doucement la commande d'entraînement jusqu'à ce que le moteur commence à fonctionner mieux. Si le moteur marche mal, tirer la commande d'étrangleur lentement jusqu'à ce que la commande puisse recouvrir lentement à l'enfoncer lentement.
  - Alors maintenez la commande d'étrangleur un petit peu pendant quelques secondes à chaque charge, démarrez-le une autre fois et permettez qu'il se chauffe pendant une minute en utilisant l'étrangleur comme décret-chauft.
- RECHAUFFEMENT DE LA TRANSMISSION AUTOMATIQUE
  - Quand vous démarrez le moteur, enfonchez doucement la commande d'entraînement jusqu'à ce que le moteur marche bien.
  - Continuez à étonner le moteur la commande petit à petit en permettant de charger, jusqu'à ce que la commande soit complètement chargée. Si le moteur commence à marcher mal, tirer un peu plus la commande pendant quelques minutes plus longues et enfoncer. Si le moteur commence à faire des vrillesses et de rebondir, arrêtez le moteur et attendez quelques minutes pour que le moteur se chauffe, selon la température.
  - Avant de conduire le tracteur l'hiver, la transmission doit être chauffée comme suit:
    - Assurez-vous que le tracteur soit garé sur un terrain plat.
    - Relâchez le frein de stationnement et permettez que le frein retourne dans la position d'opération.
    - Permettez que la transmission se réchauffe pendant une minute. Ceci peut être fait pendant le temps d'échauffement.
    - Les accessoires peuvent être utilisés pendant le temps d'échauffement.
    - Peuvent également être utilisées les commandes de chauffage qui sont utilisées pour faire fonctionner le moteur.

**HÉMORRHOÏDE:** Avent de commandes, le sens des aiguilles survient, et tournez la clé dans le sens des aiguilles survient.

- Déplacez la commande des gaz à la position rapide.
- Tirez la commande d'étrangleur pour tenir de faire un démarrage à froid. Pour le démarage d'un moteur chaud ceci ne sera pas nécessaire.


gze le frein de stationnement.  
Déplacez l'embarayage d'accèssoire à la position débrayée  
(DISENGAGED).

- Assurez-vous que la commande route libre soit dans la position d'engrenage engagée.
- Assurez-vous sur le siège, enfonnez la pédale frein et emgagé.

motetur est sans essence, il faut plus de temps pour déplacer l'essence du réservoir au moteur.

## **POUR DEMARRER LE MOTEUR (Voir la Fig. 16)**

Fig. 26



1. Elevez le siège Pour accès à la souپape d'essence.

2. Pour Fonctionnement normal, souپape d'essence devrait étre en position Première, tel que vu.

3. Si tracter est sans essence, déplacez la levier pour le souپape d'essence dans position réserve.

4. Conduisez la tracteur et se ravitailliez d'essence.

5. Après, Retournez la levier pour le souپape d'essence dos en position, vers position Première.

#### LOPERATION DE LA SOUPAPE D'ESSENCE

**ATTENTION:** Les carburents contenant de l'acool (appelés essence-acool, ou gazohol, ou contenants de méthanol ou du méthanol) peuvent attirer l'humidité et conduire à une séparation et à la formation d'acides durant le remisage. Le gaz acide peut endommager le circuit de carburation et un moteur pendrait son remisage. Pour éviter tout problème au niveau du moteur, viderez le circuit de carburation tous les 30 jours ou plus. Vérifiez le moteur régulièrement, mettez le moteur en marche et laissez-le tourner jusqu'à ce que les condutives de carburation d'informations, consultez les consignes de remisage. N'utilisez jamais d'agent de nettoyage pour moteur ou carburateur dans le réservoir de carburant. Risque de dommages irreversibles. Un stabilisateur de essence est un autre moyen accapable pour minimiser la formation d'gomme dans le réservoir de carburant.

Le réservoir de carburant, mètres le moteur en marche et laissez-le tourner jusqu'à ce que les condutives de carburation d'informations, consultez les consignes de remisage. Utilisez toujours dans le réservoir de carburant un stabilisateur de méthanol ou de carburant. Ne videz pas le réservoir de carburant ni le carburateur si un stabilisateur layout du stabilisateur afin de permettre minutes après l'ajout du stabilisateur. Ne videz pas le réservoir de carburant ni le carburateur si un stabilisateur de méthanol ou de carburant. Ne videz pas le réservoir de carburant à toute heure.

עלווה

## **AUTRES ACCESSOIRES**

COMPTEUR HORAIRES

Le complément horaire indique le nombre total d'heures de toc-tionnement du moteur. Pour l'entretien courant du moteur et de la tondeuse, préférez-vous à la section Entretien de ce manuel.

#### **VERIFIEZ LE NIVEAU D'HUILE DU MOTEUR**

Le motteur de votre tondeuse a été expédié de l'usine rempli

d'une huile d'ete.

Quelques-uns de ces derniers ont été transformés pour servir de vases ou

- Tirez vers le haut et enlevez la jauge de remplissage d'huile;

La fermeture d'un lieu de culte est un acte administratif qui nécessite une procédure réglementaire. Il existe plusieurs étapes à suivre pour déterminer si la fermeture est nécessaire et pour déterminer le délai auquel elle doit être effectuée.

remplissez avec l'huile jusqu'à la marque pleine (FULL) de

- Pour faciliter le démarrage pendant l'hiver, vous devriez

échangeant une partie de leur production dans la section d'entretien de ce manuel.

• Pour changer l'huile de moteur, voir la section Entretien de

## ITEM FIVE IN THE ENVIRONMENTAL STATEMENT

seule. Ne remplacez pas trop. Utilisez une essence neuve, changez régulièrement les filtres et nettoyez régulièrement le moteur.

people, ordinary substances provide a tasteless or a sweet taste. The mélangez pas d'huile à lessence. Achetez des quantités de essence pourront être consommées dans les 30 jours afin de servir à faire la lessence.


**IMPORtant:** Pour assurer un bon démarrage température (sous les 32°F/0°C), vous devrez utiliser de l'essence fraîche, propre et spéciale diHiver.

**ATTENTION:** Essuyez toujours l'huile ou l'essence renversée. Vous ne devrez jamais emmagasiner, étendre ou utiliser de l'essence près d'une flamme nue.



**REMARQUE:** Pour protéger le capot des dommages pendant le transport, assurez-vous que le capot soit fermé et fixé au tracteur. Utilisez les moyens appropriés (cordes, câble, etc.).

Fig. 25



- Soulevez le mécanisme de levage d'accessoire à la position plus haute sur la barre d'attelage arrête du tracteur.
- Tirez la commande de route libre et relâchez-la pour qu'elle soit à la position "DEBRAYEE".
- Arrêtez le tracteur et débranchez le fil électrique d'accèssoire.
- Ne remorquez pas sur une vitesse de plus de 3,2 km/h (2 mph).
- Pour réengrenner la transmission, inversez le procédé ci-dessus.

(Voir la Fig. 25)


### POUR TRANSPORTER LE TRACTEUR

- Choisissez la vitesse la plus lente avant de commencer à monter ou descendre une côte.
- Évitez de changer la vitesse ou d'arrêter dans une côte.
- Si l'estaboulement nécessite d'arrêter, engagez rapidement la pédale de frein jusqu'à sa position de freinage. Engagez le frein de stationnement.
- Pour redémarrer, dégagerez lentement le frein de stationnement et la pédale de frein.
- Appuyez lentement sur la pédale de marche avant jusqu'à ce que l'engagement soit désempêché.
- Votre tracteur est équipé d'un système de fonctionnement en marche arrêté (ROS). Si l'opérateur tente de circuler en marche arrière avec l'embreayage de l'accessoire engagé il provoquera un arrêt du moteur (ROS). Si l'opérateur tente de circuler en marche avant avec l'embreayage de l'accessoire engagé, une alarme sonore sera émise.
- Pour réengrenner la transmission, inversez le procédé ci-dessus.



### POUR UTILISER DANS LES PENTES

Fig. 24



- Utilisez que si vous êtes certain qu'un enfant ou tiers n'est présent sur la surface à tondeuse.
- Enfonnez complètement la pédale renversée d'entraînement pour regarder vers le bas et vers l'arrière avant de reculer.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens antihoraire sur ON.
- Lorsque l'utilisation du ROS n'est plus nécessaire, faites tourner la clé de contact en sens horaire sur ON.

- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens antihoraire sur ON.
- Utilisez que si vous êtes certain qu'un enfant ou tiers n'est présent sur la surface à tondeuse.
- Enfonnez complètement la pédale renversée d'entraînement pour regarder vers le bas et vers l'arrière avant de reculer.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Utilisez que si vous êtes certain qu'un enfant ou tiers n'est présent sur la surface à tondeuse.

### EN MARCHE ARRÊTE

- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Utilisez que si vous êtes certain qu'un enfant ou tiers n'est présent sur la surface à tondeuse.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.


- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.
- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.

### MARCHE ARRÊTE (ROS) (Voir la Fig. 24)

### SYSTÈME DE FONCTIONNEMENT EN MARCHE ARRÊTE

- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.

Fig. 23



- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.



- Assurez-vous que le moteur en marche, introduisez la clé dans le contact et tournez-la tout en sens horaire sur ON.

### POUR ARRETER LES LAMES DE TONDEUSE

- Assurez-vous que les lames de tondeuse en débrayant la commande d'embrayage d'accessoire à la position "EMBRAYEE".
- Assurez-vous que les lames de tondeuse en débrayant la commande d'embrayage d'accessoire à la position "DEBRAYEE".
- Assurez-vous que les lames de tondeuse en débrayant la commande d'embrayage d'accessoire à la position "TONDUEUSE".


- Assurez-vous que les lames de tondeuse en débrayant la commande d'embrayage d'accessoire à la position "TONDUEUSE".
- Assurez-vous que les lames de tondeuse en débrayant la commande d'embrayage d'accessoire à la position "DEBRAYEE".
- Assurez-vous que les lames de tondeuse en débrayant la commande d'embrayage d'accessoire à la position "EMBRAYEE".

### POUR UTILISER LA TONDEUSE

- Assurez-vous que les lames de tondeuse en débrayant la commande d'embrayage d'accessoire à la position "TONDUEUSE".
- Assurez-vous que les lames de tondeuse en débrayant la commande d'embrayage d'accessoire à la position "DEBRAYEE".
- Assurez-vous que les lames de tondeuse en débrayant la commande d'embrayage d'accessoire à la position "EMBRAYEE".

# UTILISATION

Fig. 22




- Répétez de l'autre côté. Installez la roue dans le même trou à fond.
- dessous du sol. Installez la roue dans le trou approprié. Serrez désserée, les roues doivent être montées légèrement au-dessus de la tondueuse est à désirer pour la hauteur de coupe désirée.
- DE LA TONDEUSE dans la section fonctionnement de ce la section de POUR REGLEUR LA HAUTEUR DE COUPE (Voyez REMARQUE: Réglez les roues quand le tracteur est sur un terrain plat).
- Les roues sont bien réglées quand elles se trouvent légèrement au-dessus du sol lorsque la tondueuse est à la hauteur de coupe désirée. Dans ce cas, les roues gardent le carter en place pour prévenir le dégagement de la tondueuse.

### (Voir la Fig. 22)

## POUR REGLEUR LES ROUES DE JAUVE

- Pour le meilleur rendement, si l'herbe mesure plus de 15,24 cm (6 po.), vous devrez la tondre deux fois. La première fois laissez-la, plutôt longue; et la deuxième fois à la hauteur de 7,62 cm (3 po.). Pendant la saison chaude, tondez souvent pour les meilleures résultats.
- La pelouse doit être tondue à 6,35 cm (2-1/2 po.) pendant la saison fraîche et à plus de 7,62 cm (3 po.) pendant la saison chaude. Tondez souvent pour les meilleures résultats.
- La plaque de régulation de la hauteur de coupe est environ de 2,54 cm (1 po.) à 10,16 cm (4 po.). Ces hauteurs sont mesurées du terrain à l'extrême de la lame quand le moteur ne marche pas.
- Ces hauteurs sont approuvées et elles pourraient changer à cause des conditions du terrain, de la hauteur de l'herbe et des types d'herbe qui sont tondus.
- Ces hauteurs sont approximatives et elles pourraient changer à cause des conditions du terrain, de la hauteur de l'herbe et des types d'herbe qui sont tondus.
- La plaque de régulation de la hauteur de coupe est tout de même utilisée.
- Faites glisser la languette (T) à la hauteur de tondeuse désirée à la hauteur désirée.
- Placez le levier d'accrochage dans la rainure correspondant à la tondeuse.

Fig. 21



- La position du levier d'accrochage (A) détermine la hauteur de la tondeuse.
- LA TONDEUSE (Voir la Fig. 21)
- POUR REGLEUR LA HAUTEUR DE COUPE DE

Pour déSEMBRAYE le régulateur, tirez le levier vers l'arrière sur "OFF", ou appuyez à fond sur la pédale de frein. Pour déSEM Brayee le régulateur, tirez le levier vers l'arrière sur "SET" et maintenez-le tout en soulevant votre pied de la pédale, puis lâchez le régulateur.

Vitesse voulue soit atteinte, poussez le régulateur sur (J) de manière à ce que la vitesse rocallieux ou lors du déclenchement de vitesse sur les pentes, les terrains rocallieux ou lors du déclenchement de vitesse sur les pentes, les lisses et droites. D'autres conditions telles que le déclenchement ou le transport du tracteur sur des surfaces qui sont relativement lisses et droites. D'autres conditions telles que lors du fouchage de la régulation de vitesse ne devrait être utilisée que lors du fouchage de la régulation de vitesse qui est utilisable qu'en marche avant.


## CARACTÉRISTIQUES DU SYSTÈME

Le régulateur de vitesse n'est utilisable qu'en marche avant.

### VITESSE (J) (Voir la Fig. 20)

## COMMENT UTILISER LE RÉGULATEUR DE

Fig. 20



- Appuyez doucement sur la pédale de marche avant (K) ou sur la pédale de marche arrière (L) pour commencer à vous déplacer. Plus vous appuyez sur la pédale, plus la vitesse augmente.
- Démarrez le tracteur et libérez le frein à main.

La direction et la vitesse du déplacement sont contrôlées par les pédales de marche avant et de marche arrière.

### (Voir la Fig. 20)


## POUR AVANCER ET POUR RECULER

- Pour déSEM Brayee l'étrangleur (N), tirez du bouton. Poussez l'étrangleur quand vous démarrez un moteur chaud.
- Utilisez l'étrangleur quand vous démarrez un moteur froid. Ne utilisez pas pour démarrez un moteur chaud.
- Lorsque l'étrangleur est démarré et que le bouton pour dégager l'étrangleur.

### Fig. 19

## POUR UTILISER L'ÉTRANGLEUR (N) (Voir la


Fig. 19



- Utilisez toujours le moteur à pleine vitesse (rapide).
- Faire fonctionner le moteur à une vitesse inférieure à sa vitesse maximale (rapide) réduit l'efficacité du moteur.
- Une pleine vitesse (rapide) permet une meilleure performance de la tondeuse.

#### (Voir la Fig. 19)

### POUR UTILISER LA COMMANDE DES GAZ (D)



**REMARQUE:** Quand le tracteur marche au ralenti, les gaz déchappement d'un moteur rachaudé peuvent causer des dommages au gazon. Pour éviter les dommages, coupez toujours le moteur quand vous arrêtez le tracteur sur le gazon.

- IMPORTANT:** Si le CONTACT D'ALLUMAGE EST LASSE, DECHARGEZ LA ET SERA ALLE A PLAT.
- A UNE AUTRE POSITION QUÉ OFF, LA BATTERIE SE ENLEVÉZ-la. Enlevez toujours la clé de contact quand vous quittez le tracteur pour empêcher l'emploi non autorisé.
- Tournez la clé de contact à la position coupe (F) STOP et utilisez pas la commande d'étrangleur pour arrêter le moteur.

**REMARQUE:** Si vous oubliez de placer la manette en position intermédiaire, vous risquez de provoquer un "retour de flammes".

- Placez la commande des gaz en position (D) intermédiaire (entre rapide et lent).
- MOTEUR -

N'APPUYEZ PAS DÉSSUS.

**IMPORTANT:** LES PÉDALES DE MARCHE AVANT ET DE MARCHE ARRIÈRE REVIENTENT AU POINT MORT SI VOUS


- frein à la position "Frein".
- Pour arrêter l'entraînement, abaissez complètement la pédale de frein à la position "Frein".

#### ENTRAÎNEMENT -

L'utilisation d'un tracteur présente le risque de projeter des particules dans les yeux qui peuvent causer des blessures sérieuses. Portez toujours des lunettes de sécurité ou une visière pendant que vous faites des réglages ou des préparations au tracteur. Nous recommandons des lunettes de sécurité ou un masque large de sécurité porte au-dessus des yeux pour éviter les blessures sérieuses. Les lunettes de sécurité ou une visière pendante protègent vos yeux contre les particules dans les yeux qui peuvent causer des blessures sérieuses. Portez toujours des lunettes de sécurité ou une visière pendante lorsque vous utilisez, ou que vous faites des réglages ou des préparations au tracteur. Nous recommandons des lunettes de sécurité porte au-dessus des yeux pour éviter les blessures sérieuses.




Fig. 18



- d'embarayage d'accèssoire à la position "DEBRAYEE" (★).
- Pour arrêter les lames de tondeuse, bougez le contrôle LAMES DE TONDEUSE -

#### (Voir la Fig. 18)

Fig. 17



- Votre tracteur est munie d'un interrupteur de détection de présence d'opératuer. Le moteur s'arrêtera, si l'opératuer quitte le siège sans engager le frein de stationnement lorsqu'il quitte le siège sans d'opératuer.
- Appuyez à fond sur la pédale (B) de frein à la position de frein (BRAKE). Maintenez le pied sur la pédale.
- Tirez sur le levier du frein de stationnement (C) et tenez-le, relâchez la pression sur la pédale de frein/d'embarayage (B), puis relâchez le levier du frein de stationnement (C) et tenez-le, assurez-vous que le frein de stationnement reste sans risque.
- Assurez-vous que le frein de stationnement reste sans risque.


#### POUR ENGAGER LE FREIN DE STATIONNEMENT (Voir la Fig. 17)

- (Z) AMPÈREMÈTRE - Indique le chargement (+) ou le déchargement (-) de la batterie.
- (P) HOROMÈTRE - Indique les heures totales d'utilisation.
- (N) COMMANDE D'ÉTRANGLAGEUR - permet de démarrer un moteur froid.
- (M) COMMANDE DE LA ROUE LIBRE - débraye la transmission pour le transport ou le remorquage du tracteur quand le moteur ne fonctionne pas.
- (L) PÉDALE DE MARCHE ARRIÈRE - Sert à faire reculer le tracteur.
- (K) PÉDALE DE MARCHE AVANT - Sert à faire avancer le tracteur.
- (J) LEVIER DE COMMANDE DE DÉPLACEMENT - permet de choisir la vitesse et la direction du tracteur.
- (H) LEVIER D'INTERUPTEUR DES LUMIÈRES - permet d'allumer/éteindre les phares du tracteur.

- (G) COMMUTATEUR DU SYSTÈME DE PRÉSENCE DE L'OPÉRATEUR (ROS) POSITION "ON" - Permet le fonctionnement de la plate-forme de fauteuil roulant avec toute autre attache.
- (F) CONTACTEUR D'ALLUMAGE - permet de couper le moteur.
- (E) INTERRUPTEUR D'EMBRAYAGE D'ACCESOIRE - est utilisé pour engager les lames de tondeuse ou les autres accessoires montés sur le tracteur.
- (D) COMMANDE DES GAZ - permet de commander la vitesse du moteur.
- (C) LEVIER DU FREIN D'ACCESOIRE - bloque la pédale de frein/embrayage en position de frein (BRAKE).
- (B) PÉDALE DE FREIN - permet de débrayer la transmission, d'arrêter le tracteur et de démarrer le moteur.
- (A) LEVIER DE LEVAGE D'ACCESOIRE - permet de soulever et de baisser le carter de tondeuse ou les autres accessoires montés au tracteur.

Nos tracteurs sont conformes aux normes de sécurité de l'American National Standards Institute.

Fig. 16



Comparez les illustrations ci-dessous à celles de votre tracteur afin de vous familiariser avec l'emplacement des différentes commandes et avec les réglages. Gardez ce manuel pour référence.

## CONNASSEZ VOTRE TRACTEUR, LISEZ CE MANUEL ET LES RÈGLES DE SECURITÉ

# UTILISATION

**FEU** indique un risque où, si il n'est pas évité, pourrait entraîner comme conséquence la mort, des blessures graves et/ou l'endommagement de la propriété.



**SURFACES CHAUDES** indique un risque où, si il n'est pas évité, pourrait avoir comme conséquence la mort, des blessures graves et/ou l'endommagement de la propriété.



**ATTENTION** lorsque il est utilisé sans le symbole d'alerte, indique une situation qui pourrait résulter en un endommagement du tracteur et/ou du moteur.



**ATTENTION** indique un risque où, si il n'est pas évité, pourrait causer des blessures mineures ou modérées.



**AVERTISSEMENT** indique un risque où, si il n'est pas évité, pourrait causer des blessures graves et la mort ou des blessures graves.




**DANGER** indique un risque où, si il n'est pas évité, aura comme conséquence la mort ou des blessures graves.



Le manchonement à suivre les instructions de sécurité pourra être résulter en de sérieuses blessures ou même la mort. Le symbole d'alerte à la mort, de sérieuses blessures et/ou risques, qui peuvent avoir pour résultats informations de sécurité pour identifier les la sécurité est utilisée pour identifier les résultats pour suivre les instructions de sécurité pourra être endommager votre propriété.



ROUE LIBRE (Seulement pour les modèles)



**GARDER L'AIREE LIBRE** RISQUE PENTE (VOYEZ SECURITE REGLES PARTIE)



DANGERE, GARDEZ LES MAINS ET PIEDS LOIN



EMBRAYAGE D'ACCESOIRE ENGAGE DEBRAVÉ




NECESSAIRE ORELLES EST PROTECTION DES MARCHE EN MARCHE ARRIERE (ROS)



ALLUMER DES PHARES ESSENCE BATTERIE PROTECTION DES



SYSTE ME DE FONCTIONNEMENT MARCHE ARRIERE DE DEVANT DE VITÈSSE LEVIER DE COMMANDE



LE MOTEUR DEMARRE ALUMME BLOCAGE DE DIFFÉRENTIEL PÉDALE DE FREIN/ STATIONNEMENT HAUTEUR LEVAGE DE



MOTEUR ALLUME DIFFÉRENTIEL PÉDALE DE FREIN/ STATIONNEMENT HAUTEUR LEVAGE DE



ARRIÈRE POINT HAUT BAS ÉTRANGLEUR RAPIDE LENTE ALLUMAGE



ARRIÈRE POINT HAUT BAS ÉTRANGLEUR RAPIDE LENTE ALLUMAGE



Ces symboles peuvent se montrer sur votre tracteur ou dans les publications fournies avec le produit. Apprenez et comprenez la signification des symboles.

## UTILISATION

## LISTE DE CONTROLE

- AVANT D'UTILISER VOTRE TRACTEUR, NOUS VOULONS RENDREMENT DE CE PRODUIT DE QUALITE ET QUE VOUS NOUS ASSUREZ QUE VOUS RECEVEREZ, LE MEILLEURS EN SERIE STASIFAT.
- Toutes les instructions ont été exécutées.
- Il n'y a pas de pièces détachées dans le carton.
- La batterie a été correctement préparée et chargée.
- Le siège a été ajusté à une position confortable et il a été serré à fond.
- Tous les pneus ont été correctement gonflés. (Les pneus ont été surgonflés pour l'expédition.)
- Assurez-vous que le résultat. (Les pneus doivent être correctement gonflés pour la conduite.)
- Verifiez la tondueuse et toutes les connexions serrées.
- Assurez-vous que la tondueuse ait été correctement utilisée et que toutes les connexions soient bien attachées et que les fils soient correctement serrés.
- Assurez-vous que la tondueuse est en état de fonctionner correctement.
- Niveau d'huile de moteur.
- Reservoir d'essence (rempli d'essence sans plomb normale, fraîche, et propre).
- Avant de conduire le tracteur, assurez-vous que la commande de démarreur le moteur, assurez-vous que vous comprenez la fonction et l'emplacement de toutes les commandes.
- Assurez-vous que le système de frein fonctionne sans risque.
- Verifiez si le système de présence de l'opérateur et le système de fonctionnement (Cf. les chapitres Fonctionnement et fonctionnement correctement (Référez-vous aux sections de "POUR DEMARRER LE MOTEUR", et "PURGER LA TRANSMISSION" dans le Manuel d'utilisation).
- Il est important de purger la transmission avant de démarrer votre tracteur pour la première fois. Suivez les instructions correctes pour le démarrage et la purge de la transmission.
- Manuel d'utilisation.

## MONTAGE

Après vous être familiarisé avec le fonctionnement de votre tracteur, vérifiez si les freins fonctionnent correctement. (Voir "POUR VERIFIER LES COURROIES SUR L'EMBRAYAGE DE POU".) Après avoir vérifié les courroies qui sont illustrées pour le remplacement des courroies de entraînement dans la section Entrerien et de ce manuel. Assurez-vous que toutes les courroies sont correctement en position dans les guides-courroie.

## VERIFIER LE SYSTEME DE FREIN

Référez-vous aux figures qui sont illustrées pour le remplacement des courroies d'entraînement dans la section Entrerien et de ce manuel. Assurez-vous que toutes les courroies sont correctement en position dans les guides-courroie.

## CORRECTEMENT EN PLACE

Pour les meilleures résultats de tondeuse, le boîtier de tondeuse doit être correctement nivelé. Référez-vous à la section "POUR NIVELER LE BOÎTIER DE TONDEUSE" dans la section Entrerien et de ce manuel.

Pour les meilleures résultats de tondeuse, le boîtier de tondeuse doit être correctement nivelé. Référez-vous à la section "POUR NIVELER LE BOÎTIER DE TONDEUSE" dans la section Entrerien et de ce manuel.

## VERIFIER SI LA TONDEUSE EST DE NIVEAU

Les pneus de votre tracteur ont été surgonflés à l'usine pour l'expédition. La pression de pneu correcte est importante pour les meilleures résultats de tondeuse.

Les pneus de votre tracteur ont été surgonflés à l'usine pour l'expédition. La pression de pneu correcte est importante pour les meilleures résultats de tondeuse.

## VERIFIER LA PRESSION DES PNEUS

Suivez le procédé décrit dans la section "POUR REMPLACER LA COURROIE D'ENTRAÎNEMENT DE LA LAME DE LA TONDEUSE", dans la section "REVISION ET REPARATION DE LA LAME DE LA TONDEUSE".

Si nécessaire, ajustez les roues de réglage avant d'utiliser la tondeuse, tel que montre dans la section Fonctionnement de la tondeuse.


Lever la mannette de levage de l'accessoire à la position la plus haute.

Si nécessaire, ajustez les roues de réglage avant d'utiliser la tondeuse, tel que montre dans la section Fonctionnement de la tondeuse.

Engager la tige de tension de courroie (k) sur le support verrouillant (l).

IMPORTANT: Vérifier que la courroie est bien acheminée dans toutes les rainures de la courroie et sous les caches du mandrin.

ATTENTION : La tige de tension de courroie est à ressort. Bien saisir la tige et engager lentement.



• Installer la courroie sur l'embryage de poulie moteur (M).

• Verrouillant (l).


• Désengager la tige de tension de courroie (k) du support verrouillant (l).

• LISE MOTRICE (M) (Voir la Fig. 15 et 17)

9. INSTALLER LA COURROIE SUR L'EMBRAYAGE DE POU-

Fig. 15

Fig. 14




**REMARQUE:** Levage du plateau de coupe nécessaire.

- ATTACHER LE BRASTAVANT (E) (Voir la Fig. 14)
    - Tournier le volant de direction pour mettre les roues vers l'avant.
    - Depuis le devant du tracteur, insérer l'extrême de la tige du bras avant (E) dans le trou dans le support de suspension bras avant (E). Insérer l'extrême de la tige du bras arrière dans le trou dans le support de suspension bras arrière (F).
    - Détacher le bras arrière et insérer le bras arrière dans le trou dans le support de la tige du bras arrière (G).
    - Déplacer vers le côté gauche de la tondueuse et insérer un grand ressort de tondueuse (H) dans le trou devant le bras arrière le support de suspension bras arrière (E).
    - Insérer une autre extrémité du bras (E) dans le trou dans le support avant de la tondueuse (H) et fixer avec une rondelle et un petit ressort de retenue (J).

### 8. ATTACHEER LE BRAIS AVANT (E) (Voir la Fig. 14)

Fig. 13



Repéter l'opération pour l'autre côté du tracteur.

- ATTACHER LES BRAS DE FORCE ARRIERE (C)**

(Voir la Fig. 13)


Inserer l'extrémité de la tige du bras de force arrière (C) dans le trou (U) du bras de suspension d'arbre et pivoter le bras vers le bas de la tondueuse.

Lever le coin arrrière de la tondueuse et placer la fente dans les bras sur la goupille sur le support arrière de la tondueuse (D) et fixer avec une grande rondelle et un grand ressort de retenue.

## 7. ATTACHEER LES BRAS DE FORCE ARRILEE (C)

MONTAGE

Fig. 7



**REMARQUE:** Une lampe torche peut être utile.

- Depuis le côté droit de la tondueuse, insérer d'abord l'extrême pointe (T) de la barre stabilisatrice (S) dans le trou du support boute-pont.
- Depuis le côté droit de la tondueuse, insérer d'abord l'extrême pointe (T) de la barre stabilisatrice (S) dans le trou du support boute-pont.

Fig. 9






Fig. 8



- Amener la courroie devant et vérifier le cheminement de la courroie dans toutes les rainures de la poigne de tondueuse.
- Glisser vers l'avant de suspension coté tondueuse sous le tracteur.
- Glisser la tondueuse sous le tracteur jusqu'à ce qu'elle soit bien centrée sous le tracteur.

**REMARQUE:** Les bras de suspension coté tondueuse (A) doivent pointer vers l'avant de suspension coté tondueuse (A) pour que la tondueuse soit correctement placée sur le tracteur.

Fig. 6




- Tourner le volant de direction à gauche aussi loin que possible et placer la tondueuse sur le côté droit du tracteur avec la protection de déflecteur (Q) à gauche.
- Tourner le volant de direction à gauche aussi loin que possible et placer la tondueuse sur le côté droit du tracteur avec la protection de déflecteur (Q) à gauche.

**PLACER LA TONDUEUSE (Voir la Fig. 6)**


**3. TOURNER LE VOLANT DE DIRECTION À GAUCHE ET**

**Fig. 5**




**2. ASSEMBLER LA ROUE DE JAUGE AVANT (W) À LAVANT**

**Fig. 4**



## MONTAGE

Fig. 2



**ATTENTION : Le levier de levage se trouve sur le côté gauche de l'aille.**

Fig. 3



- Enfoncer la pédale d'embrayage/frein jusqu'à la fond et tenir.
- Tirer le levier du frein de stationnement vers le haut tout en tenant le frein de stationnement. La pédale doit rester en position de frein.
- Relâcher la pédale d'embrayage/frein, ensuite relâcher le levier du frein de stationnement.
- Assujetez-vous sur le siège.

(Voir la Fig. 3 et 4)

#### 1. TIRER LE BRAS DU MANETTE DE LEVAGE DE LA POSITIONNEMENT ET BAISSEZ LA MANETTE DE LEVAGE (Voir la Fig. 3 - 15)

- Appuyez sur la pédale de frein/embrayage pour dégager le frein de stationnement.
- Déplacez la commande de route libre à la position roue libre dans la section transmission. (Voir "POUR TRANSPOSER")
- Retirez le tracteur hors de la position haute.
- Continuez selon les instructions suivantes.


#### POUR RETIRER LE TRACTEUR DE LA PALLETTE EN LE FAISANT ROULER (Voir la section fonctionnement pour connaître l'emplacement et la fonction des commandes.)

**Avertissement :** Avant de démarrer, nous vous prions de lire, comprendre et suivre toutes les instructions ci-après pour retirer le tracteur soit place dans une zone bien aérée. S'assurer qu'il n'y a aucune personne ou objet.

**REMARQUE :** Vous pouvez maintenir faire rouler le tracteur hors de la plateforme. Suivez les instructions ci-après pour retirer le tracteur de la plateforme.

**REMARQUE :** Si cette batterie est mise en service après les mois de l'année indiqués sur l'étiquette, (étiquette se trouve entre les bornes) veillez charger la batterie pendant au moins une heure à 6-10 ampères. (Voir "BATTERIE") dans la section Entretien de ce manuel.

**REMARQUE :** Pour installer batterie suivre le procédé décrit dans la section "REPLACEZ LA BATTERIE" dans la section Révision et Regagés de ce manuel.



AJUSTEZ LE SIÈGE (Voir la Fig. 2)

Fig. 1

- Fermer le siège ou le capot.
- Connectez le câble de prise de terre NOIR (-) avec le boulon et l'érou roustant. Bien serrer.
- Prenez le branchement, branchez le câble de batterie ROUGE à la borne positive (+) avec boulon et écrou, tel que montré. Bien serrer. Glisser la couverture de borne sur le terminal.
- Retirer deux capuchons de protection des bornes et les soulever le siège ou le capot.
- Localiser la batterie. Elle doit se trouver sous le siège ou le capot.
- Soulèver le siège ou le capot.
- Retirer deux capuchons de protection des bornes et les soulever le siège ou le capot.
- Fermer le siège ou le capot.

**AVERTISSEMENT :** Évitez un court-circuit en vous assurant qu'un outil ou que tout autre objet n'entre pas en contact avec les deux bornes en même temps. Avant de brancher la batterie, éteignez toutes les étincelles qui peuvent être provoquées par une prise de terre accidentelle.

#### CONNEXION LA BATTERIE (Voir la Fig. 1)

# MONTAGE

#### AVANT RETIRER LE TRACTEUR DE PALETTE



**LES OUTILS EXIGÉS POUR LE MONTAGE DE VOTRE TRACTEUR**

Un jeu de clé à double rendra le montage. Les dimensions nor-  
males des clés sont inscrites.

Quand on utilise l'expression "DROITE" ou "GAUCHE", elle signifie la droite ou la gauche à partir de la position derrière le volant de direction.

- (1) Cles de 9/16"

(1) Cle à douille de 3/4" à cliquet

- Vérifiez si il y a des pièces détachées et conservez-les.
- Retirez la plaque panneau des cotés.

(2) Clés de 7/16" • Couper le long des lignes pointillées sur les quatre surfaces de carton. Enlever les panneaux situés à chaque bout et

Un jeu de clé à douille rendra le montage. Les dimensions nor-  
males des clés sont inscrites.

MONTAGE

The diagram illustrates the exploded view of a string trimmer, organized into two main sections: 'Tondeuse' (lawnmower) and 'Si Équipé' (if equipped).

**Tondeuse (Lawnmower):**

- Roue devant de tondeuse (1)**: Front wheel, shown as a circular hub.
- Boulon (1)**: Bolt, shown as a threaded fastener.
- Rondelle (1-1/4") (1)**: Flat washer, shown as a thin circular disc.
- Roue arrière de levage (1)**: Rear lift wheel, shown as a hub with a central hole.
- Écrou (1 3/8-16") (1)**: Nut, shown as a hexagonal nut.
- Tube de Vidange (1)**: Drain tube, shown as a curved tube.
- Cles d'accouplement du rapide (1)**: Quick coupling keys, shown as a set of two keys.
- Guide-pente (1)**: Grade guide, shown as a rectangular strip with a slot.
- Cles (2)**: Keys, shown as two separate keys.
- Boîte à outils (1)**: Tool box, shown as a rectangular case with a handle.

**Si Équipé (If equipped):**

- Tondeuse (1)**: String trimmer, shown as a long handle with a curved head.
- Rondelle (1 3/16") (5)**: Flat washer, shown as a thin circular disc.
- Bielles du levage (1)**: Lift shafts, shown as a curved metal rod.
- Ressort de Retenue (1)**: Retention spring, shown as a coiled wire.
- Grand levage (1)**: Large lift, shown as a curved metal rod.
- Bielles du levage (1)**: Lift shafts, shown as a curved metal rod.
- Ressort de Retenue (1)**: Retention spring, shown as a coiled wire.
- Barre de non mouvement (1)**: Non-movement bar, shown as a straight metal rod.
- Rondelle 3/4" (1)**: Flat washer, shown as a thin circular disc.
- Petit Ressort de Retenue (1)**: Small retention spring, shown as a coiled wire.

## PIECES PAS ASSÉMBLÉ

|                           |       |                       |     |                   |    |
|---------------------------|-------|-----------------------|-----|-------------------|----|
| RÈGLES DE SÉCURITÉ        | 18-22 | ENTRETIEN             | 2-3 | ENTRETIEN         | 34 |
| SPÉCIFICATIONS DE PRODUIT | 23-27 | REVISIION ET REGLAGES | 4   | ENTREPOSAGE       | 28 |
| MONTAGE                   | 29-30 | GARANTIE              | 5-9 | GARANTIE          | 32 |
| UTILISATION               | 10-17 | GUIDE DE DÉPANNAGE    | 4   | GUIDE D'ENTRETIEN | 18 |
| GUIDE D'ENTRETIEN         |       | ENTRETIEN DE "SEARS"  |     |                   |    |

## SOMMAIRE

Un pare-échappement autorisé le plus proche.  
d'un centre en autorisé le plus proche.

Un pare-échappement autorisé le plus proche.  
d'un centre en autorisé le plus proche.

- AVERTISSEMENT: Ce tracteur est équipé d'un moteur à compression et il ne doit pas être utilisé sur un terrain couvert d'arbres, d'arbustes, ou d'herbes si le système d'échappement n'est pas aussi étanche que le système de refroidissement.
- Toujours aviser une autre personne lorsqu'e vous êtes à l'extérieur pour ranger le tracteur.
- Porter des lunettes de sécurité lorsque vous utilisez des outils de coupe ou des solaires à bout court.
- Si vous utilisez un programme régulier d'entretien, et d'utilisation du tracteur.
- Lisez et observez les règles de sécurité.
- Si vous utilisez un programme régulier d'entretien, et d'utilisation du tracteur.
- Si vous utilisez un programme régulier d'entretien, et d'utilisation du tracteur.
- Si vous utilisez un programme régulier d'entretien, et d'utilisation du tracteur.

## RESPONSABILITÉS DU CLIENT

Il existe un contrat d'entretien Sears pour ce produit. Contactez le magasin Sears le plus proche pour des informations supplémentaires.

VEUILLEZ lire et conserver ce manuel. Les instructions qui contiennent vos permis de monter, et d'entretenir correctement votre tracteur. Déservrez toujours les "RÈGLES DE SÉCURITÉ".  
Contactez le centre d'entretien autorisé le plus proche. Vous y trouverez des techniques qualifiées équipées des outils appropriés pour faire l'entretien et la réparation de ce tracteur.  
Si vous avez un problème que vous ne pouvez pas résoudre, contactez le centre d'entretien autorisé le plus proche. Vous y trouverez des techniques qualifiées équipées des outils appropriés pour faire l'entretien et la réparation de ce tracteur.  
Toutes tracteurs vous est expédié de la manufacture avec de l'huile à moteur non-synthétique SAE 10W30.  
Capacité d'huile: 1,89 L/64 OZ.  
Bougie d'allumage: CHAMPION 25 132 13  
(Ecart: .030"/.76 mm)  
Système de chargement: 15 Ampères @ 3600 RPM  
Batterie: Amp/Hr: 28  
Min. CCA: 230  
Dimensions: U1R  
 couple de rotation 62-75 Nm  
au boulon de lame: (45-55 Ft. Lbs.)  
\* Vous pouvez utiliser de l'essence contenant jusqu'à 10% d'éthanol (E10) avec cet appareil. L'utilisation d'essence contenant plus de 10% d'éthanol annule la garantie du produit.

|                                       |  |   |
|---------------------------------------|--|---|
| Capacité et le type d'essence:        | 15,14 L / 4 Gallons *                          | Le essence sans plomb normale   |
| Type d'huile (API: SJ-SN):            | SAE 10W30 (supérieure de 32°F/0°C)             | SYNTHETIC (inférieure de 0°F/-18°C)   |
| Capacité d'huile:                     | 1,89 L/64 OZ.                                  | Votre tracteur vous est expédié de la manufacture avec de l'huile à moteur non-synthétique SAE 10W30. |
| Bougie d'allumage:                    | CHAMPION 25 132 13<br>(Ecart: .030"/.76 mm)    | Si vous utilisez un programme régulier d'entretien, et d'utilisation du tracteur.                     |
| Système de chargement:                | 15 Ampères @ 3600 RPM                          | Si vous utilisez un programme régulier d'entretien, et d'utilisation du tracteur.                     |
| Batterie:                             | Amp/Hr: 28<br>Min. CCA: 230<br>Dimensions: U1R | Si vous utilisez un programme régulier d'entretien, et d'utilisation du tracteur.                     |
| Couple de rotation au boulon de lame: | (45-55 Ft. Lbs.)                               | Si vous utilisez un programme régulier d'entretien, et d'utilisation du tracteur.                     |

## SPÉCIFICATIONS DE PRODUIT

## MANIPULATION SURE DE LESSENCE

Portez toujours des lunettes de protection lorsque vous utilisez la machine.



Qui mises des protocoles dans lesquels pour éviter la faillite.



- Ne faites jamais fonctionner la machine dans un endroit clos.  
Tous les écrans et les boutons doivent être bien serrés pour éviter que l'appareil fonctionne en condition de sécurité.  
Ne bricolez jamais les dispositifs de sécurité. Ne jamais inter-  
férer avec le fonctionnement dispositif d'un sécurité ou réduire bon fonctionnement régulièrement. NE JAMAIS utiliser une machine avec une sécurité dispositif que ne fonctionne pas à protection fournit un dispositif d'un sécurité le fermer avec le fonctionnement dispositif. Vérifiez le bon fonctionnement régulièrement. NE JAMAIS utiliser une machine avec une sécurité dispositif qui fonctionne pas de carburant. Laissez la machine refroidir avant de la ranger.  
Si vous heurtéz un objet, arrêtez et inspectez la machine. Réparez-la au besoin avant de redémarrer.  
N'effectuez jamais ni réglages, ni préparations avec le moteur en marche.  
Inspectez fréquemment les compositions du bac de ramasse-urine et la gouttière de décharge, et remplacer avec les places recommandées du fabricant, selon le besoin.  
Les lames des grilles et Fairies extrêmement attention pendant les opérations d'entretien.  
Vérifiez fréquemment le fonctionnement du frein. Effectuez les opérations de réglage et d'entretien.  
Conservez et remplacez au besoin les autocollants de sécurité et d'instruction.

ENTRETIEN GÉNÉRAL




## **REGLES DE SECURITE**

Conseils pour l'utilisation en toute sécurité des tracteurs



### III. FONCTIONNEMENT DANS LES PENTES

**V. ENTRÉE** LIBÈREZ LA MACHINE DES BRINS D'HERBE, DES FEUILLES D'AUTRES DEBRIS ACCUMULÉS SUSCEPTIBLES DE TOUCHER LE TUYAU D'ÉCHAPPE-MENT OU LES PARTIES CHAUDES DU MOTEUR ET DE BRÛLER. NE LASSEZ PAS LE BAS DE LA TONDEUSE SUSCEPTIBLE DE S'ACCUMULER. NETTOYEZ L'HUILE ET LE LIQUIDE DE FREIN SUR LA TERRE. LASSEZ LA MACHINE REFROIDIR AVANT DE LA RANGER.





Sears Canada, Inc., Toronto, Ontario M5B 2B8

\* La puissance nominale indiquée par le fabricant du moteur est la puissance brute moyenne (à un régime en t/min spécifique) d'un moteur de production type pour le modèle de moteur mesuré selon les normes SAE pour la puissance brute du moteur. Se reporter au fabricant du moteur pour tous les détails.

- Montage
- Utilisation
- Entretien
- Révision et Régages

TRACTEUR DE JARDIN  
AUTOMATIQUE  
TONDEUSE DE 137 CM (54 PO.)  
DEMARRAGE ÉLECTRIQUE  
26,0 C.V.\*

**CRAFTSMAN**

IMPORTANT:  
Lisez et suivez le mode d'emploi et toutes les règles de sécurité avant d'utiliser cet équipement.

944.10108  
MODÈLE  
NUMÉRO DE

OPÉRATEUR  
MANUEL DE  
**SEARS**

