


SEARS

OPERATOR'S MANUAL

**MODEL NO.
944.10134**

IMPORTANT:
Read and follow
all Safety Rules
and Instructions
Before Operating
This Equipment



CRAFTSMAN®

23 HP*
ELECTRIC START
46" MOWER
AUTOMATIC TRANSMISSION
LAWN TRACTOR

- **Assembly**
- **Operation**
- **Maintenance**
- **Service and Adjustments**

* The power rating as declared by the engine manufacturer is the average gross power output at the specified RPM of a typical production engine for the engine model measured using SAE Standards for engine gross power. Please refer to the engine manufacturer for details.

Sears Canada, Inc., Toronto, Ontario M5B 2B8

115818226 Rev. 1

12.02.16 CL
Printed in the U.S.A.

SAFETY RULES

Safe Operation Practices for Ride-On Mowers

DANGER: THIS CUTTING MACHINE IS CAPABLE OF AMPUTATING HANDS AND FEET AND THROWING OBJECTS. FAILURE TO OBSERVE THE FOLLOWING SAFETY INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.



WARNING: In order to prevent accidental starting when setting up, transporting, adjusting or making repairs, always disconnect spark plug wire and place wire where it cannot contact spark plug.



WARNING: Do not coast down a hill in neutral, you may lose control of the tractor.



WARNING: Tow only the attachments that are recommended by and comply with specifications of the manufacturer of your tractor. Use common sense when towing. Operate only at the lowest possible speed when on a slope. Too heavy of a load, while on a slope, is dangerous. Tires can lose traction with the ground and cause you to lose control of your tractor.

⚠️ WARNING ⚠️

Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

⚠️ WARNING ⚠️

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

I. CHILDREN



WARNING! CHILDREN CAN BE INJURED BY THIS EQUIPMENT. The American Academy of Pediatrics recommends that children be a minimum of 12 year of age before operating a pedestrian controlled lawn mower and a minimum of 16 years of age before operating a riding lawn mower.



WARNING! CHILDREN CAN BE SERIOUSLY INJURED OR KILLED BY THIS EQUIPMENT. Carefully read and follow all of the safety instructions below.

Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the machine and the mowing activity. Never assume that children will remain where you last saw them.

- Keep children out of the mowing area and in the watchful care of a responsible adult other than the operator.

- Be alert and turn machine off if a child enters the area.
- Before and while backing, look behind and down for small children.
- Never carry children, even with the blades shut off. They may fall off and be seriously injured or interfere with safe machine operation. Children who have been given rides in the past may suddenly appear in the mowing area for another ride and be run over or backed over by the machine.
- Never allow children to operate the machine.
- Use extreme caution when approaching blind corners, shrubs, trees, or other objects that may block your view of a child.

II. GENERAL OPERATION

- Read, understand, and follow all instructions on the machine and in the manual before starting.
- Do not put hands or feet near rotating parts or under the machine. Keep clear of the discharge opening at all times.
- Only allow responsible adults, who are familiar with the instructions, to operate the machine.
- Clear the area of objects such as rocks, toys, wire, etc., which could be picked up and thrown by the blades.
- Ensure the area is clear of bystanders before operating. Stop machine if anyone enters the area.
- Never carry passengers.
- Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing.
- Never direct discharged material toward anyone. Avoid discharging material against a wall or obstruction. Material may ricochet back toward the operator. Stop the blades when crossing gravel surfaces.
- Do not operate machine without the entire grass catcher, discharge chute, or other safety devices in place and working.
- Slow down before turning.
- Never leave a running machine unattended. Always turn off blades, set parking brake, stop engine, and remove keys before dismounting.
- Disengage blades when not mowing. Shut off engine and wait for all parts to come to a complete stop before cleaning the machine, removing the grass catcher, or unclogging the discharge chute.
- Operate machine only in daylight or good artificial light.
- Do not operate the machine while under the influence of alcohol or drugs.
- Watch for traffic when operating near or crossing roadways.
- Use extreme caution when loading or unloading the machine into a trailer or truck.
- Always wear eye protection when operating machine.
- Use ear protectors to avoid damage to hearing.
- Data indicates that operators, age 60 years and above, are involved in a large percentage of riding mower-related injuries. These operators should evaluate their ability to operate the riding mower safely enough to protect themselves and others from serious injury.
- Follow the manufacturer's recommendation for wheel weights or counterweights.
- Keep machine free of grass, leaves or other debris build-up which can touch hot exhaust / engine parts and burn. Do not allow the mower deck to plow leaves or other debris which can cause build-up to occur. Clean any oil or fuel spillage before operating or storing the machine. Allow machine to cool before storage.



SAFETY RULES

Safe Operation Practices for Ride-On Mowers



III. SLOPE OPERATION



WARNING! When loading or unloading this machine, do not exceed the maximum recommended operation angle of 15°.

Slopes are a major factor related to loss of control and tip-over accidents, which can result in severe injury or death. Operation on all slopes requires extreme caution. If you cannot back up the slope or if you feel uneasy on it, do not mow it.

- Mow up and down slopes, not across.
- Watch for holes, ruts, bumps, rocks, or other hidden objects. Uneven terrain could overturn the machine. Tall grass can hide obstacles.
- Choose a low ground speed so that you will not have to stop or shift while on the slope.
- Do not mow on wet grass. Tires may lose traction. Always keep the machine in gear when going down slopes.
- Do not shift to neutral and coast downhill.
- Avoid starting, stopping, or turning on a slope. If the tires lose traction, disengage the blades and proceed slowly straight down the slope.
- Keep all movement on the slopes slow and gradual. Do not make sudden changes in speed or direction, which could cause the machine to roll over.
- Use extreme caution while operating machine with grass catchers or other attachments; they can affect the stability of the machine. Do no use on steep slopes.
- Do not try to stabilize the machine by putting your foot on the ground.
- Do not mow near drop-offs, ditches, or embankments. The machine could suddenly roll over if a wheel is over the edge or if the edge caves in.
- If machine stops while going uphill, disengage blades, shift into reverse and back down slowly.
- Do not turn on slopes unless necessary, and then, turn slowly and gradually downhill, if possible.



IV. TOWING

- Tow only with a machine that has a hitch designed for towing. Do not attach towed equipment except at the hitch point.
- Follow the manufacturer's recommendation for weight limits for towed equipment and towing on slopes.
- Never allow children or others in or on towed equipment.
- On slopes, the weight of the towed equipment may cause loss of traction and loss of control.
- Travel slowly and allow extra distance to stop.

V. SERVICE

SAFE HANDLING OF GASOLINE

To avoid personal injury or property damage, use extreme care in handling gasoline. Gasoline is extremely flammable and the vapors are explosive.

- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only approved gasoline container.

- Never remove gas cap or add fuel with the engine running.
- Allow engine to cool before refueling.
- Never fuel the machine indoors.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light such as on a water heater or other appliances.
- Never fill containers inside a vehicle or on a truck or trailer bed with plastic liner. Always place containers on the ground away from your vehicle when filling.
- Remove gas-powered equipment from the truck or trailer and refuel it on the ground. If this is not possible, then refuel such equipment with a portable container, rather than from a gasoline dispenser nozzle.
- Keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete. Do not use a nozzle lock-open device.
- If fuel is spilled on clothing, change clothing immediately.
- Never overfill fuel tank. Replace gas cap and tighten securely.

GENERAL SERVICE

- Never operate machine in a closed area.
- Keep all nuts and bolts tight to ensure the equipment is in safe working condition.
- Never tamper with safety devices. Never interfere with the intended function of a safety device or reduce the protection provided by a safety device. Check there proper operation regularly. NEVER operate a machine with a safety device that does not function properly.
- Keep machine free of grass, leaves, or other debris build-up. Clean oil or fuel spillage and remove any fuel-soaked debris. Allow machine to cool before storing.
- If you strike a foreign object, stop and inspect the machine. Repair, if necessary, before restarting.
- Never make any adjustments or repairs with the engine running.
- Check grass catcher components and the discharge chute frequently and replace with manufacturer's recommended parts, when necessary.
- Mower blades are sharp. Wrap the blade or wear gloves, and use extreme caution when servicing them.
- Check brake operation frequently. Adjust and service as required.
- Maintain or replace safety and instruction labels, as necessary.



Use ear protectors to avoid damage to hearing.



Always wear eye protection when operating machine.

PRODUCT SPECIFICATIONS

Gasoline Capacity and type:	3 Gallons/11,35 L Regular Unleaded *
Oil Type: (API: SJ-SN)	SAE 30 (above 32°F/0°C) SAE 5W30 (below 32°F/0°C) SYNTHETIC (below 0°F/-18°C)
Your tractor was shipped from the factory with non-synthetic SAE 10W30 motor oil.	
Oil Capacity:	W/Filter: 64 Oz./1,89 L W/out Filter: 60 Oz./1,77 L
Spark Plug:	QC12YC (Gap: .030"/0.76 mm)
Charging System:	16 Amps @3600 RPM
Battery:	Amp/Hr: 28 Min. CCA: 230 Case size: U1R
Blade Bolt Torque:	45-55 Ft. Lbs./62-75 Nm

* Gasoline containing up to 10% ethanol (E10) is acceptable for use in this machine. The use of any gasoline exceeding 10% ethanol (E10) will void the product warranty.

CONGRATULATIONS on your purchase of a new tractor. It has been designed, engineered and manufactured to give you the best possible dependability and performance.

Should you experience any problem you cannot easily remedy, please contact your nearest authorized service center/department. We have competent, well-trained technicians and the proper tools to service or repair this tractor.

Please read and retain this manual. The instructions will enable you to assemble and maintain your tractor properly. Always observe the "SAFETY RULES".

MAINTENANCE AGREEMENT

A Maintenance Agreement is available on this product. Contact your nearest Sears store for details.

CUSTOMER RESPONSIBILITIES

- Read and observe the safety rules.
- Follow a regular schedule in maintaining, caring for and using your tractor.
- Follow the instructions in the Maintenance and Storage sections of this manual.
- Wear proper Personal Protective Equipment (PPE) while operating this machine, including (at a minimum) sturdy footwear, eye protection, and hearing protection. Do not mow in shorts and/or open toed footwear.
- Always let someone know you are outside mowing.

WARNING: This tractor is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator.


A spark arrester for the muffler is available through your nearest authorized service center/department .

TABLE OF CONTENTS

SAFETY RULES	2-3
PRODUCT SPECIFICATIONS.....	4
CUSTOMER RESPONSIBILITIES.....	4
ASSEMBLY	5-6
OPERATION	7-13
MAINTENANCE SCHEDULE	14
MAINTENANCE	14-18
SERVICE AND ADJUSTMENTS	19-25
STORAGE.....	26
TROUBLESHOOTING	27-28
WARRANTY.....	30

UNASSEMBLED PARTS

Keys



Key(s)




(1) Oil Drain Tube



(1) Quick Connect

Slope Sheet



Battery



(2) Hex Bolts



(2) Nut Keps

ASSEMBLY

Your new tractor has been assembled at the factory with the exception of those parts left unassembled for shipping purposes.

TOOLS REQUIRED FOR ASSEMBLY

A socket wrench set will make assembly easier. Standard wrench sizes are listed.

- | | |
|--------------------|---------------------|
| (1) 1/2" wrench | Tire pressure gauge |
| (2) 7/16" wrenches | Utility knife |
| | Pliers |

When right or left hand is mentioned in this manual, it means when you are in the operating position (seated behind the steering wheel).

TO REMOVE TRACTOR FROM CARTON

UNPACK CARTON

- Remove all accessible loose parts and parts cartons from carton.
- Cut along dotted lines on all four panels of carton. Remove end panels and lay side panels flat.
- Check for any additional loose parts or cartons and remove.

BEFORE REMOVING TRACTOR FROM SKID

CONNECT BATTERY (See Fig. 1)



WARNING: Do not short battery terminals by allowing a wrench or any other object to contact both terminals at the same time. Before connecting battery, remove metal bracelets, wristwatch bands, rings, etc. Positive terminal must be connected first to prevent sparking from accidental grounding.

NOTE: If this battery is put into service after month and year indicated on label (label is located between terminals) charge battery for minimum of one hour at 6-10 amps. (See "BATTERY" in the Maintenance section of this manual for charging instructions.)

- Determine battery location. Battery location will be under the seat or the hood.
- Lift seat pan or hood to raised position.
- Remove two terminal caps and discard.
- First connect RED battery cable to positive (+) terminal with bolt and nut as shown. Tighten securely. Slide terminal cover over terminal.
- Connect BLACK grounding cable to negative (-) terminal with remaining bolt and nut. Tighten securely.
- Lower seat pan or hood.

NOTE: For battery installation see "REPLACING BATTERY" in the Service and Adjustments section in this manual.




Fig. 1

ADJUST SEAT (See Fig. 2)

- Sit in seat.
- Lift up adjustment lever (A) and slide seat until a comfortable position is reached which allows you to press clutch/brake pedal all the way down.
- Release lever to lock seat in position.




Fig. 2

ASSEMBLY

NOTE: You may now roll your tractor off the skid. Continue using the instructions that follow to remove the tractor from the skid.

WARNING: Before starting, read, understand and follow all instructions in the Operation section of this manual. Ensure tractor is in a well-ventilated area. Ensure the area in front of tractor is clear of other people and objects.

TO ROLL TRACTOR OFF SKID (See Operation section for location and function of controls)

- Raise attachment lift lever to its highest position.
- Release parking brake by depressing clutch/brake pedal.
- Place freewheel control in "TRANSMISSION DISENGAGED" position. (See "TO TRANSPORT" in the Operation section of this manual.)
- Roll tractor forward off skid.
- Remove banding holding the deflector shield up against tractor.

Continue with the instructions that follow.

CHECK TIRE PRESSURE

The tires on your tractor were overinflated at the factory for shipping purposes. Correct tire pressure is important for best cutting performance.

- Reduce tire pressure to PSI shown on tires.

CHECK DECK LEVELNESS

For best cutting results, mower housing should be properly leveled. See "TO LEVEL MOWER HOUSING" in the Service and Adjustments section of this manual.

CHECK FOR PROPER POSITION OF ALL BELTS

See the figures that are shown for replacing motion and mower blade drive belts in the Service and Adjustments section of this manual. Verify that the belts are routed correctly.

CHECK BRAKE SYSTEM

After you learn how to operate your tractor, check to see that the brake is operating properly. See "TO CHECK BRAKE" in the Service and Adjustments section of this manual.

✓ CHECKLIST

BEFORE YOU OPERATE YOUR NEW TRACTOR, WE WISH TO ASSURE THAT YOU RECEIVE THE BEST PERFORMANCE AND SATISFACTION FROM THIS QUALITY PRODUCT.

PLEASE REVIEW THE FOLLOWING CHECKLIST:


- ✓ All assembly instructions have been completed.
- ✓ No remaining loose parts in carton.
- ✓ Battery is properly prepared and charged.
- ✓ Seat is adjusted comfortably and tightened securely.
- ✓ All tires are properly inflated. (For shipping purposes, the tires were overinflated at the factory).
- ✓ Be sure mower deck is properly leveled side-to-side/ front-to-rear for best cutting results. (Tires must be properly inflated for leveling).
- ✓ Check mower and drive belts. Be sure they are routed properly around pulleys and inside all belt keepers.
- ✓ Check wiring. See that all connections are still secure and wires are properly clamped.
- ✓ Before driving tractor, be sure freewheel control is in "transmission engaged" position (see "TO TRANSPORT" in the Operation section of this manual).

WHILE LEARNING HOW TO USE YOUR TRACTOR, PAY EXTRA ATTENTION TO THE FOLLOWING IMPORTANT ITEMS:

- ✓ Engine oil is at proper level.
- ✓ Fuel tank is filled with fresh, clean, regular unleaded gasoline.
- ✓ Become familiar with all controls, their location and function. Operate them before you start the engine.
- ✓ Be sure brake system is in safe operating condition.
- ✓ Be sure Operator Presence System and Reverse Operation System (ROS) are working properly (See the Operation and Maintenance sections in this manual).
- ✓ It is important to purge the transmission before operating your tractor for the first time. Follow proper starting and transmission purging instructions (See "TO START ENGINE" and "PURGE TRANSMISSION" in the Operation section of this manual).

OPERATION

These symbols may appear on your tractor or in literature supplied with the product. Learn and understand their meaning.



Failure to follow instructions could result in serious injury or death. The safety alert symbol is used to identify safety information about hazards which can result in death, serious injury and/or property damage.

OPERATION

KNOW YOUR TRACTOR

READ THIS MANUAL AND SAFETY RULES BEFORE OPERATING YOUR TRACTOR

Compare the illustrations with your tractor to familiarize yourself with the locations of various controls and adjustments. Save this manual for future reference.




Fig. 3

Our tractors conform to the applicable safety standards of the American National Standards Institute.

(A) ATTACHMENT LIFT LEVER - Used to raise and lower the mower or other attachments mounted to your tractor.

(B) BRAKE PEDAL - Used for braking the tractor and starting the engine.

(C) PARKING BRAKE - Locks clutch/brake pedal into the brake position.

(D) THROTTLE/CHOKE CONTROL - Used for starting and controlling engine speed.

(E) ATTACHMENT CLUTCH SWITCH - Used to engage the mower blades or other attachments mounted to your tractor.

(F) IGNITION SWITCH - Used for starting and stopping the engine.

(G) REVERSE OPERATION SYSTEM (ROS) "ON" POSITION - Allows operation of mower or other powered attachment while in reverse.

(H) LIGHT SWITCH - Turns the headlights on and off.

(J) CRUISE CONTROL LEVER - Used to set forward movement of tractor at desired speed without holding the forward drive pedal.

(K) FORWARD DRIVE PEDAL - Used for forward movement of tractor.

(L) REVERSE DRIVE PEDAL - Used for reverse movement of tractor.

(M) FREEWHEEL CONTROL - Disengages transmission for pushing or slowly towing the tractor with the engine off.

(P) SERVICE MINDER/HOUR METER - Indicates when service is required for the engine and mower.

(Z) AMMETER - Indicates charging (+) or discharging (-) of battery.

OPERATION



The operation of any tractor can result in foreign objects thrown into the eyes, which can result in severe eye damage. Always wear safety glasses or eye shields while operating your tractor or performing any adjustments or repairs. We recommend standard safety glasses or a wide vision safety mask worn over spectacles.

HOW TO USE YOUR TRACTOR

TO SET PARKING BRAKE (See Fig. 4)

Your tractor is equipped with an operator presence sensing switch. When engine is running, any attempt by the operator to leave the seat without first setting the parking brake will shut off the engine.

- Depress brake pedal (B) all the way down and hold.
- Pull parking brake lever (C) up and hold, release pressure from brake pedal (B), then release parking brake lever. Pedal should remain in brake position. Make sure parking brake will hold tractor secure.




Fig. 4

STOPPING (See Fig. 5)

MOWER BLADES -

- To stop mower blades, place attachment clutch control in the "DISENGAGED" position (★).




Fig. 5

GROUND DRIVE -

- To stop ground drive, depress brake pedal into full "BRAKE" position.

IMPORTANT: FORWARD AND REVERSE DRIVE PEDALS RETURN TO NEUTRAL POSITION WHEN NOT DEPRESSED.

ENGINE -

- Move throttle control (D) to slow position.

NOTE: Failure to move throttle control to slow position and allowing engine to idle before stopping may cause engine to "backfire".

- Turn ignition key (F) to "STOP" position and remove key. Always remove key when leaving tractor to prevent unauthorized use.
- Never use the choke to stop the engine.

IMPORTANT: LEAVING THE IGNITION SWITCH IN ANY POSITION OTHER THAN "STOP" WILL CAUSE THE BATTERY TO DISCHARGE AND GO DEAD.

NOTE: Under certain conditions when tractor is standing idle with the engine running, hot engine exhaust gases may cause "browning" of grass. To eliminate this possibility, always stop engine when stopping tractor on grass areas.



CAUTION: Always stop tractor completely, as described above, and set parking brake before leaving the operator's position.

TO USE THROTTLE CONTROL (D) (See Fig. 6)

Always operate engine at full speed (fast).

- Operating engine at less than full speed (fast) reduces the engine's operating efficiency.
- Full speed (fast) offers the best mower performance.




Fig. 6

TO MOVE FORWARD AND BACKWARD (See Fig. 7)

The direction and speed of movement is controlled by the forward and reverse drive pedals.

- Start tractor and release parking brake.
- Slowly depress forward (K) or reverse (L) drive pedal to begin movement. Ground speed increases the further down the pedal is depressed.

OPERATION

TO USE CRUISE CONTROL (J) (See Fig. 7)

The cruise control feature can be used for forward travel only.




Fig. 7

SYSTEM CHARACTERISTICS

The cruise control should only be used while mowing or transporting on relatively smooth, straight surfaces. Other conditions such as trimming at slow speeds may cause the cruise control to disengage. Do not use the cruise control on slopes, rough terrain or while trimming or turning.

- With forward drive pedal depressed to desired speed, pull cruise control lever (J) up and hold while lifting your foot off the pedal, then release the lever.

To disengage the cruise control, depress the brake pedal or tap on forward drive pedal.

TO ADJUST MOWER CUTTING HEIGHT (See Fig. 8)

The position of the attachment lift lever (A) determines the cutting height.




Fig. 8

- Put attachment lift lever in desired cutting height slot.

The cutting height range is approximately 1 to 4" (25,4 to 101,6 mm). The heights are measured from the ground to the blade tip with the engine not running. These heights are approximate and may vary depending upon soil conditions, height of grass and types of grass being mowed.

- The average lawn should be cut to approximately 2-1/2" (63,5 mm) during the cool season and to over 3" (76,2 mm) during hot months. For healthier and better looking lawns, mow often and after moderate growth.
- For best cutting performance, grass over 6" (152,4 mm) in height should be mowed twice. Make the first cut relatively high; the second to desired height.

TO ADJUST GAUGE WHEELS (See Fig. 9)

Gauge wheels are properly adjusted when they are slightly off the ground when mower is at the desired cutting height in operating position. Gauge wheels then keep the deck in proper position to help prevent scalping in most terrain conditions.

NOTE: Adjust gauge wheels with tractor on a flat level surface.

- Adjust mower to desired cutting height (See "TO ADJUST MOWER CUTTING HEIGHT" in this section of manual).
- With mower in desired height of cut position, gauge wheels should be assembled so they are slightly off the ground. Install gauge wheel in appropriate hole. Tighten securely.
- Repeat for all, installing gauge wheel in same adjustment hole.




Fig. 9

TO OPERATE MOWER

Your tractor is equipped with an operator presence sensing switch. Any attempt by the operator to leave the seat with the engine running and the attachment clutch engaged will shut off the engine. You must remain fully and centrally positioned in the seat to prevent the engine from hesitating or cutting off when operating your equipment on rough, rolling terrain or hills.

- Select desired height of cut. (See "TO ADJUST MOWER CUTTING HEIGHT".)
- Start mower blades by engaging attachment clutch control.

TO STOP MOWER BLADES

Disengage attachment clutch control.



CAUTION: Do not operate the mower without either the entire grass catcher, on mowers so equipped, or the deflector chute in place (See Fig. 10).




Fig. 10

OPERATION

REVERSE OPERATION SYSTEM (ROS)

Your tractor is equipped with a Reverse Operation System (ROS). Any attempt by the operator to travel in the reverse direction with the attachment clutch engaged will shut off the engine unless ignition key is placed in the ROS "ON" position.

WARNING: Backing up with the attachment clutch engaged while mowing is strongly discouraged. Turning the ROS "ON", to allow reverse operation with the attachment clutch engaged, should only be done when the operator decides it is necessary to reposition the machine with the attachment engaged. **Do not mow in reverse unless absolutely necessary.**

USING THE REVERSE OPERATION SYSTEM - (See Fig. 11)

Only use if you are certain no children or other bystanders will enter the mowing area.

- Depress brake pedal all the way down.
- With engine running, turn ignition key counterclockwise to ROS "ON" position.
- Look down and behind before and while backing.
- Slowly depress reverse drive pedal to start movement.
- When use of the ROS is no longer needed, turn the ignition key clockwise to engine "ON" position.




Fig. 11

TO OPERATE ON HILLS



CAUTION: Do not drive up or down hills with slopes greater than 15° and do not drive across any slope.

- Choose the slowest speed before starting up or down hills.
- Avoid stopping or changing speed on hills.
- If stopping is absolutely necessary, push brake pedal quickly to brake position and engage parking brake.
- To restart movement, slowly release parking brake and brake pedal.
- Slowly depress appropriate drive pedal to slowest setting.
- Make all turns slowly.

TO TRANSPORT (See Fig. 3 &12)

When pushing or towing your tractor, ensure transmission is disengaged by placing freewheel control in freewheeling position. Free wheel control is located at the rear drawbar of tractor.

- Raise attachment lift to highest position with attachment lift control.
- Pull freewheel control out and into the slot and release so it is held in the disengaged position.
- Do not push or tow tractor at more than two (2) mph (3,2 km/h).
- To reengage transmission, reverse above procedure.




Fig. 12

NOTE: To protect hood from damage when transporting your tractor on a truck or a trailer, ensure hood is closed and secured to tractor. Use an appropriate means of tying hood to tractor (rope, cord, etc.).

TOWING CARTS AND OTHER ATTACHMENTS

Tow only the attachments that are recommended by and comply with specifications of the manufacturer of your tractor. Use common sense when towing. Too heavy of a load, while on a slope, is dangerous. Tires can lose traction with the ground and cause you to lose control of your tractor.

HOURMETER

The hourmeter shows the total number of hours the engine has run. To service engine and mower, see the Maintenance section of this manual.

OPERATION

BEFORE STARTING THE ENGINE

CHECK ENGINE OIL LEVEL

The engine in your tractor has been shipped from the factory already filled with summer weight oil.

- Check engine oil with tractor on level ground.
- Pull up and remove oil fill cap/dipstick; wipe oil off. Reinsert the dipstick into the tube and push down firmly into place. Remove and read oil level. If necessary, add oil until "FULL" mark on dipstick is reached. Do not overfill.
- For cold weather operation you should change oil for easier starting. (See "OIL VISCOSITY CHART" in the Maintenance section of this manual.)
- To change engine oil, see the Maintenance section in this manual.

ADD GASOLINE

- Fill fuel tank to bottom of filler neck. Do not overfill. Use fresh, clean, regular gasoline with a minimum of 87 octane. Do not mix oil with gasoline. Purchase fuel in quantities that can be used within 30 days to ensure fuel freshness.



CAUTION: Wipe off any spilled oil or fuel. Do not store, spill or use gasoline near an open flame.

IMPORTANT: WHEN OPERATING IN TEMPERATURES BELOW 32°F (0°C), USE FRESH, CLEAN WINTER GRADE GASOLINE TO HELP ENSURE GOOD COLD WEATHER STARTING.

CAUTION: Alcohol blended fuels (called gasohol or using ethanol or methanol) can attract moisture which leads to separation and formation of acids during storage. Acidic gas can damage the fuel system of an engine while in storage. To avoid engine problems, the fuel system should be emptied before storage of 30 days or longer. Drain the gas tank, start the engine and let it run until the fuel lines and carburetor are empty. Use fresh fuel next season. See Storage Instructions for additional information. Never use engine or carburetor cleaner products in the fuel tank or permanent damage may occur. Fuel stabilizer is an acceptable alternative in minimizing the formation of fuel gum deposits during storage. Add stabilizer to gasoline in fuel tank or storage container. Always follow the mix ratio found on stabilizer container. Run engine at least 10 minutes after adding stabilizer to allow the stabilizer to reach the carburetor. Do not empty the gas tank and carburetor if using fuel stabilizer.

TO START ENGINE (See Fig. 3)

When starting the engine for the first time or if the engine has run out of fuel, it will take extra cranking time to move fuel from the tank to the engine.

- Ensure freewheel control is in the transmission engaged position.
- Sit on seat in operating position, depress brake pedal and set parking brake.
- Move attachment clutch to "DISENGAGED" position.
- Move throttle control to choke position.

NOTE: Before starting, read the warm and cold starting procedures below.

- Insert key into ignition and turn key clockwise to "START" position and release key as soon as engine starts. Do not run starter continuously for more than fifteen seconds per minute. If the engine does not start after several attempts, move throttle control to fast position, wait a few minutes and try again. If engine still does not start, move the throttle control back to the choke position and retry.

WARM WEATHER STARTING (50°F/10°C and above)

- When engine starts, move the throttle control to the fast position.
- The attachments and ground drive can now be used. If the engine does not accept the load, restart the engine and allow it to warm up for one minute using the choke as described above.

COLD WEATHER STARTING (50°F/10°C and below)

- When engine starts, allow engine to run with the throttle control in the choke position until the engine runs roughly, then move throttle control to fast position. This may require an engine warm-up period from several seconds to several minutes, depending on the temperature.

AUTOMATIC TRANSMISSION WARM UP

- Before driving the unit in cold weather, the transmission should be warmed up as follows:
 - Be sure the tractor is on level ground.
 - Release the parking brake and let the brake slowly return to operating position.
 - Allow one minute for transmission to warm up. This can be done during the engine warm up period.
- The attachments can also be used during the engine warm-up period after the transmission has been warmed up.

OPERATION

PURGE TRANSMISSION



CAUTION: Never engage or disengage free-wheel lever while the engine is running.

To ensure proper operation and performance, it is recommended that the transmission be purged before operating tractor for the first time. This procedure will remove any trapped air inside the transmission which may have developed during shipping of your tractor.

IMPORTANT: SHOULD YOUR TRANSMISSION REQUIRE REMOVAL FOR SERVICE OR REPLACEMENT, IT SHOULD BE PURGED AFTER REINSTALLATION BEFORE OPERATING THE TRACTOR.

1. Place tractor safely on a level surface - that is clear and open - with engine off and parking brake set.
2. Disengage transmission by placing freewheel control in disengaged position. (See "TO TRANSPORT" in this section of manual.)
3. Sitting in the tractor seat, start engine. After the engine is running, move throttle control to slow position. Disengage parking brake



CAUTION: At any time, during step 4, there may be movement of the drive wheels.

4. Depress forward drive pedal to full forward position, hold for five (5) seconds and release pedal. Depress reverse drive pedal to full reverse position, hold for five (5) seconds and release pedal. Repeat this procedure three (3) times.
5. Shut-off engine and set parking brake.
6. Engage transmission by placing freewheel control in engaged position. (See "TO TRANSPORT" in this section of manual.)
7. Sitting in the tractor seat, start engine. After the engine is running, move throttle control to half (1/2) speed. Disengage parking brake.
8. Drive tractor forward for approximately 5 feet (1.5 m) then backwards for 5 feet (1.5 m). Repeat this driving procedure three times.

Your transmission is now purged and now ready for normal operation.

MOWING TIPS

- DO NOT use tire chains when the mower housing is attached to tractor.
- Mower should be properly leveled for best mowing performance. See "TO LEVEL MOWER HOUSING" in the Service and Adjustments section of this manual.
- The left hand side of mower should be used for trimming.
- Drive so that clippings are discharged onto the area that has been cut. Have the cut area to the right of the tractor. This will result in a more even distribution of clippings and more uniform cutting.
- When mowing large areas, start by turning to the right so that clippings will discharge away from shrubs, fences, driveways, etc. After one or two rounds, mow in the opposite direction making left hand turns until finished (See Fig. 13).




Fig. 13

- If grass is extremely tall, it should be mowed twice to reduce load and possible fire hazard from dried clippings. Make first cut relatively high; the second to the desired height.
- Do not mow grass when it is wet. Wet grass will plug mower and leave undesirable clumps. Allow grass to dry before mowing.
- **Always operate engine at full throttle when mowing** to ensure better mowing performance and proper discharge of material. Regulate ground speed by selecting a low enough gear to give the mower cutting performance as well as the quality of cut desired.
- When operating attachments, select a ground speed that will suit the terrain and give best performance of the attachment being used.

MAINTENANCE

MAINTENANCE SCHEDULE		BEFORE EACH USE	EVERY 8 HOURS	EVERY 25 HOURS	EVERY 50 HOURS	EVERY 100 HOURS	EVERY SEASON	BEFORE STORAGE
TRACTOR	Check Brake Operation	✓	✓					
	Check Tire Pressure	✓	✓					
	Check Operator Presence and ROS Systems	✓						
	Check for Loose Fasteners	✓				✓		✓
	Check/Replace Mower Blades			✓ ³				
	Inspect/Clean Blade Holder Assembly			✓ ²				
	Lubrication Chart		✓					✓
	Check Battery Level		✓ ⁴					
	Clean Battery and Terminals		✓					✓
	Clean Debris off Steering Plate		✓ ⁵					
	Check Transaxle Cooling		✓					
	Check Mower Levelness				✓			
	Check V-Belts					✓		
ENGINE	Check Engine Oil Level	✓	✓					
	Change Engine Oil (models with oil filter)				✓ _{1,2}			✓
	Change Engine Oil (models without oil filter)			✓ _{1,2}				✓
	Clean Air Filter		✓ ₂					
	Clean Air Screen		✓ ₂					
	Inspect Muffler/Spark Arrestor				✓			
	Replace Oil Filter (If equipped)					✓ _{1,2}		
	Clean Engine Cooling Fins					✓ ₂		
	Replace Spark Plug					✓		✓
	Replace Air Filter Paper Cartridge					✓ ₂		
	Replace Fuel Filter						✓	

1 - Change more often when operating under a heavy load or in high ambient temperatures.

2 - Service more often when operating in dirty or dusty conditions.

3 - Replace blades more often when mowing in sandy soil.

4 - Not required if equipped with maintenance-free battery.

5 - See Cleaning in Maintenance Section.

GENERAL RECOMMENDATIONS

The warranty on this tractor does not cover items that have been subjected to operator abuse or negligence. To receive full value from the warranty, operator must maintain tractor as instructed in this manual.

Some adjustments will need to be made periodically to properly maintain your tractor.


At least once a season, check to see if you should make any of the adjustments described in the Service and Adjustments section of this manual.

- At least once a year you should replace the spark plug, clean or replace air filter, and check blades and belts for wear. A new spark plug and a clean air filter ensure proper air-fuel mixture and help your engine run better and last longer.

BEFORE EACH USE

- Check engine oil level.
- Check brake operation.
- Check tire pressure.
- Check operator presence and ROS systems for proper operation.
- Check for loose fasteners.

LUBRICATION CHART



① General Purpose Grease

② Refer to Maintenance "ENGINE" Section

IMPORTANT: DO NOT OIL OR GREASE THE PIVOT POINTS WHICH HAVE SPECIAL NYLON BEARINGS. VISCOUS LUBRICANTS WILL ATTRACT DUST AND DIRT THAT WILL SHORTEN THE LIFE OF THE SELF-LUBRICATING BEARINGS. IF YOU FEEL THEY MUST BE LUBRICATED, USE ONLY A DRY, POWDERED GRAPHITE TYPE LUBRICANT SPARINGLY.

MAINTENANCE

TRACTOR

Always observe safety rules when performing any maintenance.

BRAKE OPERATION

If tractor requires more than five (5) feet (1.5 m) to stop at highest speed in highest gear on a level, dry concrete or paved surface, then brake must be checked and adjusted. (See "TO CHECK BRAKE" in the Service and Adjustments section of this manual.)

TIRES

- Maintain proper air pressure in all tires. (See the sides of tires for proper PSI.)
- Keep tires free of gasoline, oil, or insect control chemicals which can harm rubber.
- Avoid stumps, stones, deep ruts, sharp objects and other hazards that may cause tire damage.

NOTE: To seal tire punctures and prevent flat tires due to slow leaks, tire sealant may be purchased from your local parts dealer. Tire sealant also prevents tire dry rot and corrosion.

OPERATOR PRESENCE SYSTEM AND REVERSE OPERATION SYSTEM (ROS) (See Fig. 14)

Be sure operator presence and reverse operation systems are working properly. If your tractor does not function as described, repair the problem immediately.

- The engine should not start unless the brake pedal is fully depressed, and the attachment clutch control is in the disengaged position.

CHECK OPERATOR PRESENCE SYSTEM

- When the engine is running, any attempt by the operator to leave the seat without first setting the parking brake should shut off the engine.
- When the engine is running and the attachment clutch is engaged, any attempt by the operator to leave the seat should shut off the engine.
- The attachment clutch should never operate unless the operator is in the seat.

CHECK REVERSE OPERATION (ROS) SYSTEM

- When the engine is running with the ignition switch in the engine "ON" position and the attachment clutch engaged, any attempt by the operator to shift into reverse should shut off the engine.
- When the engine is running with the ignition switch in the ROS "ON" position and the attachment clutch engaged, any attempt by the operator to shift into reverse should NOT shut off the engine.




Fig. 14

BATTERY

Your tractor has a battery charging system which is sufficient for normal use. However, periodic charging of the battery with an automotive charger will extend its life.

- Keep battery and terminals clean.
- Keep battery bolts tight.
- Keep small vent holes open.
- Recharge at 6-10 amperes for 1 hour.

NOTE: The original equipment battery on your tractor is maintenance free. Do not attempt to open or remove caps or covers. Adding or checking level of electrolyte is not necessary.

TO CLEAN BATTERY AND TERMINALS

Corrosion and dirt on the battery and terminals can cause the battery to "leak" power.

- Remove terminal guard.
- Disconnect BLACK battery cable first then RED battery cable and remove battery from tractor.
- Rinse the battery with plain water and dry.
- Clean terminals and battery cable ends with wire brush until bright.
- Coat terminals with grease or petroleum jelly.
- Reinstall battery. (See "REPLACING BATTERY" in the Service and Adjustments section of this manual.)

V-BELTS

Check V-belts for deterioration and wear after 100 hours of operation and replace if necessary. The belts are not adjustable. Replace belts if they begin to slip from wear.

TRANSAXLE COOLING

The transmission fan and cooling fins should be kept clean to assure proper cooling.

Do not attempt to clean fan or transmission while engine is running or while the transmission is hot. To prevent possible damage to seals, do not use high pressure water or steam to clean transaxle.

- Inspect cooling fan to be sure fan blades are intact and clean.
- Inspect cooling fins for dirt, grass clippings and other materials. To prevent damage to seals, do not use compressed air or high pressure sprayer to clean cooling fins.

TRANSAXLE PUMP FLUID

The transaxle was sealed at the factory and fluid maintenance is not required for the life of the transaxle. Should the transaxle ever leak or require servicing, contact your nearest authorized service center/department.

MAINTENANCE

BLADE CARE

For best results mower blades must be kept sharp. Replace bent or damaged blades.



CAUTION: Use only a replacement blade approved by the manufacturer of your tractor. Using a blade not approved by the manufacturer of your tractor is hazardous, could damage your tractor, and void your warranty.

BLADE REPLACEMENT (See Figs. 15 - 20)

- Raise mower to highest position to allow access to blades.

CAUTION: When handling the blade, protect your hands with gloves and/or wrap blade with heavy cloth.

TO REMOVE BLADE

- Squeeze tabs inward to release cap. Remove by lifting cap from hinge and set aside. (See Fig. 15.)




Fig. 15

- Slide thumb lock and release pivot to allow wire-form to swing free from standoffs. (See Fig. 16.)




Fig. 16

- Open the top plate and remove blade. (See Fig. 17.)

NOTE: Blade is held in place by magnets to prevent free release.




Fig. 17

TO INSTALL BLADE

- Clean area under top plate, the bottom of the mandrel assembly, and around bosses thoroughly to remove any dirt or debris.
- Align bosses and insert blade. (See Fig. 18.)

NOTE: Magnets should hold blade in place.




Fig. 18

- Close the top plate over the blade and hook the wire-form over the standoffs.
- Push pivot closed until secured by the thumb lock. (See Fig. 19.)




Fig. 19

- Reinstall cap. Hook cap onto hinge and rotate onto tabs. Press cap firmly into place, ensuring both tabs lock into cap. (See Fig. 20.)

NOTE: Replace cap if worn or cracked.




Fig. 20

MAINTENANCE

ENGINE

LUBRICATION

Only use high quality detergent oil rated with API service classification SJ-SN. Select the oil's SAE viscosity grade according to your expected operating temperature. When operating in temperatures below 0° F (-18° C) synthetic oil must be used.




Fig. 21

* **CAUTION:** Air cooled engines run hotter than automotive engines. The use of non-synthetic multi-viscosity oils (5W30, 10W30 etc.) in temperatures above 40° F (4° C) will result in higher than normal oil consumption. When using a multi-viscosity oil, check oil level more frequently.

** **CAUTION:** SAE 30 oil, if used below 40° F (4° C), will result in hard starting and possible engine bore damage due to inadequate lubrication.



NOTE: Synthetic oil meeting ILSAC GF-2, API certification mark and API service symbol (shown at left) with "SJ/CF ENERGY CONSERVING" or higher, is an acceptable oil at all temperatures. **Use of synthetic oil does not alter required oil change intervals.**

Change the oil after every 50 hours of operation or at least once a year if the tractor is not used for 50 hours in one year.

Check the crankcase oil level before starting the engine and after each eight (8) hours of operation. Tighten oil fill cap/dipstick securely each time you check the oil level.

TO CHANGE ENGINE OIL (See Fig. 21 - 23)

Determine temperature range expected before oil change. All oil must meet API service classification SJ-SN.

- Ensure tractor is on level surface.
- Oil will drain more freely when warm.
- Catch oil in a suitable container.

LOWER DASH COVER REMOVAL

- Raise hood.
- Remove fastener from lower dash cover.

CAUTION: Remove lower dash cover carefully to ensure cover tabs are not broken.

- Slide lower dash cover up to release cover tabs from tapered slots in lower dash and remove.




Fig. 22

- Remove oil fill cap/dipstick. Be careful not to allow dirt to enter the engine when changing oil.
- Remove yellow cap from end of drain valve and install the drain tube onto the fitting.
- Unlock drain valve by pushing inward and turning counterclockwise.
- To open, pull out on the drain valve.




Fig. 23

- After oil has drained completely, close and lock the drain valve by pushing inward and turning clockwise until the pin is in the locked position as shown.
- Remove the drain tube and replace the cap onto to the bottom fitting of the drain valve.
- Refill engine with oil through oil fill dipstick tube. Pour slowly. Do not overfill. For approximate capacity see "PRODUCT SPECIFICATIONS" section of this manual.
- Use gauge on oil fill cap/dipstick for checking level. Ensure dipstick cap is tightened securely for accurate reading. Keep oil at "FULL" line on dipstick. Tighten cap onto the tube securely when finished.

ENGINE OIL FILTER

Replace the engine oil filter every season or every other oil change if the tractor is used more than 100 hours in one year.

NOTE: If needed, remove lower dash covers using steps from "Lower dash cover removal" section of this manual.

AIR FILTER

Your engine will not run properly using a dirty air filter. Service air cleaner more often under dusty conditions.

MAINTENANCE

CLEAN AIR SCREEN

The air screen is over the air intake blower located on top of engine. The air screen must be kept free of dirt and chaff to prevent engine damage from overheating. Clean with a wire brush or compressed air to remove dirt and stubborn dried gum fibers.

ENGINE COOLING SYSTEM

To ensure proper cooling, make sure the grass screen, cooling fins, and other external surfaces of the engine are kept clean at all times.

Every 100 hours of operation (more often under extremely dusty, dirty conditions), remove the blower housing and other cooling shrouds. Clean the cooling fins and external surfaces as necessary. Ensure the cooling shrouds are reinstalled.

NOTE: Operating the engine with a blocked grass screen, dirty or plugged cooling fins, and/or cooling shrouds removed will cause engine damage due to overheating.

SPARK PLUGS

Replace spark plugs at the beginning of each mowing season or after every 100 hours of operation, whichever occurs first. Spark plug type and gap setting are shown in "PRODUCT SPECIFICATIONS" section of this manual.

MUFFLER

Inspect and replace corroded muffler and spark arrester (if equipped) as it could create a fire hazard and/or damage.

IN-LINE FUEL FILTER (See Fig. 24)

The fuel filter should be replaced once each season. If fuel filter becomes clogged, obstructing fuel flow to carburetor, replacement is required.

- With engine cool, remove filter and plug fuel line sections.
- Place new fuel filter in position in fuel line with arrow pointing towards carburetor.
- Be sure there are no fuel line leaks and clamps are properly positioned.
- Immediately wipe up any spilled gasoline.




Fig. 24

CLEANING

- Clean engine, battery, seat, finish, etc. of all foreign matter.
- Clean debris from steering plate. Debris can restrict clutch/brake pedal shaft movement, causing belt slip and loss of drive. See Fig. 25.



CAUTION: Avoid all pinch points and movable parts.




Fig. 25

- Keep finished surfaces and wheels free of all gasoline, oil, etc.
- Protect painted surfaces with automotive type wax.

Except for the washout port (if equipped), we do not recommend using a garden hose or pressure washer to clean the outside of your tractor unless the engine and transmission are covered to keep water out. Water in engine or transmission will shorten the useful life of your tractor. Use compressed air or a leaf blower to remove grass, leaves and trash from outside tractor and mower.

MAINTENANCE

DECK WASHOUT PORT (See Fig. 26)

Your tractor's deck is equipped with a washout port as part of its deck wash system. It should be utilized after each use.

1. Drive the tractor to a level, clear spot on your lawn, near enough to a water spigot for your garden hose to reach.

IMPORTANT: Make certain the tractor's discharge chute is directed AWAY from your house, garage, parked cars, etc. Remove bagger chute or mulch cover if attached.

2. Make sure the attachment clutch control is in the "DISENGAGED" position, set the parking brake, and stop the engine.
3. Pull back the lock collar of the nozzle adapter and push the adapter onto the deck washout port at the left end of the mower deck. Release the lock collar to lock the adapter on the nozzle.




Fig. 26

IMPORTANT: Tug hose ensuring connection is secure.

4. Turn the water on.
5. While sitting in the operator's position on the tractor, re-start the engine and place the throttle lever in the Fast "Fast" position.

IMPORTANT: Recheck the area to ensure the area is clear. Ensure no children are in the area while cleaning the deck.

6. Move the tractor's attachment clutch control to the "ENGAGED" position. Remain in the operator's position with the cutting deck engaged until the deck is cleaned.
7. Move the tractor's attachment clutch control to the "DISENGAGED" position. Turn the ignition key to the STOP position to turn the tractor's engine off. Turn the water off.
8. Pull back the lock collar of the nozzle adapter to disconnect the adapter from the nozzle washout port.
9. Move the tractor to a dry area, preferably a concrete or paved area. Place the attachment clutch control in the "ENGAGED" position to remove excess water and to help dry before putting the tractor away.



WARNING: A broken or missing washout fitting could expose you or others to thrown objects from contact with the blade.

- Replace broken or missing washout fitting immediately, prior to using mower again.
- Plug any holes in mower with bolts and locknuts.

SERVICE AND ADJUSTMENTS



WARNING: TO AVOID SERIOUS INJURY, BEFORE PERFORMING ANY SERVICE OR ADJUSTMENTS:

- Depress brake pedal fully and set parking brake.
- Place attachment clutch in "DISENGAGED" position.
- Turn ignition key to "STOP" and remove key.
- Make sure the blades and all moving parts have completely stopped.
- Disconnect spark plug wire from spark plug and place wire where it cannot come in contact with plug.

TO REMOVE MOWER (See Fig. 27)

- Place attachment clutch in "DISENGAGED" position.
- Lower attachment lift lever to its lowest position.
- Remove mower belt from electric clutch pulley (M).
- Disconnect front link (E) from mower - remove retainer spring and washer.
- Go to either side of mower and disconnect mower suspension arm (A) from chassis and rear lift link (C) from rear mower bracket (D) - remove retainer springs and washers.
- Go to other side of mower and disconnect the suspension arm and rear lift link.



CAUTION: After rear lift links are disconnected, the attachment lift lever will be spring loaded. Have a tight grip on lift lever when changing position of the lever.

- Slide mower out from under right side of tractor.




Fig. 27

TO INSTALL MOWER (See Figs. 27 - 32)

Ensure tractor is on level surface and engage parking brake.

- Lower attachment lift lever to its lowest position.



CAUTION: Lift lever is spring loaded. Have a tight grip on lift lever, lower it slowly and engage in lowest position.

NOTE: Ensure mower side suspension arms (A) are pointing forward before sliding mower under tractor.

- Slide mower under tractor until it is centered under tractor.

SERVICE AND ADJUSTMENTS

- ATTACH MOWER SIDE SUSPENSION ARMS (A) TO CHASSIS - Position hole in arm over pin (B) on outside of tractor chassis and secure with retainer spring.
- Repeat on opposite side of tractor.




Fig. 28

- ATTACH REAR LIFT LINKS (C) - Lift rear corner of mower and position slot in link assembly over pin on rear mower bracket (D) and secure with washer and retainer spring.




Fig. 29

- ATTACH FRONT LINK (E) - Work from left side of tractor. Insert rod end of link assembly through front hole in tractor front suspension bracket (F).
- Insert end of link (E) into hole in front mower bracket (H) and secure with washer and retainer spring (J).




Fig. 30

- Install belt onto electric clutch pulley (M).




Fig. 31

IMPORTANT: CHECK BELT FOR PROPER ROUTING IN ALL MOWER PULLEY GROOVES.

- Raise attachment lift lever to highest position.
- If necessary, adjust gauge wheels before operating mower as shown in the Operation section of this manual.




Fig. 32

SERVICE AND ADJUSTMENTS

TO LEVEL MOWER

Ensure tires are properly inflated to the PSI shown on tires. If tires are over or under inflated, it may affect the appearance of your lawn and lead you to think the mower is not adjusted properly.

VISUAL SIDE-TO-SIDE ADJUSTMENT (See Fig. 33)

- With all tires properly inflated and if your lawn appears unevenly cut, determine which side of mower is cutting lower.
- With a 3/4" or adjustable wrench, turn lift link adjustment nut (A) to the left to lower LH side of mower, or, to the right to raise LH side of mower.




Fig. 33

NOTE: Each full turn of adjustment nut will change mower height about 3/16" (4,7 mm).

- Test your adjustment by mowing some uncut grass and visually checking the appearance. Readjust, if necessary, until you are satisfied with the results.

PRECISION SIDE-TO-SIDE ADJUSTMENT (See Fig. 34)

- With all tires properly inflated, park tractor on level ground or driveway.



CAUTION: Blades are sharp. Protect your hands with gloves and/or wrap blade with heavy cloth.

- Raise mower to its highest position.
- At both sides of mower, position blade at side and measure the distance (A) from bottom edge of blade to the ground. The distance should be the same on both sides.
- If adjustment is necessary, see steps in Visual Adjustment instructions above.
- Recheck measurements, adjust if necessary until both sides are equal.




Fig. 34

FRONT-TO-BACK ADJUSTMENT (See Figs. 35 & 36)

IMPORTANT: Deck must be level side-to-side.

To obtain the best cutting results, the mower blades should be adjusted so the front tip is 1/8" to 1/2" (3,1 to 12,7 mm) lower than the rear tip when the mower is in its highest position.



CAUTION: Blades are sharp. Protect your hands with gloves and/or wrap blade with heavy cloth.

- Raise mower to highest position.
- Position blade so the tip is pointing straight forward. Measure distance (B) to the ground at front and rear tip of the blade.
- If front tip of blade is not 1/8" to 1/2" (3,1 to 12,7 mm) lower than the rear tip, go to the front of tractor.




Fig. 35

- With an 11/16" or adjustable wrench, loosen jam nut A several turns to clear adjustment nut B.
- With a 3/4" or adjustable wrench, turn front link adjustment nut (B) clockwise (↷) (tighten) to raise the front of mower, or, counterclockwise (↶) (loosen) to lower the front mower.




Fig. 36

NOTE: Each full turn of the adjustment nut will change mower height about 1/8" (3,1 mm).

- Recheck measurements, adjust if necessary until front tip of blade is 1/8" to 1/2" (3,1 to 12,7 mm) lower than the rear tip.
- Hold adjustment nut in position with wrench and tighten jam nut securely against adjustment nut.

SERVICE AND ADJUSTMENTS

TO REPLACE MOWER BLADE DRIVE BELT (See Fig. 37)

MOWER DRIVE BELT REMOVAL

- Park tractor on a level surface. Engage parking brake.
- Lower attachment lift lever to its lowest position.
- Remove any dirt or grass clippings which may have accumulated around mandrels and entire upper deck surface.
- Remove belt from electric clutch pulley (M), both mandrel pulleys (R) and all idler pulleys (V).

MOWER DRIVE BELT INSTALLATION

- Install belt around all mandrel pulleys (R) and around idler pulleys (V) as shown.
- Install belt onto electric clutch pulley (M).

IMPORTANT: Check belt for proper routing in all mower pulley grooves.

- Raise attachment lift lever to highest position.




Fig. 37

TO CHECK BRAKE

If tractor requires more than five (5) feet (1.5 m) to stop at highest speed in highest gear on a level, dry concrete or paved surface, then brake must be serviced.

You may also check brake by:

1. Park tractor on a level, dry concrete or paved surface, depress brake pedal all the way down and engage parking brake.
2. Disengage transmission by placing freewheel control in "transmission disengaged" position. Pull freewheel control out and into the slot and release so it is held in the disengaged position.

The rear wheels must lock and skid when you try to manually push the tractor forward. If the rear wheels rotate, then the brake needs to be serviced. Contact a Sears or other qualified service center.

TO REPLACE MOTION DRIVE BELT (See Fig. 38)

Park the tractor on level surface. Engage parking brake. For assistance, there is a belt installation guide decal on bottom side of left footrest.

BELT REMOVAL -

1. Remove mower. (See "TO REMOVE MOWER" section in this manual.)

NOTE: Observe entire motion drive belt and position of all belt guides and keepers.

2. Disconnect clutch wire harness (A).
3. Remove anti-rotation link (B) on right side of tractor.
4. Remove belt from stationary idler (C) and clutching idler (D).
5. Remove belt from centerspan idler (E).
6. Pull belt slack toward rear of tractor. Carefully remove belt upwards from transmission input pulley and over cooling fan blades (F).
7. Remove belt downward from engine pulley and around electric clutch (G).
8. Slide belt toward rear of tractor, off the steering plate (H) and remove from tractor.

BELT INSTALLATION -

1. Install new belt from tractor rear to front, over the steering plate (H) and above clutch brake pedal shaft (J).
2. Pull belt toward front of tractor and roll belt around electric clutch and onto engine pulley (G).
3. Pull belt toward rear of tractor. Carefully work belt down around transmission cooling fan and onto the input pulley (F). Be sure belt is inside the belt keeper.
4. Install belt on centerspan idler (E).
5. Install belt through stationary idler (C) and clutching idler (D).
6. Reinstall anti-rotation link (B) on right side of tractor. Tighten securely.
7. Reconnect clutch harness (A).
8. Ensure belt is in all pulley grooves and inside all belt guides and keepers.
9. Install mower. (See "TO INSTALL MOWER" section in this manual.)




Fig. 38

SERVICE AND ADJUSTMENTS

TO REMOVE WHEEL (See Fig. 39)

- Block up axle securely.
- Remove axle cover, retaining ring and washers to allow wheel removal (rear wheel contains a square key - Do not lose).
- Repair tire and reassemble.
- On rear wheels only: align grooves in rear wheel hub and axle. Insert square key.
- Replace washers and snap retaining ring securely in axle groove.
- Replace axle cover.

NOTE: To seal tire punctures and prevent flat tires due to slow leaks, tire sealant may be purchased from your local parts dealer. Tire sealant also prevents tire dry rot and corrosion.




Fig. 39

FRONT WHEEL TOE-IN/CAMBER

Your new tractor front wheel toe-in and camber is set at the factory and is normal. The front wheel toe-in and camber are not adjustable. If damage has occurred to affect the factory set front wheel toe-in or camber, contact a qualified service center.

TO START ENGINE WITH A WEAK BATTERY (See Fig. 40)



WARNING: Lead-acid batteries generate explosive gases. Keep sparks, flame and smoking materials away from batteries. Always wear eye protection when around batteries.

If your battery is too weak to start the engine, it should be recharged. (See "BATTERY" in the MAINTENANCE section of this manual).

If "jumper cables" are used for emergency starting, follow this procedure:

IMPORTANT: YOUR TRACTOR IS EQUIPPED WITH A 12 VOLT SYSTEM. THE OTHER VEHICLE MUST ALSO BE A 12 VOLT SYSTEM. DO NOT USE YOUR TRACTOR BATTERY TO START OTHER VEHICLES.

TO ATTACH JUMPER CABLES -

- Connect one end of the RED cable to the POSITIVE (+) terminal of each battery(A-B), taking care not to short against tractor chassis.
- Connect one end of the BLACK cable to the NEGATIVE (-) terminal (C) of fully charged battery.
- Connect the other end of the BLACK cable (D) to good chassis ground, away from fuel tank and battery.

TO REMOVE CABLES, REVERSE ORDER -

- BLACK cable first from chassis and then from the fully charged battery.
- RED cable last from both batteries.




Fig. 40

REPLACING BATTERY (See Fig. 41)



WARNING: Do not short battery terminals by allowing a wrench or any other object to contact both terminals at the same time. Before connecting battery, remove metal bracelets, wristwatch bands, rings, etc. Positive terminal must be connected first to prevent sparking from accidental grounding.

- Lift hood to raised position.
- Remove terminal cover.
- Disconnect BLACK battery cable then RED battery cable and carefully remove battery from tractor.
- Install new battery with terminals in same position as old battery.
- Reinstall terminal cover.
- First connect RED battery cable to positive (+) battery terminal with bolt and nut as shown. Tighten securely.
- Connect BLACK grounding cable to negative (-) battery terminal with remaining bolt and nut. Tighten securely
- Close hood.




Fig. 41

SERVICE AND ADJUSTMENTS

TO REPLACE HEADLIGHT BULB

- Raise hood.
- Pull bulb holder out of the hole in the backside of the grill.
- Replace bulb in holder and push bulb holder securely back into the hole in the backside of the grill.
- Close hood.

INTERLOCKS AND RELAYS

Loose or damaged wiring may cause your tractor to run poorly, stop running, or prevent it from starting.

- Check wiring.

TO REPLACE FUSE

Replace with 20 amp automotive-type plug-in fuse. The fuse holder is located behind the dash.

TO REMOVE HOOD & GRILL ASSEMBLY (See Fig. 42)

1. Raise hood.
2. Unsnap headlight wire connector.
3. Remove retainer clip and washer from right hand pivot pin.
4. Stand in front of tractor. Grasp hood at sides and slide left removing hood from pivot pins and lift hood off of tractor.
5. When replacing hood, reconnect the headlight wire connector, and reinstall the washer and retainer clip on the right hand pivot pin.




Fig. 42

TRANSMISSION

REMOVAL/REPLACEMENT

Should your transmission require removal for service or replacement, it should be purged after reinstallation and before operating the tractor. See "PURGE TRANSMISSION" in the Operation section of this manual.

ENGINE

TO ADJUST THROTTLE CONTROL CABLE

The throttle control has been preset at the factory and adjustment should not be necessary. If adjustment is necessary, see engine manual.

TO ADJUST CHOKE CONTROL

The choke control has been preset at the factory and adjustment should not be necessary. If adjustment is necessary, see engine manual.

STORAGE

Immediately prepare your tractor for storage at the end of the season or if the tractor will not be used for 30 days or more.



WARNING: Never store the tractor with gasoline in the tank inside a building where fumes may reach an open flame or spark. Allow the engine to cool before storing in any enclosure.

TRACTOR

Remove mower from tractor for winter storage. When mower is to be stored for a period of time, clean it thoroughly, remove all dirt, grease, leaves, etc. Store in a clean, dry area.

- Clean entire tractor. (See "CLEANING" in the Maintenance section of this manual.)
- Inspect and replace belts, if necessary. (See belt replacement instructions in the Service and Adjustments section of this manual.)
- Lubricate as shown in the Maintenance section of this manual.
- Be sure that all nuts, bolts and screws are securely fastened. Inspect moving parts for damage, breakage and wear. Replace if necessary.
- Touch up all rusted or chipped paint surfaces; sand lightly before painting.

BATTERY

- Fully charge the battery for storage.
- After a period of time in storage, battery may require recharging.
- To help prevent corrosion and power leakage during long periods of storage, battery cables should be disconnected and battery cleaned thoroughly. (See "TO CLEAN BATTERY AND TERMINALS" in the Maintenance section of this manual.)
- After cleaning, leave cables disconnected and place cables where they cannot come in contact with battery terminals.
- If battery is removed from tractor for storage, do not store battery directly on concrete or damp surfaces.
- If unit is equipped with battery indicator/charging plug, an optional charging unit may be purchased and connected to the unit to charge the battery during long term storage. Inspect and clean the battery terminals as needed prior to long term storage with charger connected.

ENGINE

FUEL SYSTEM

IMPORTANT: IT IS IMPORTANT TO PREVENT GUM DEPOSITS FROM FORMING IN ESSENTIAL FUEL SYSTEM PARTS SUCH AS CARBURETOR, FUEL FILTER, FUEL HOSE, OR TANK DURING STORAGE. ALSO, EXPERIENCE INDICATES THAT ALCOHOL BLENDED FUELS (CALLED GASOHOL OR USING ETHANOL OR METHANOL) CAN ATTRACT MOISTURE WHICH LEADS TO SEPARATION AND FORMATION OF ACIDS DURING STORAGE. ACIDIC GAS CAN DAMAGE THE FUEL SYSTEM OF AN ENGINE WHILE IN STORAGE.

- Empty the fuel tank by starting the engine and let it run until the fuel lines and carburetor are empty.
- Never use engine or carburetor cleaner products in the fuel tank or permanent damage may occur.
- Use fresh fuel next season.

NOTE: Fuel stabilizer is an acceptable alternative in minimizing the formation of fuel gum deposits during storage. Add stabilizer to gasoline in fuel tank or storage container. Always follow the mix ratio found on stabilizer container. Run engine at least 10 minutes after adding stabilizer to allow the stabilizer to reach the carburetor. Do not empty the gas tank and carburetor if using fuel stabilizer.

ENGINE OIL

Drain oil (with engine warm) and replace with clean engine oil. (See "ENGINE" in the Maintenance section of this manual.)

CYLINDER(S)

- Remove spark plug(s).
- Pour one ounce (29.5 mL) of oil through spark plug hole(s) into cylinder(s).
- Turn ignition key to "START" position for a few seconds to distribute oil.
- Replace with new spark plug(s).

OTHER

- Do not store gasoline from one season to another.
- Replace your gasoline can if your can starts to rust. Rust and/or dirt in your gasoline will cause problems.
- If possible, store your tractor indoors and cover it to give protection from dust and dirt.
- Cover your tractor with a suitable protective cover that does not retain moisture. Do not use plastic. Plastic cannot breathe which allows condensation to form and will cause your tractor to rust.

IMPORTANT: NEVER COVER TRACTOR WHILE ENGINE AND EXHAUST AREAS ARE STILL WARM.


TROUBLESHOOTING

PROBLEM	CAUSE	CORRECTION
Will not start	1. Out of fuel. 2. Engine not "CHOKED" properly. 3. Engine flooded. 4. Bad spark plug. 5. Dirty air filter. 6. Dirty fuel filter. 7. Water in fuel. 8. Loose or damaged wiring. 9. Engine valves out of adjustment.	1. Fill fuel tank. 2. See "TO START ENGINE" in Operation section. 3. Wait several minutes before attempting to start. 4. Replace spark plug. 5. Clean/replace air filter. 6. Replace fuel filter. 7. Empty fuel tank and carburetor, refill tank with fresh gasoline and replace fuel filter. 8. Check all wiring. 9. Contact an authorized service center/department.
Hard to start	1. Dirty air filter. 2. Bad spark plug. 3. Weak or dead battery. 4. Dirty fuel filter. 5. Stale or dirty fuel. 6. Loose or damaged wiring. 7. Engine valves out of adjustment.	1. Clean/replace air filter. 2. Replace spark plug. 3. Recharge or replace battery. 4. Replace fuel filter. 5. Empty fuel tank and refill tank with fresh, clean gas. 6. Check all wiring. 7. Contact an authorized service center/department.
Engine will not turn over	1. Brake pedal not depressed. 2. Attachment clutch is engaged. 3. Weak or dead battery. 4. Blown fuse. 5. Corroded battery terminals. 6. Loose or damaged wiring. 7. Faulty ignition switch. 8. Faulty solenoid or starter. 9. Faulty operator presence switch(es).	1. Depress brake pedal. 2. Disengage attachment clutch. 3. Recharge or replace battery. 4. Replace fuse. 5. Clean battery terminals. 6. Check all wiring. 7. Check/replace ignition switch. 8. Check/replace solenoid or starter. 9. Contact an authorized service center/department.
Engine clicks but will not start	1. Weak or dead battery. 2. Corroded battery terminals. 3. Loose or damaged wiring. 4. Faulty solenoid or starter.	1. Recharge or replace battery. 2. Clean battery terminals. 3. Check all wiring. 4. Check/replace solenoid or starter.
Loss of power	1. Cutting too much grass/too fast. 2. Throttle in "CHOKE" position. 3. Build-up of grass, leaves, trash under mower. 4. Dirty air filter. 5. Low oil level/dirty oil. 6. Faulty spark plug. 7. Dirty fuel filter. 8. Stale or dirty fuel. 9. Water in fuel. 10. Spark plug wire loose. 11. Dirty engine air screen/fins. 12. Dirty/clogged muffler. 13. Loose or damaged wiring. 14. Engine valves out of adjustment.	1. Raise cutting height/reduce speed. 2. Adjust throttle control. 3. Clean underside of mower housing. 4. Clean/replace air filter. 5. Check oil level/change oil. 6. Clean and regap or change spark plug. 7. Replace fuel filter. 8. Empty fuel tank and refill tank with fresh, clean gas. 9. Empty fuel tank and carburetor, refill tank with fresh gasoline and replace fuel filter. 10. Connect and tighten spark plug wire. 11. Clean engine air screen/fins. 12. Clean/replace muffler. 13. Check all wiring. 14. Contact an authorized service center/department.
Excessive vibration	1. Worn, bent or loose blade. 2. Bent blade mandrel. 3. Loose/damaged part(s).	1. Replace blade. Tighten blade bolt. 2. Replace blade mandrel. 3. Tighten loose part(s). Replace damaged parts.

TROUBLESHOOTING

PROBLEM	CAUSE	CORRECTION
Engine continues to run when operator leaves seat with attachment clutch engaged	1. Faulty operator-safety presence control system.	<p>1. Check wiring, switches and connections. If not corrected, contact an authorized service center/department.</p> <p> CAUTION: DO NOT operate machine until problem is corrected.</p>
Poor cut - uneven	<p>1. Worn, bent or loose blade.</p> <p>2. Mower deck not level.</p> <p>3. Buildup of grass, leaves, trash under mower.</p> <p>4. Bent blade mandrel.</p> <p>5. Clogged mower deck vent holes from buildup of grass, leaves, and trash around mandrels.</p>	<p>1. Replace blade. Tighten blade bolt.</p> <p>2. Level mower deck.</p> <p>3. Clean underside of mower housing.</p> <p>4. Replace blade mandrel.</p> <p>5. Clean around mandrels to open vent holes.</p>
Mower blades will not rotate	<p>1. Obstruction in clutch mechanism.</p> <p>2. Worn/damaged mower drive belt.</p> <p>3. Frozen idler pulley.</p> <p>4. Frozen blade mandrel.</p>	<p>1. Remove obstruction.</p> <p>2. Replace mower drive belt.</p> <p>3. Replace idler pulley.</p> <p>4. Replace blade mandrel.</p>
Poor grass discharge	<p>1. Engine speed too slow.</p> <p>2. Travel speed too fast.</p> <p>3. Wet grass.</p> <p>4. Mower deck not level.</p> <p>5. Low/uneven tire air pressure.</p> <p>6. Worn, bent or loose blade.</p> <p>7. Buildup of grass, leaves, trash under mower.</p> <p>8. Mower drive belt worn.</p> <p>9. Blades improperly installed.</p> <p>10. Improper blades used.</p> <p>11. Clogged mower deck vent holes from buildup of grass, leaves, trash around mandrels.</p>	<p>1. Place throttle control in "FAST" position.</p> <p>2. Shift to slower speed.</p> <p>3. Allow grass to dry before mowing.</p> <p>4. Level mower deck.</p> <p>5. Check tires for proper air pressure.</p> <p>6. Replace blade. Tighten blade bolt.</p> <p>7. Clean underside of mower housing.</p> <p>8. Replace mower drive belt.</p> <p>9. Reinstall blades sharp edge down.</p> <p>10. Replace with blades listed in parts manual.</p> <p>11. Clean around mandrels to open vent holes.</p>
Headlight(s) not working (if so equipped)	<p>1. Switch is "OFF".</p> <p>2. Bulb(s) or lamp(s) burned out.</p> <p>3. Faulty light switch.</p> <p>4. Loose or damaged wiring.</p> <p>5. Blown fuse.</p>	<p>1. Turn switch "ON".</p> <p>2. Replace bulb(s) or lamp(s).</p> <p>3. Check/replace light switch.</p> <p>4. Check wiring and connections.</p> <p>5. Replace fuse.</p>
Battery will not charge	<p>1. Bad battery cell(s).</p> <p>2. Poor cable connections.</p> <p>3. Faulty regulator (if so equipped).</p> <p>4. Faulty alternator.</p>	<p>1. Replace battery.</p> <p>2. Check/clean all connections.</p> <p>3. Replace regulator.</p> <p>4. Replace alternator.</p>
Loss of drive	<p>1. Freewheel control in "disengaged" position.</p> <p>2. Debris on steering plate (if equipped).</p> <p>3. Motion drive belt worn, damaged, or broken.</p> <p>4. Air trapped in transmission during shipment or servicing.</p> <p>5. Axle key missing.</p>	<p>1. Place freewheel control in "engaged" position.</p> <p>2. See "CLEANING" in the Maintenance section.</p> <p>3. Replace motion drive belt.</p> <p>4. Purge transmission.</p> <p>5. Install axle key at rear wheel. See "TO REMOVE WHEEL" in the Service and Adjustments section.</p>
Engine "backfires" when turning engine "OFF"	1. Engine throttle control not set between half and full speed (fast) position before stopping engine.	1. Move throttle control between half and full speed (fast) position before stopping engine.
Engine dies when tractor is shifted into reverse	1. Reverse operation system (ROS) is not "ON" while mower or other attachment is engaged.	1. Turn ignition key to ROS "ON" position. See Operation section.

SUGGESTED GUIDE FOR SIGHTING SLOPES FOR SAFE OPERATION



1. Fold this page along dotted line indicated above.
2. Hold page before you so that its left edge is vertically parallel to a tree trunk or other upright structure.
3. Sight across the fold in the direction of hill slope you want to measure.
4. Compare the angle of the fold with the slope of the hill.

GENERAL: Craftsman products are warranted to be free from defects in materials or workmanship for a specific time period as set-out below (the "Warranty Period"). Warranties extend to the original purchaser of a Craftsman product only. Purchases made through an online auction or through any website other than www.sears.ca are excluded. The relevant Warranty Period commences on the original date of purchase. Within this period, SEARS CANADA, Inc. will, at its sole option, repair or replace any products or components which fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts or labor, provided that the customer shall be responsible for any transportation cost.

EXCLUSIONS: This warranty does not cover failures due to normal wear, abuse, misuse, neglect (including but not limited to the use of stale fuel, dirt, abrasives, moisture, rust, corrosion, or any adverse reaction due to improper storage or use habits), improper maintenance or failure to follow maintenance guidelines and/or instructions, failure to operate the product in accordance with the owner's manual or any additional instructions or information provided at the time of purchase or in subsequent communications with the original purchaser, accident or unauthorized alterations or repairs made or attempted by others. Also excluded from warranty coverage - except as provided below - are the following: maintenance, adjustments, components subject to wear including but not limited to: cosmetic components, belts, blades, blade adapters, bulbs, tires, filters, guide bars, lubricants, seats, grips, recoil assy's, saw chains and bars, trimmer lines and spools, spark plugs, starter ropers and tines, and discoloration resulting from ultraviolet light. Any product missing the model and/or serial number identification label will be disqualified from coverage under this warranty.

REPAIRS: Repairs have a 90 day warranty. If the defective product is still within the Warranty Period, then the new warranty is 90 days from the date of repair or to the end of the original Warranty Period, whichever period is longer.

DISCLAIMERS: THE WARRANTIES AND REMEDIES CONTAINED HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER ORAL OR WRITTEN (OTHER THAN AS STATED HEREIN), AND WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO ANY. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM PROVINCE TO PROVINCE.

IN NO EVENT SHALL SEARS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM THE USE, MISUSE OR INABILITY TO USE THE PRODUCT OR FROM DEFECTS IN THE PRODUCT. THE EXCLUSIONS IN THIS PARAGRAPH SHALL NOT APPLY IN JURISDICTIONS WHERE APPLICABLE LAW DOES NOT ALLOW FOR THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. IN SUCH JURISDICTIONS, THIS PARAGRAPH SHALL NOT APPLY, BUT THE REMAINING PROVISIONS OF THIS DOCUMENT SHALL REMAIN VALID.

SEARS retains the exclusive right to repair or replace the product or offer a full refund of the purchase price at its sole discretion. SUCH REMEDY SHALL BE YOUR SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY.

CUSTOMER RESPONSIBILITIES: In addition to complying with all suggested maintenance guidelines and instructions, customers' obligations shall include but shall not be limited to: operating the product in accordance with the owner's manual or any additional instructions or information provided at the time of purchase or in subsequent communications to the purchaser from time to time, exhibit reasonable care in the use, operation, maintenance, general upkeep and storage of the product. Failure to comply with these requirements will void any applicable warranty.

LIST OF APPLICABLE WARRANTY PERIODS: The following list contains the applicable Warranty Period for your Craftsman product and is based on a combination of the type of product or component and the intended and actual use of the product or component:

1. **90 DAYS:** Craftsman products intended for use or actually used for commercial, institutional, professional or income-producing purposes
2. **2 YEARS:** Craftsman riding lawn mowers, yard and garden tractors, walk behind mowers, tillers, brush cutters, snow blowers, handheld blowers, backpack blowers, hedge trimmers and electrical products for noncommercial, nonprofessional, non-institutional, or non-income-producing use, except for those components which are part of engine systems manufactured by third party engine manufacturers for which the purchase has received an separate warranty with product information supplied at the time of purchase.
3. **1 YEAR:** Craftsman power cutters, stump grinders, pole pruners, gas chain saws, electric chain saws, trimmer attachments, baggers and pole saws for noncommercial, nonprofessional, non-institutional, or non-income-producing use.
4. **90 DAYS:** All defective batteries, which will be replaced during this 90-day Warranty Period.
5. **60 DAYS:** Additional Warranty Period of 60 days will apply to adjustments and worn products or components BUT DOES NOT INCLUDE WEAR OR ADJUSTMENTS for products used for commercial, institutional, professional or income-producing purposes. Wear items include but are not limited to: belts, blades, tires, spark plugs, air filters, chains, shear bolts, skid plates, scraper bars, drift cutters, ropes, tines, collection bags and pulleys.

As the Warranty Period runs from the date of purchase and NOT from the date that a product is delivered, opened, assembled or first used, please ensure during this time period that your product or component has been assembled and tested for correct operation regardless of when you intend to actually use it. Claims made after the Warranty Period has expired will not be honored.

PROOF OF PURCHASE/DOCUMENTATION: Warranty coverage is conditioned upon the original purchaser furnishing SEARS CANADA or its authorized third party service provider if applicable, with the original sales receipt or other adequate written proof of the original purchase date and identification of the product. In the event that the original purchaser is unable to provide a copy of the original sales receipt, SEARS CANADA Inc. reserves the right to determine in its sole discretion what other written proof of the original purchase date and identification of the product is acceptable.

SERVICE NOTES

Get it fixed, at your home or ours!

Just Call:

1-800-4-MY-HOME[®]

(1-800-469-4663)

24 hours a day, 7 days a week

For the repair of major brand appliances **in your own home...**
no matter who made it, no matter who sold it!

For your nearest **Sears Parts and Service** location,
to bring in products like vacuums, lawn equipment and electronics.

For **Sears Parts & Service**, to order the replacement parts,
accessories and owner's manuals that you need to do-it-yourself.

www.sears.ca

To purchase or inquire about a Sears Maintenance Agreement, call:

1-800-361-6665

9 a.m. – 11 p.m. Mon. – Fri., EST, 9 a.m. – 4 p.m. Sat.

Pour service en français:

1-800-LE-FOYER^{MC}

(1-800-533-6937)

www.sears.ca



® / ™ Trademarks of Sears Brands Management Corporation used under license by Sears Canada

MD Marque déposée / MC Marque de commerce de Sears Brands Management Corporation utilisée en vertu d'une licence de Sears Canada

® / ™ Trademarks of Sears Brands Management Corporation used under license by Sears Canada
MD Marque déposée / MC Marque de commerce de Sears Brands Management Corporation utilisée en vertu d'une licence de Sears Canada



www.sears.ca
(1-800-469-4663)
1-800-4-MY-HOME®
 For service in English:

de 9 h à 23 h du lundi au vendredi (HNE), de 9 h à 16 h le samedi
1-800-361-6665

sur un contrat d'entretien Sears, téléphonez au:
 Pour acheter ou demander des renseignements

www.sears.ca

Pour connaître le no. de téléphone du **Service des pièces et de l'entretien**
 Sears afin de commander les pièces de rechange, accessoires et manuels d'instructions requis pour effectuer vous-même les réparations.

Pour connaître l'emplacement du **Service des pièces et de l'entretien**
 Sears le plus proche afin d'apporter à l'atelier des produits tels que des aspirateurs, tondeuses à gazon ou appareils électroniques.

Pour la réparation des appareils électroménagers de grandes marques à votre domicile ... peu importe le fabricant ou le détaillant!

24 heures par jour, 7 jours par semaine
(1-800-533-6937)
1-800-LE-FOYER
 Téléphonez au:

Faites-le réparer, à domicile ou à l'atelier!

REMARGUES D'ENTRETIEN

PREUVE D'ACHAT ET DOCUMENTS: La protection de la garantie est conditionnelle à la présentation par l'acheteur initial, à Sears Canada ou à son fournisseur de service autorisé s'il y a lieu, de la facture ou de toute autre preuve d'achat appropriée indiquant la date de l'achat et désignant le produit. Dans le cas où l'acheteur initial se réunit dans l'impossibilité de fournir une copie de sa facture, Sears Canada le réserve le droit d'établir, à sa seule discrétion, quelle autre preuve écrite de la date d'achat initial et de la désignation du produit est acceptable.

Etant donné que la période de garantie débute à la date d'achat et NON à la date à laquelle le produit est livré, l'emballage ouvert et l'appareil démonté ou démonté pour les premières fois, assuriez-vous que votre produit ou composition est asssemblé et mis à lessi pour servir le bon fonctionnement, quel que soit le moment où vous prévoyez de commencer à utiliser réellement. Les reclamations présentées après l'expiration de la garantie ne seront pas acceptées.

lames, pneus, bougies, filtres à air, chaînes, bouloons de cisaillement, plaques de protection, barres de racleage, coupe-coupe-
coulégeres, cordons, dénts, sacs collecteurs et poules.

60 JOURS - Une période de garantie additionnelle de 60 jours s'applique pour le réglage ou l'usure des produits déposés dans les institutions, professionnels ou librairies. Les articles sujet à l'usure englobent, sans s'y restreindre : les corrolles, compositions mises en évidence par le règlement ou l'usure des produits utilisés à des fins commerciales.

90 JOURS - Toutes les batteries défectueuses, qui sortent remplaçées pendant une période de garantie de 90 jours.

bordures et produits électriques à usage non commercial, non professionnels, non institutionnel ou non lucratif, sauf les bordures et produits portant le symbole de systèmes de mesure pour lesquels un motif de "label" est spécifié dans la partie finale des instructions sur le produit au moment de l'achat.

2. 2 ANS - Les produits de maturé Craftsman suivants : tondeuses à conducteur porté, tracteurs de jardin, tondeuses à conditionneuses, débroussailleurs, souffleuses à neige, souffleuses portatives, souffleuses d'herbes, taille-

90 OURS - Produits Craftsman devant être ou étant effectivement utilisés à des fins commerciales, institutionnelles, professionnelles ou lucratives.

LISTE DES PERIODES DE GARANTIE APPAREILS La liste ci-dessous indique la période de garantie applicable aux divers produits Craftsmen qu'elle concerne. La période de garantie détermine la durée au cours de laquelle le fabricant sera tenu à remplacer ou à réparer les appareils qui ne fonctionnent pas correctement.

RESPONSABILITÉS DU CLIENT: En plus d'observer toutes les consignes et directives d'entretien, le client doit s'acquitter, entre autres, des obligations suivantes: utiliser le produit conformément à ses obligations contractuelles pour l'utilisation, le fonctionnement, l'entretien général, le maintien en bon état et l'entreposage du produit. Le manquement à ces obligations entraînera une annulation de la garantie applicable.

Séries consacrée le droit exclusif de préparer ou de remplacer le produit ou encore d'offrir un remboursement complet de son prix d'achat, à sa seule discrétion. CE RECOURS SERA LE SEUL ET UNIQUE RECOURS DONT VOUS DISPOSEZ EN CAS D'INEXÉCUTION QUELLE QUE ELLE SOIT DE LA GARANTIE.

SEARS NE POURRA, EN AUCUN CAS ÊTRE TENUE RESPONSABLE DE TOUT DOMMAGE ACCÉSSOIRE, SPÉCIAL, INDIRECT OU CONSÉCUTIF, QUI RÉSULTERAIT DE L'UTILISATION, DU MÉSUAGÉ OU DE L'INCAPACITÉ D'UTILISER LE PRODUIT OU QUICQUEL AUTRE PRODUIT OU SERVICE DE EXCLUSIONS DU PRÉSENT PARAGRAPHE NE S'APPLIQUENT PAS DANS LES TERRITOIRES OU LA LOI NE PERMET PAS L'EXCLUSION DES DOMMAGES ACCESSOIRES OU CONSÉCUTIFS. DANS CES TERRITOIRES, LE PRÉSENT PARAGRAPHE SERA SANS EFFET, MAIS LES AUTRES DISPOSITIONS DU PRÉSENT DOCUMENT DEMEURENT VALIDES.


RESTRICTIONS : LES GARANTIES ET RECOURS DEFINIS DANS LES PRESENTES SONT EXCLUSIFS ET REMPLACENT TOUTE AUTRE GARANTIE, QUELLE SOIT VERBALE OU ECRITE (AUTRE QUE CELLES ENONCEES DANS LES PRESENTES) OU QUELLE SOIT EXPRESSE, IMPLICITE OU PRELUDE PAR LA LOI, SANS SE RESTREINDRE A AUCUNE. LA PRESENTE GARANTIE VOUS CONFERRE DES DROITS JURIDIQUES PRECIS, POUVANT DIFFERER D'UNE PROVINCE A L'AUTRE. QUELLE SOIT EXPRESSE, IMPLICITE OU ECRITE (AUTRE QUE CELLES ENONCEES DANS LES PRESENTES) OU QUELLE SOIT EXPRESSE, IMPLICITE OU PRELUDE PAR LA LOI, SANS SE RESTREINDRE A AUCUNE. LA PRESENTE GARANTIE VOUS CONFERRE DES DROITS JURIDIQUES PRECIS, POUVANT DIFFERER D'UNE PROVINCE A L'AUTRE.

REPARATIONS : Les préparations sont garanties pendant une période de 90 jours. Si le produit défectueux est toujours couvert par la garantie, la nouvelle garantie est de 90 jours à compter de la date de la réparation ou jusqu'à la fin de la période de garantie initiale, selon la plus longue des deux échéances.

GENERALITES : Les produits Craftsman sont garantis contre tout défaut de matériau ou de fabrication pendant une période de temps précisée, celle qui établie ci-dessous (la « période de garantie »). En outre, cette garantie est offerte uniquement à l'acheteur initial d'un produit Craftsman, à sa seule discrétion, à remplacer tout produit ou composant sera effectué pour le client sans frais de port ni de main-d'œuvre, à condition que le client prenne à sa charge les frais de transport.

GUIDE SUGGÈRE POUR L'ÉVALUATION DES PENTES AFIN D'AMÉLIORER LA SÉCURITÉ D'UTILISATION

29



AVERTISSEMENT: Pour éviter de vous blesser gravement, utilisez votre tracteur parallèlement à la pente, jamais transversalement. N'affrontez pas de pentes de plus de 15 degrés. Effectuez les virages graduellement afin d'éviter le renversement ou la perte de contrôle. Soyez extrêmement prudent quand vous changez de direction sur les pentes.

1. Pliez cette page suivant les pointillées, comme précédemment.
2. Tenez cette page devant vous, avec le côté gauche parallèle à un tronc d'arbre ou à tout autre structure verticale.
3. Regardez à travers la pliure dans la direction de la pente que vous entendez mesurer.
4. Comparez l'angle de la pliure avec la pente de la colline.

PROBLEME	CAUSE	CORRECTION
Le moteur marche-tourne sans accouplement avec le siège d'accessoire engagé	ATTENTION : n'utilisez pas la machine avant d'avoir corrigé le problème.	1. Le système qui détecte la présence du connecteur d'embrayage, les interrupteurs et les connexions. Si le problème n'est pas corrigé, contactez un centre d'entretien autorisé.
Les moteurs marche-tourne avec le siège d'accessoire engagé	ATTENTION : n'utilisez pas la machine avant d'avoir corrigé le problème.	1. Verifiez le câblage, les interrupteurs et les connexions. Si le problème n'est pas corrigé, contactez un centre d'entretien autorisé.
Coupe inégale		1. La lame est usée, tordue ou lâche. 2. Remplacez la lame. Serrez le bouton de lame. 3. Nivelez le carter de tonduse. 4. La carter de tonduse n'est pas équilibré. 5. Il y a une accumulation d'herbe, de feuilles, et de débris sous la tonduse. 6. Nettoyez le bouton de lame ou affilez-la. Serrez le bouton de lame. 7. La lame est usée, tordue ou lâche. 8. Remplacez la lame ou l'herbe avec un fil à l'herbe. 9. Remplacez les lames avec le bord tranchant vers le bas. 10. Les lames n'ont pas été correctement montées. 11. Nettoyez les faces de mandrin pour ouvrir les trous de mandrin.
Mauvaise décharge d'herbe		1. La vitesse de moteur est trop lente. 2. Déplacez la commande des gaz à la position rapide (FAST). 3. Herbe humide. 4. La vitesse de course est trop rapide. 5. Vérifiez la pression des pneus. 6. Remplacez la lame ou l'herbe avec un fil à l'herbe. 7. La lame est usée, tordue ou lâche. 8. Remplacez la lame ou l'herbe avec un fil à l'herbe. 9. Remplacez la lame avec le bord tranchant vers le bas. 10. Les lames n'ont pas été correctement montées. 11. Nettoyez les faces de mandrin pour ouvrir les trous de mandrin.
Les lames de tonduse		1. Enlevez l'obstruction. 2. Remplacez la courroie d'entraînement de tonduse. 3. Gantez-vous une paire de gants tendus. 4. Un mandrin de lame grippé. 4. Remplacez le mandrin de lame.
La lame humide		1. La vitesse de moteur est trop lente. 2. Déplacez la commande des gaz à la position rapide (FAST). 3. Herbe humide. 4. La vitesse de course est trop rapide. 5. Vérifiez la pression des pneus. 6. Remplacez la lame ou l'herbe avec un fil à l'herbe. 7. La lame est usée, tordue ou lâche. 8. Remplacez la lame ou l'herbe avec un fil à l'herbe. 9. Remplacez la lame avec le bord tranchant vers le bas. 10. Les lames n'ont pas été correctement montées. 11. Nettoyez les faces de mandrin pour ouvrir les trous de mandrin.
La mauvaise décharge d'herbe		1. La vitesse de moteur est trop lente. 2. Déplacez la commande des gaz à la position rapide (FAST). 3. Herbe humide. 4. La vitesse de course est trop rapide. 5. Vérifiez la pression des pneus. 6. Remplacez la lame ou l'herbe avec un fil à l'herbe. 7. La lame est usée, tordue ou lâche. 8. Remplacez la lame ou l'herbe avec un fil à l'herbe. 9. Remplacez la lame avec le bord tranchant vers le bas. 10. Les lames n'ont pas été correctement montées. 11. Nettoyez les faces de mandrin pour ouvrir les trous de mandrin.
Les phares mal alignés (si munis)		1. Limiteur est à la position d'arrêt (OFF). 2. Ampoule(s) ou lampe(s) grillées. 3. Limiteur des phares est défectueux. 4. Vérifiez/remplacez l'interrupteur des phares. 5. Remplacez la batterie.
La batterie ne charge pas		1. Malvauxs élément(s) de la batterie. 2. Malvauxs connexions du câble. 3. Vérifiez/remplacez toutes les connexions. 4. Remplacez la batterie.
Une perte d'entraînement		1. La commande de la roue libre est en position debout. 2. Voyez "NETTOYAGE" dans la section Entretien de ce manuel. 3. Remplacez la commande de la roue libre en position engagée. 4. Remplacez l'alternateur. 5. Remplacez le régulateur de tension (si munis).
Pétralade au silence		1. La commande des gaz de moteur n'est pas dans la position intermédiaire (entre rapide et lent) avant de couper le moteur. 2. Déplacez la commande des gaz de moteur n'est pas dans la position intermédiaire (entre rapide et lent) avant de couper le moteur. 3. Courroie d'entraînement de déplacement est cassée. 4. Purgez la transmission. 5. Réinstallez la clé carree d'axe. Voyez "POUR ENLEVER LES ROUES" dans la section Revision Entretien de ce manuel.
La tondeuse (ou son accessoire) s'arrête lorsqu'elle coupe le moteur		1. Tournez le ROS dans la position ON. 2. Système de fonctionnement en marche arrêté (ROS) est dans la position OFF.

GUIDE DE DÉPANNAGE

PROBLEME	CAUSE	CORRECTION
Le moteur refuse de démarrer	1. Sans essence. 2. Le moteur n'est pas démarré à froid correctement. 3. Le moteur est noyé. 4. Mauvaise bougie d'allumage. 5. Filtre à air sale. 6. Essence sale.	1. Remplissez le réservoir d'essence. 2. Référez-vous à la section fonctionnement. 3. Attendez quelques minutes avant d'essayer de démarrer. 4. Remplacez la bougie d'allumage. 5. Nettoyez/réemplaciez le filtre à air. 6. Remplacez le filtre d'essence. 7. Vérifiez l'essence du réservoir avec le filtre d'essence. 8. Remplacez le filtre à air. 9. Les soupapes de moteur demandent un réglage. 10. Contractez un centre d'entretien autorisé.
Le moteur tourne difficile	1. Filtre à air sale. 2. Mauvaise bougie d'allumage. 3. Batterie faible ou à plat. 4. Essence sale. 5. Filtre d'essence sale. 6. Essence sale ou vieille. 7. Il y a de l'eau dans l'essence. 8. Remplacez le filtre d'essence.	1. Nettoyez/réemplaciez le filtre à air. 2. Remplacez la bougie d'allumage. 3. Remplacez ou remplacez la batterie. 4. Remplacez l'embaragée d'accès. 5. Débrayez l'embaragée d'accès. 6. Remplacez sur la pédale de frein/embrayage. 7. Appuyez sur la pédale de frein/embrayage. 8. L'embaragée/accès est débrayé. 9. La pédale de frein/embrayage n'est pas bassee. 10. Appuyez sur la pédale de frein/embrayage.
Moteur ne tourne pas au ralenti	1. La pédale de frein/embrayage n'est pas bassee. 2. Débrayez l'embaragée d'accès. 3. Débrayez l'embaragée d'accès. 4. Fusible sauté. 5. Les bornes de batterie sont corrodées. 6. Essence sale. 7. Le câble de batterie ou à plat. 8. L'embaragée n'est pas basée.	1. Appuyez sur la pédale de frein/embrayage. 2. Débrayez l'embaragée d'accès. 3. Remplacez ou remplacez la batterie. 4. Remplacez le fusible. 5. Nettoyez les bornes de batterie. 6. Nettoyez le filtre d'essence. 7. Remplacez le filtre d'essence. 8. Remplacez la batterie. 9. Débrayez l'embaragée d'accès. 10. La pédale de frein/embrayage n'est pas bassee.
Il y a un déclic dans le moteur ne démarre pas	1. Batterie faible ou à plat. 2. Les bornes de batterie sont corrodées. 3. Il y a une accumulation d'herbe, de feuilles, etc dans sous la tondueuse. 4. Filtre à air sale. 5. Niveau d'huile bas/huile sale. 6. La bougie d'allumage est défectueuse. 7. Filtre d'essence sale. 8. Essence sale ou vieille. 9. Il y a de l'eau dans l'essence. 10. Broschez et serrez le fil de bougie d'allumage. 11. Tamis d'air du moteur/allètes sont sales. 12. Silencieux sale ou encrassee. 13. Le câble est lâche ou endommagé. 14. Les soupapes du moteur demandent un réglage.	1. Mettez à la position de coupe plus haute ou réduisez la vitesse. 2. Remplacez la commande des gaz à la position étranglée. 3. Il y a une accumulation d'herbe, de feuilles, etc dans sous la tondueuse. 4. Nettoyez/réemplaciez le filtre à air. 5. Nettoyez le niveau d'huile/chansez l'huile. 6. Vérifiez le filtre d'essence. 7. Remplacez le filtre d'essence. 8. Lessence sale ou vieille. 9. Il y a de l'eau dans l'essence. 10. Broschez et serrez le fil de bougie d'allumage. 11. Nettoyez le tamis d'air du moteur/allètes. 12. Nettoyez/réemplaciez le silencieux. 13. Vérifiez tout le câblage. 14. Contractez un centre d'entretien autorisé.
Le moteur manque de puissance	1. Vous tondez trop d'herbe/la vitesse de la tondue- sest trop rapide. 2. Broschez la commande des gaz. 3. Il y a une accumulation d'herbe, de feuilles, etc dans sous la tondueuse. 4. Broschez et serrez le filtre à air. 5. Nettoyez le niveau d'huile/chansez l'huile. 6. Vérifiez le filtre d'essence. 7. Remplacez le filtre d'essence. 8. Lessence sale ou vieille. 9. Il y a de l'eau dans l'essence. 10. Broschez et serrez le fil de bougie d'allumage. 11. Tamis d'air du moteur/allètes sont sales. 12. Silencieux sale ou encrassee. 13. Le câble est lâche ou endommagé. 14. Les soupapes du moteur demandent un réglage.	1. Broschez et serrez le fil de bougie d'allumage. 2. Broschez la commande des gaz. 3. Broschez et serrez le fil de bougie d'allumage. 4. Broschez et serrez le fil de bougie d'allumage. 5. Broschez et serrez le fil de bougie d'allumage. 6. Broschez et serrez le fil de bougie d'allumage. 7. Broschez et serrez le fil de bougie d'allumage. 8. Broschez et serrez le fil de bougie d'allumage. 9. Broschez et serrez le fil de bougie d'allumage. 10. Broschez et serrez le fil de bougie d'allumage. 11. Broschez et serrez le fil de bougie d'allumage. 12. Broschez et serrez le fil de bougie d'allumage. 13. Broschez et serrez le fil de bougie d'allumage. 14. Broschez et serrez le fil de bougie d'allumage.
Vibrations excessives de la tondeuse	1. lame est usée, torde, ou lâche. 2. Un mandrin de lame est tordu. 3. Des pièces sont lâches ou endommagées.	1. Remplacez la lame. Serrez à fond le bouton de lame. 2. Remplacez le mandrin de lame. 3. Serrez les pièces lâches. Remplacez les pièces endommagées.

GUIDE DE DÉPANNAGE

REVISION ET REGLAGES

POUR REMPLACER L'AMPOULE DES PHARES

- Soulevez le capot.
- Dégagez de la douille d'amphoule de l'orifice à l'arrière de la calandre.
- Retirez l'amphoule dans la douille et poussez à fond la douille d'amphoule dans l'orifice à l'arrière de la calandre.
- Replacez l'amphoule dans la douille et arrêtez de la faire tourner.
- Fermez le capot.

MOTEUR

- Vérifiez le câblage.
- Un câblage desserré ou arraché peut être la cause du mauvais fonctionnement de l'avant de non-démarrage du tracteur.

POUR REMPLACER LE FUSIBLE

Le portefusible est située directement derrière le tableau de bord. Remplacez par un fusible interchangeable de type automobile, de 20A.

POUR ENLEVER LE CAPOT ET LA CALANDE

- Soulevez le capot.
- Décorechez le connecteur de fil du phare.
- Retirez l'agrafe de retenue et la rondelle du tourillon droit.
- Mettez-vous devant le tracteur. Attrapez le capot par les côtés et glissez-le vers la gauche en dérouchant le capot du tourillon et soulevez le capot du tracteur.
- En repoussant le capot, repoussez le connecteur de fil du tourillon droit.




Fig. 42

POUR RÉGLER LA COMMANDE DU STARTER

La commande des gaz a été préreglée à l'usine et un réglage ne devrait pas être nécessaire. Si un réglage est nécessaire, voir le manuel du moteur.

La commande des gaz a été préreglée à l'usine et un réglage nécessaire devrait pas être nécessaire. Si un réglage est nécessaire, voir le manuel du moteur.

POUR RÉGLER LE CÂBLE DE LA COMMANDE DES GAZ

Si votre transmission doit être retirée pour un entretien ou pour être remplacée, elle doit être purgée après avoir été remisée à l'avant de faire fonctionner le tracteur. Voir "PURGEZ LA TRANSMISSION" dans la section Utilisation de ce manuel.

Si votre transmission doit être retirée pour un entretien ou pour être remplacée, elle doit être purgée après avoir été remisée à l'avant de faire fonctionner le tracteur. Voir "PURGEZ LA TRANSMISSION" dans la section Utilisation de ce manuel.

ENLEVEMENT/REMPLACEMENT

TRANSMISSION

REVISIION ET REGLAGES





Fig. 41

- Levrez le capot.
- Enlevez le protектор des bornes.
- Prenez le câble de la batterie NOIR et ensuite le câble de la batterie ROUGE et enlevez la batterie.
- Installez la nouvelle batterie en placant les bornes au même endroit que l'ancienne batterie.
- Reinstallez protектор des bornes.
- Prenez le câble de la batterie ROUGE à la borne positive (+) avec un bouton H et écornez à taguets qui restent. Serrez à fond.
- Branchez le câble de masse de batterie NOIR à la borne négative (-) avec le bouton H et écornez à taguets qui restent. Serrez à fond.
- Fermez les portes d'accès aux bornes.
- Fermez le capot.




REPLACER LA BATTERIE (Voir la Fig. 41)

Fig. 40

- Procédez.
- Détachez le câble de la batterie NOIR du châssis et ensuite le câble de la batterie ROUGE des deux batteries.
- Débranchez ensuite le câble ROUGE des deux batteries.
- Fixez solidement des câbles sous l'essieu.
- Enlevez le couvre-essieu, la baguette de retenue et les rondelles pour permettre l'enlèvement de la roue (la roue arrête de tourner pour pouvoir pincer pneu chez votre dépositaire de pièces. Étant donné que le couvre-essieu est également fait de plastique, vous pouvez activer le levier de la roue arrêter et insérer une rondelle dans la rainure de l'essieu).
- Sur les routes arrêter seulement; alignez les rainures dans le moyen de route arrêter et l'essieu. Insérez la clé arrêter dans la rainure de l'essieu.
- Préparez le pneu et rassemblez-le.
- Sur les routes arrêter seulement; alignez les rainures dans le moyen de route arrêter et l'essieu. Insérez la clé arrêter dans la rainure de l'essieu.
- Remarque: Pour boucler les cravaisons de pneus et pour prévenir les pneus à plat à cause des fuites, vous pouvez activer le levier de la roue arrêter et insérer une rondelle dans la rainure de l'essieu.
- REMARQUE: Pour éviter la corrosion du pneu, obturez le pneu aussi lasséchement et la corrosion du pneu.

- Si vous utilisez des "câbles de survoltage" pour un démarrage d'urgence, voici le procédé à suivre:
 - Si votre batterie est trop faible pour démarer le moteur, elle devrait être rechargeée. (Voir "BATTERIE" dans la section Entrien de votre véhicule est trop faible pour démarer le moteur).
 - Si vous avez une autre batterie contre le châssis mis à la masse. Maintenez l'autre extrémité du câble NOIR (D) au châssis mis à la masse.
 - Branchez une extrémité du câble ROUGE à la borne (C) NEGATIF de la batterie contre le châssis.
 - Branchez une extrémité du câble ROUGE à la borne (C) NEGATIF de la ne pas contre le châssis.
 - POSETIVE (+) de chaque extrémité du câble ROUGE à la borne (A-B) de la batterie contre le châssis.
 - POUR ATTACHER LES CÂBLES DE DEMARRAGE -
- IMPRIMANT: VOTRE TRACTEUR EST MUNI D'UN SYSTÈME DE 12 VOLTS. L'AUTRE VEHICULE DOIT AUSSI AVOIR UN Système de 12 VOLTS. UTILISEZ PAS LA BATTERIE DU VEHICULE, PORTANT, VOUS UTILISEZ DES "câbles de survoltage" pour un démarrage d'urgence.
- Si vous utilisez des câbles de survoltage pour un démarrage d'urgence, voici le procédé à suivre:
 - Si votre batterie est trop faible pour démarer le moteur, elle devrait être rechargeée. (Voir "BATTERIE" dans la section Entrien de votre véhicule est trop faible pour démarer le moteur).
 - Si vous avez une autre batterie contre le châssis mis à la masse.
 - Branchez une extrémité du câble NOIR à la borne (D) au châssis mis à la masse.
 - Branchez l'autre extrémité du câble NOIR à la borne (D) au châssis mis à la masse.
 - Branchez une extrémité du câble ROUGE à la borne (C) NEGATIF de la batterie contre le châssis.
 - Branchez une extrémité du câble ROUGE à la borne (C) NEGATIF de la ne pas contre le châssis.
 - POSETIVE (+) de chaque extrémité du câble ROUGE à la borne (A-B) de la batterie contre le châssis.
 - POUR ATTACHER LES CÂBLES DE DEMARRAGE -




POUR DEMARRER LE MOTEUR AVEC UNE BATTERIE FAIBLE (Voir la Fig. 40)

- La convexion autrefois le centre de carrossage des roues avant, contactez le centre réglable sur votre tracteur. Si des dommages affectent la convexion autrefois le centre de carrossage des roues avant ne sont pas d'entretien autrefois le plus proche.
- La convexion autrefois le centre de carrossage des roues avant, contactez le centre réglable sur votre tracteur. Si des dommages affectent la convexion autrefois le centre de carrossage des roues avant ne sont pas d'entretien autrefois le plus proche.

CONVERGENCE DES ROUES AVANT/CARROSSAGE

Fig. 39




- REMARQUE: Pour boucler les cravaisons de pneus et pour éviter la corrosion du pneu, obturez le pneu aussi lasséchement et la corrosion du pneu.
- REMARQUE: Pour éviter la corrosion du pneu, obturez le pneu aussi lasséchement et la corrosion du pneu.

- Préparez le pneu et rassemblez-le.
- Sur les routes arrêter seulement; alignez les rainures dans le moyen de route arrêter et l'essieu. Insérez la clé arrêter dans la rainure de l'essieu.
- Préinstallez les rondelles et insérez à fond la baguette de retenue dans la rainure de l'essieu.
- Préinstallez le couvre-essieu. Alignez les rainures dans le moyen de route arrêter et l'essieu. Insérez la clé arrêter dans la rainure de l'essieu.
- Préparez le pneu et rassemblez-le.
- REMARQUE: Pour boucler les cravaisons de pneus et pour éviter la corrosion du pneu, obturez le pneu aussi lasséchement et la corrosion du pneu.

POUR ENLEVER LES ROUES (Voir la Fig. 39)

REVISION ET REGLAGES

Fig. 38



Installez la tonduseuse. (Voir «POUR INSTALLER LA TONDEUSE» dans la présente section du manuel.)

1. Installez une nouvelle courroie en partant de l'arbre du tracteur vers l'avant, sur la plaque de direction (H) et au-dessus de l'embarayage vers l'arrière de la poulie de embrayage (J).
2. Tirez la courroie vers l'arrière du tracteur et enroulez-la autour de l'embarayage électrique et de la poulie motrice (G).
3. Tirez la courroie vers l'arrière du tracteur de l'embrayage (F). Assurez-vous que la transmission est bien serrée sur la poulie d'entree (F). Assurez-vous que la transmission est bien serrée à l'intérieur du disjoncteur.
4. Installez la courroie sur la poulie de tension centrale (E).
5. Faites passer la courroie dans la poulie de tension fixe (C) et à la poulie d'entree (D).
6. Installez de nouveau la poulie anti rotation (B) à la droite du tracteur. Serrez fermement.
7. Branchez le nouveau câble de embrayage (A).
8. Assurez-vous que la courroie est bien serrée dans les guides et les dispositifs de retenue.

INSTALLATION DE LA COURROIE .

1. Retirez la tonduseuse (Voir «POUR ENLEVER LA TONDEUSE» dans la présente section du manuel).
2. Débranchez le faisceau de câbles de l'embarayage (A).
3. Retirez la bille anti rotation (B) à la droite du tracteur.
4. Retirez la courroie de la poulie de tension fixe (C) et la poulie d'embarayage (D).
5. Retirez la courroie de la poulie de tension centrale (E).
6. Tirez la courroie vers l'arrière de la poulie de transmission soit vers le haut et sur les lames de la transmission soit vers le bas et sur les lames du tracteur. Retirez soit déroulez la courroie de la poulie motrice vers le bas et autour de l'embarayage électrique (G).
7. Déroulez la courroie de la poulie motrice vers le bas et autour de l'embarayage électrique (F).
8. Faites glisser la courroie vers l'arrière du tracteur, à l'extrême de la plaque de direction (H) et retirez-la du tracteur.

RETRIEVEZ LA COURROIE .


1. Retirez la tonduseuse (Voir «POUR ENLEVER LA TONDEUSE» dans la présente section du manuel).
2. Actionnez le tracteur sur une surface de niveau. Actionnez le frein de stationnement. En cas de besoin, un autocollant servira de guide à l'installation de la courroie se trouve sur le dessous du repose-pied gauche.

POUR REMPLACER LA COURROIE D'ENTRAÎNEMENT (Voir la Fig. 38)

1. Stationnez le tracteur sur une surface de niveau en cliquant ou pavé, vous devrez faire arrêter les freins. Assurez-vous que la transmission le tracteur vers l'avant. Si les roues arrière sont dans la position de stationnement. Les roues arrière doivent être bloquées et dérapper lorsqu'une roue tourne.
2. Descendez la transmission en plaçant le pied à ce qu'il soit dans la position de stationnement. Tirez sur le contrôle de roue libre et placez-le dans la position «transmission désengagée» (transmission libre à la position «transmission désengagée»). Tirez sur le contrôle de roue libre et placez-le dans la position de stationnement.

POUR VÉRIFIER LES FREINS


Fig. 37



1. Stationnez le tracteur sur une surface de niveau en cliquant ou pavé, vous devrez faire arrêter les freins. Assurez-vous que la transmission est bien serrée dans les positions des poulies de la tonduseuse.
2. Soulvez le levier de levage à sa position la plus haute.
3. Installez la courroie sur la poulie de l'embarayage électrique (M).
4. Installez la courroie autour des poulies des mandrins (R) et autour des poulies des mandrins (V) tel que montré.
5. Retirez la courroie de la poulie de la transmission (V) et toutes les poulies de tension (M), les deux poulies des mandrins (R) et l'embarayage électrique doivent être accrochés à la surface des plateaux supérieurs.
6. Abaissez le levier le levage à sa position la plus basse.
7. Actionnez le tracteur sur une surface de niveau. Actionnez le frein de stationnement.
8. Stationnez le tracteur sur une surface de niveau. Actionnez le frein de stationnement.
9. RETIRER LA COURROIE D'ENTRAÎNEMENT DE LA TONDEUSE
10. RETIRER LA COURROIE D'ENTRAÎNEMENT DE LA TONDEUSE
11. LAME DE DETONDEUSE (Voir la Fig. 37)


REVISION ET REGLAGES

Fig. 34




- Maintenez l'écrou de réglage en place avec la clé de serre 1/2 po. (1/2 po.) inférieure à la pointe arrière.
- Vérifiez de nouveau les mesures, ajustez si nécessaire jusqu'à ce que la pointe avant de la lame est 3,1 to 12,7 mm (1/8 à 1/2 po.).
- REMARQUE: Chaque tour complet de l'écrou de réglage modifie la hauteur de la tonduse d'environ 3,1 mm (1/8 po.).

Fig. 36



- Si la pointe avant de la lame n'est pas de 3,1 to 12,7 mm (1/8 à 1/2 po.), plus basse que la pointe arrière, allez à "Avant du tracteur".
- A l'aide d'une clé ajustable ou de 1 1/16", dévissez l'écrou de serrage (A) pour dépasser l'écrou de réglage (B).
- A l'aide d'une clé ajustable ou de 3/4", faites tourner l'écrou de réglage de la bille avant de la tonduse (B) dans le sens horaire (↗) (deviseur) pour abaisser l'avant de la tonduse.
- REMARQUE: Chaque tour complet de l'écrou de réglage modifie la hauteur de la tonduse d'environ 4,7 mm (3/16 po.).

Fig. 35



- Soulvez la tonduse à sa position la plus haute.
- Placez un morceau quel que soit la distance (B) au sol à la pointe avant et la pointe arrière de la lame.
- Assurez-vous que la tonduse soit stable sur le niveau.

ATTENTION: Les lames sont tranchantes.
en enveloppant les lames d'un tissu épais.

- Pour obtenir de meilleurs résultats, les lames de la tonduse doivent être ajustées de sorte que la pointe avant est 3,1 to 12,7 mm (1/8 à 1/2 po.) inférieure à la pointe arrière lorsqu'elle est à sa position la plus élevée.
- IMPORTANT: La plateforme doit être au même niveau d'un côté que l'autre.
- Assurez-vous que vos pneus soient gonflés jusqu'à la pression en PSI indiquée sur eux-ci. Si les pneus sont trop ou pas assez gonflés, cela peut affecter l'apparence de votre pelouse et vous faire courir.

- Si un ajustement est nécessaire, voir la étape des instructions ci-dessous.
- D'un côté et de l'autre de la tonduse, placez la lame de coupe jusqu'à ce que les deux côtés soient égaux.
- Vérifiez de nouveau les mesures, ajustez si nécessaire jusqu'à ce que la tonduse soit visuel ci-dessus.
- Soulvez la tonduse à sa position la plus haute.

ATTENTION: Les lames sont tranchantes.
en enveloppant les lames d'un tissu épais.

- Assurez-vous que vos pneus sont adéquatement gonflés, puis stationnez le tracteur sur un terrain de niveau ou une entree de cour.
- Assurez-vous que vos pneus sont adéquatement gonflés, et en vérifiant tout autre élément en tondant à la même hauteur de coupe.
- Vérifiez l'ajustement en tondant à la même hauteur de coupe en vérifiant que les deux côtés soient satisfait du résultat.
- REMARQUE: Chaque tour complet de l'écrou de réglage modifie la hauteur de la tonduse d'environ 4,7 mm (3/16 po.).


AJUSTEMENT LATÉRAL DE PRÉCISION (Voir Fig. 34)

- Vérifiez l'ajustement en tondant à la même hauteur de coupe en vérifiant que les deux côtés soient satisfait du résultat.

ATTENTION: Les lames sont tranchantes.
en enveloppant les lames d'un tissu épais.

- Assurez-vous que vos pneus sont adéquatement gonflés, puis stationnez le tracteur sur un terrain de niveau ou une entree de cour.
- Assurez-vous que vos pneus sont adéquatement gonflés, et en vérifiant tout autre élément en tondant à la même hauteur de coupe.
- Vérifiez l'ajustement en tondant à la même hauteur de coupe en vérifiant que les deux côtés soient satisfait du résultat.
- REMARQUE: Chaque tour complet de l'écrou de réglage modifie la hauteur de la tonduse d'environ 4,7 mm (3/16 po.).

ATTENTION: Les lames sont tranchantes.
en enveloppant les lames d'un tissu épais.



- Assurez-vous que vos pneus sont adéquatement gonflés, puis stationnez le tracteur sur un terrain de niveau ou une entree de cour.
- Assurez-vous que vos pneus sont adéquatement gonflés, et en vérifiant tout autre élément en tondant à la même hauteur de coupe.
- Vérifiez l'ajustement en tondant à la même hauteur de coupe en vérifiant que les deux côtés soient satisfait du résultat.
- REMARQUE: Chaque tour complet de l'écrou de réglage modifie la hauteur de la tonduse d'environ 4,7 mm (3/16 po.).

AJUSTEMENT LATÉRAL VISUEL (Voir Fig. 33)


- Assurez-vous que vos pneus soient gonflés adéquatement.
- Si votre pelouse ne semble pas couper de façon uniforme, déterminez quel côté de la tonduse coupe plus bas.
- Assurez-vous que vos pneus soient gonflés adéquatement.
- Si vous avez une clé ajustable ou de 3/4", tournez l'écrou de réglage de la bille de levage (A) vers la gauche pour abaisser le côté gauche de la tonduse, ou vers la droite pour lever le côté gauche de la tonduse.
- Assurez-vous que vos pneus soient gonflés adéquatement.

REVISION ET RÉGLAGES

POUR AJUSTER LE NIVEAU LA TONDUEUSE

21


Fig. 32



- Si nécessaire, tél que monté dans la section Fonctionnement nécessaire, ajustez les roues de réglage avant d'utiliser la tondeuse.
- Soulvez le levier de levage à sa position la plus haute.


IMPORATN: Assurez-vous que la courroie est bien en place dans les sillons des poulies de la tondeuse.

Fig. 31




- Installez la courroie sur la poulie de moteur (M).

Fig. 30




- FIXEZ LA BIELLE AVANT (E) - Commençez à la gauche du tracteur. Insérez l'embout du support de la bieille (E) dans l'orifice avant du châssis de suspension avant du tracteur. Insérez l'autre embout de la bieille (E) dans l'orifice de la bieille dans l'avant de la tondeuse (H) et fixez fermement à l'aide d'une rondelle et d'un ressort-arrestoir (J).

Fig. 29



- ATTACHEZ LES BIELLES ARRIÈRES (C) - Soulvez le coin arrière de la tondeuse et positionnez la ramure du bras sur la tige (D) du support arrière de la tondeuse et fixez fermement à l'aide d'une rondelle et d'un ressort-arrestoir.


Fig. 28



- FIXEZ LES BRAS DE SUSPENSION LATÉRAUX DE LA TONDEUSE AU CHÂSSIS - Placez l'orifice du bras sur la tige (B) à l'arrière du châssis du tracteur et fixez solidement à l'aide d'une ressort-arrestoir.
- Répétez de l'autre côté du tracteur.

REVISION ET REGLAGES

Fig. 27



Glissez la tondueuse du dessous du tracteur.

ATTENTION : Après avoir démonté les mécanismes à ressort, tenez fermement le biellet, le levier d'accrochage possède un bras de tondueuse sous le tracteur.



Enlevez la bielette avant (E) de la tondueuse - retirez le ressort - arrêtez le roulement et la rondelle.

Abaissez la courroie de la poulie d'embarayage (M) et actionnez le frein de levage à sa position la plus basse.

Assurez-vous que le tracteur se trouve sur une surface de niveau et actionnez le frein de stationnement.

Placez l'embarayage d'accrochage à la position "DÉSENGAGÉ".

Tournez la clé de contact à la position d'arrêt (STOP) et enlevez-la.

Assurez-vous que les lames et toutes les pièces tournaires se soient arrêtées.

Débranchez le câble de bougie d'allumage.

Appuyez sur la pédale de frein et engagez le frein de stationnement.

Placez l'embarayage d'accrochage en position débrayée (DÉENGAGÉ).

Tournez la clé de contact à la position d'arrêt (STOP) et enlevez-la.



ATTENTION : Le levier possède un mécanisme à ressort. Tenez fermement le bras de tondueuse (A) pour éviter que le bras de suspension latéral ne glisse le long de la bielette de levage, abaissez-le lentement et enclenchez-le à sa position la plus basse.



REMARQUE : Assurez-vous que les bras de suspension latéraux de la tondueuse (A) pointent vers l'avant avant de glisser la tondueuse sous le tracteur.

INSTALLER LA TONDUEUSE (Voir Fig. 27)

Assurez-vous que le tracteur se trouve sur une surface de niveau et actionnez le frein de stationnement.

Placez l'embarayage d'accrochage à la position "DÉSENGAGÉ".

Assurez-vous que les lames et toutes les pièces tournaires se soient arrêtées.

Débranchez le câble de bougie d'allumage.

Appuyez sur la pédale de frein et engagez le frein de stationnement.


Placez l'embarayage d'accrochage en position débrayée (DÉENGAGÉ).

Tournez la clé de contact à la position d'arrêt (STOP) et enlevez-la.



ADVERTISSEMENT : POUR ÉVITER DES DOMMAGES SERIEUX, AVANT DE FAIRE TOUS LES RÉVISI-


REVISIÖN ET REGLAGES



1. Conduisez le tracteur vers la maison, le garage, les voitures en stationnement etc. Retirez la goupille du ramasse-herbe ou le couvre-palissis éventuellement fixés.
2. Assurez-vous le contrôle d'embrayage d'accèssoire à la position "DEBRArrYEE", serrez le frein de stationnement et coupez le moteur.
3. Triez sur la collerette de blocage de l'adaptateur de la base de lavage puis posez l'adaptateur sur le racCORD de lavage de coupe de la tondeuse. Relâchez la collerette de blocage de coupe de la tondeuse. Relâchez la collerette de plateau de plateau de coupe située à l'extrême gauche du plateau de plateau puis posez l'adaptateur sur la base de lavage de lavage qui fait partie du système de lavage du plateau de coupe.
4. Ouvrez le robinet d'eau.
5. Prenez place sur le siège du tracteur, relâchez le moteur et mettez le levier d'accélération en position rapide ("Fast").
6. Déplacez-vous le contrôle d'embrayage d'accèssoire à la position "DEBRArrYEE". Ne quittez pas le siège de l'opérateur pendant longtemps. Tenez les enfants une fois que la zone de travail est dégagée. Tenez les enfants éloignés de la zone de travail lorsqu'ils vous nettoient le plateau de coupe.
7. Déplacez-vous le contrôle d'embrayage d'accèssoire à la position "DEBRArrYEE". Mettez la clé de contact jusqu'à ce que le plateau soit nettoyé.
8. Assurez-vous que la commande d'accèssoire à la STOP pour couper le moteur. Fermez le robinet d'eau.
9. Conduisez le tracteur vers un endroit sec, de préférence dans une position "DEBRArrYEE". Arrêtez le moteur. Coupez l'eau.

IMPORtANT: Tirer le tuyau d'arrosage pour vous assurer que le racCORD de lavage est sécurisé.

Fig. 26




1. Conduisez le tracteur vers un endroit plat et dégagé de votre pelouse, suffisamment près pour atténir le robinet d'eau dessiné au tuyau d'arrosage de votre jardin.
2. Assurez-vous que la partie du système de lavage du plateau de coupe est utilisée après chaque usage.
3. Triez sur la collerette de blocage de l'adaptateur de la base de lavage puis posez l'adaptateur sur le racCORD de lavage de coupe de la tondeuse. Relâchez la collerette de plateau de plateau de coupe de la tondeuse. Relâchez la collerette de plateau de coupe située à l'extrême gauche du plateau de plateau de coupe.
4. Ouvrez le robinet d'eau.
5. Prenez place sur le siège du tracteur, relâchez le moteur et mettez le levier d'accélération en position rapide ("Fast").
6. Assurez-vous le contrôle d'embrayage d'accèssoire à la position "DEBRArrYEE", serrez le frein de stationnement et coupez le moteur.
7. Assurez-vous que la commande d'accèssoire à la STOP pour couper le moteur. Fermez le robinet d'eau.
8. Assurez-vous le contrôle d'embrayage d'accèssoire à la position "DEBRArrYEE". Mettez la clé de contact jusqu'à ce que le plateau soit nettoyé.
9. Conduisez le tracteur vers un endroit sec, de préférence dans une position "DEBRArrYEE". Arrêtez le moteur. Coupez l'eau.

COUPE (Voir La Fig. 26)

RACCORD DE LAVAGE DU PLATEAU DE

- Utilisez de l'air comprimé ou une souffleuse à feuilles pour refaire le moteur ou la transmission raccommoder la durée utile du tracteur.
- Utilisez de l'herbe, les feuilles et les débris sur le tracteur et la tondeuse.
- Protégez les surfaces peintes avec cire d'auto.
- Conservez la propreté de la finition et des roues en enlevant soigneusement l'essence, l'huile etc.
- Al'exception du racord de lavage (si équipé), nous conseillons de nettoyer le moteur un boyau d'arrosage ou un nettoyeur haute pression pour nettoyer le tracteur, à moins d'avoir recouvert le moteur et la transmission pour empêcher la penetration de l'eau. L'eau dans le moteur ou la transmission peut entraîner la corrosion et la rouille.
- Utilisez de l'herbe, les feuilles et les débris sur le tracteur et la tondeuse.

Fig. 25



ATTENTION : Évitez les points de pliage - mett et les pièces mobiles.

- Nettoyez le moteur, la batterie, le siège, et la finition, etc. de toutes les matières étrangères.
- Nettoyez tout le moteur sans solvant correct, assurez-vous que le moteur est propre sans solvant correct, assurez-vous que la température de l'air est correcte pour refroidissement.
- Les débris peuvent empêcher le mouvement de l'arbre de pédale de frein/d'embrayage, provoquant le glissement de la courroie avec perte de puissance. Voir Fig. 25.

NETTOYAGE

- Pour assurer le refroidissement correct, assurez-vous que toutes les autres surfaces de refroidissement sont propres en tout temps.
- Toutes les 100 heures d'utilisation (plus souvent dans des conditions possibles) éliminez le bâti de refroidissement et les autres défectuosités de refroidissement, nettoyez les ailettes de refroidissement et les surfaces d'air de refroidissement.
- REMARQUE : Si vous utilisez le moteur avec un tamis d'air pourra être endommagé à cause du surchauffage.
- Remplacez les bougies d'allumage au début de chaque saison de tonne ou après toutes les 100 heures d'utilisation selon que se présente en premier. Pour le type de bougie d'allumage est le régulateur de carburateur, assurez-vous à la section de "SPECIFICATIONS DU PRODUIT", de ce manuel.
- Inspectez le silencieux et le pare-étincelle (s'il y a lieu) et remplacez-les. Ils pourraient créer des risques d'incendie et/ou endommagement.

NETTOYER LES TAMIS D'AIR

ENTRETIEN

- **SILENCIEUX**
- **BOUGIE D'ALLUMAGE**
- **FILTRE D'ESSENCE INSTALLE EN LINÉE**
- **(Voir la Fig. 24)**




Fig. 24

- Assurez-vous qu'il n'y ait pas de fuites de la conduite d'essence.
- Posez le nouveau filtre dans la conduite d'essence avec la bride de serrage.
- Quand le moteur est froid, enlevez le filtre et bouchez les trouages de conduite d'essence.
- Si le filtre d'essence devrait être remplacé au moins chaude saison, laissez l'essence est bouché de obturateur. Posez le nouveau filtre dans la conduite d'essence avec la bride de serrage.
- Assurez-vous que la conduite d'essence renversee.
- Nettoyez immédiatement l'essence renversée.

FILTRE À AIR

REMARQUE: Si à lieu, enlever les dépôses du tableau de commande intérieur à l'aide des étapes décrites dans la section "Dépose du couvercle du tableau de commandes". Votre moteur ne fonctionne pas correctement avec un filtre à air sale. Nettoyez le filtre à air plus souvent si utilisé dans les endroits très poussiéreux ou sales. Voir le manuel du moteur.

- Après que l'huile se soit écoulée complièrement, serrez et verrouillez la souffrance de vidange en poussant vers l'intérieur ce que la cheville soit en position verrouillée comme montré.
- Retirez le tube de vidange et remettez le bouchon sur le racord inférieur de la soupape de vidange.
- Remplissez le moteur avec l'huile dans le tube de la jauge de remplissage d'huile. Versez lentement. Ne mettez pas trop. Voir la section de "SPECSIFICATIONS DU PRODUIT"
- Utilisez le calibre du bouchon de remplissage d'huile avec la jauge d'huile pour vérifier le niveau d'huile. Assurez-vous que la jauge est serrée à fond pour obtenir une indication correcte du niveau d'huile. Maintenez le niveau d'huile à la marque pleine (FULL) de la jauge d'huile. Serrez à fond le bouchon sur le tube quand vous avez fini.

Fig. 23






Fig. 21



ENTRETIEN

LUBRIFICATION MOTEUR



Utilisez seulement l'huile dégragante de qualité supérieure de la classification API SJ-SN. Choisissez le degré de viscosité SAE à des températures au-dessous de 0° F (-18° C). L'huile synthétique doit être utilisée lorsque le moteur fonctionne dans une station de température élevée ou dans une utilisation prévue.

***ATTENTION:** Les moteurs à refroidissement par air fonctionnent à une charge plus élevée que les moteurs d'automobile. L'usage des huiles multi-viscosité non-synthétiques (PW-30, 10W-30, etc.) à consommation d'huile plus élevée que la normale. Veiller à utiliser des huiles multi-viscosité lubrifiantes (PW-30, 10W-30, etc.) à température ambiante au-dessus de 40° F (4° C). Restera en une huile multi-viscosité lubrifiantes (PW-30, 10W-30, etc.) à température ambiante d'huile plus élevée que la normale. Utiliser est utilisée.

ATTENTION: Lorsque SAE 30, si utiliser à des températures au-dessous de 40° F (4° C), entraînera un démarrage difficile et des dommages éventuels à l'alésage du moteur causés par une lubrification insuffisante.

Changer l'huile toutes les 50 heures d'utilisation ou au moins une fois par an si le tracteur est utilisé moins de 50 heures par an.

Vérifiez le niveau d'huile et ajoutez de l'huile si nécessaire. Serrez le bouchon de remplissage d'huile avec la jauge d'huile chaque fois que vous vérifiez le niveau d'huile.

Le moteur et toutes les huit (8) heures d'utilisation. Démarrer le moteur et attendre que le moteur se refroidisse complètement avant de démonter le carter-moteur.

PRÉCAUTION: Retirez avec soin le couvercle du tableau de commande inférieur en portant attention à ne pas briser les pattes inférieures.

- Soulvez le capot.
 - Retirez l'attache du couvercle du tableau de commande

- Assurez-vous que le tracteur soit stationné sur un terrain plat.
- L'huile se vidangea plus librement quand elle est chaude.
- Recueillez l'huile dans un récipient approprié.

Determinez la gamme de températures prévue avant le changement d'huile. Toute l'huile doit avoir la classification API SJ-SN.

Assurez-vous que le tracteur soit stationné sur un terrain plat.

L'huile se vidangea plus librement quand elle est chaude.

Recueillez l'huile dans un récipient approprié.

DÉPOSE DU COUVERCLE DU TABLEAU DE COMMANDE INFERIEUR

(Voir la Fig. 21 - 23)


POUR CHANGER L'HUILE DE MOTEUR

Les parcs sont utilisés moins de 50 heures par an. Vérifiez le niveau d'huile du carter-moteur avant de démarrer le moteur et toutes les huit (8) heures d'utilisation. Serrez le bouchon de remplissage d'huile avec la jauge d'huile chaque fois que vous verrez le niveau d'huile.

ILSAC G-F-2. L'huile synthétique de classe II est recommandée pour les moteurs à essence et à compression. Les moteurs à essence doivent être équipés d'un filtre à huile de 50 microns. Les moteurs à compression doivent être équipés d'un filtre à huile de 50 microns. L'huile synthétique de classe II est recommandée pour les moteurs à essence et à compression. Les moteurs à essence doivent être équipés d'un filtre à huile de 50 microns. Les moteurs à compression doivent être équipés d'un filtre à huile de 50 microns.


**** ATTENTION:** Lorsque SAE 30, si utiliser à des températures au-dessous de 40° F (4° C), entraînera un démarrage difficile et des dommages éventuels à l'alésage du moteur causés par une lubrification insuffisante.

Fig. 17




- REMARQUE:** La lame est maintenue en place par des aimants pour prévenir tout dégagement intempestif.
- Ouvrir la plaque supérieure et déposer la lame. (Voir Fig. 17.)

Fig. 16



- Faites glisser le loquet à butée métallique d'osciller librement dans la zone définie par les entretiennes (Voir Fig. 16).
- Faites glisser le pivot et dégagé le pivot pour permettre le loquet à butée métallique d'osciller librement dans la zone définie par les entretiennes (Voir Fig. 16).

Fig. 15



- Comprimez les languettes pour ouvrir le capuchon. Enlevez en soulevant le capuchon pour dégager de la charnière et mettez-le de côté. (Voir Fig. 15.)

DEPOSE DE LA LAME

- Relevez la tondueuse le plus haut possible pour avoir aux vos mains avec des gants et/ou enveloppez la lame, protégez chiffon épais.
- ATTENTION: Lorsque vous manipulez la lame, protégez vos mains avec des gants et/ou enveloppez la lame, protégez chiffon épais.

ENLEVER LA LAME (Voir les figs. 15 - 20)

DANGER: N'utilisez que les lames de rechange autorisées par le fabricant de votre tondueuse. L'usage d'une lame n'ayant pas été autorisée par le fabricant de votre tondueuse est dangereux et risque d'endommager votre garantie.




Pour obtenir les meilleurs résultats, les lames de tondueuse doivent toujours être tranchantes. Remplacez les lames courbées ou endommagées.

ENTRETIEN DES LAMES


ENTRETIEN

Fig. 20




- REMARQUE:** Remplacer le couvercle si il est usé ou fissuré.
- Placez le capuchon, en vous assurant que les deux languettes étaillées basculent sur les languettes. Poussez fermement en place le capuchon à la charnière.

Fig. 19




- Refermer la plaque supérieure sur la lame et attacher le fil sur le dispositif annulaire.
- Refermer la plaque supérieure sur la lame et attacher le fil à la mollette de verrouillage. (Voir Fig. 19.)
- Fermer le pivot jusqu'à ce qu'il soit bien verrouillé à l'aide de la mollette de verrouillage.

Fig. 18



- REMARQUE:** Les aimants doivent maintenir la lame en place.
- Alligner les cannelures et insérer la lame. (Voir Fig. 18.)
- Bossege pour enlever tout débris ou saleté.
- Nettoyez soigneusement la zone située sous la plaque supérieure, le bas de l'ensemble du mandrin et autour du bossege pour enlever tout débris ou saleté.

POSÉ DE LA LAME



- REMARQUE:** Remplacer le couvercle si il est usé ou fissuré.
- Placez le capuchon, en vous assurant que les deux languettes étaillées basculent sur les languettes. Poussez fermement en place le capuchon à la charnière.

Fig. 20

ENTRETIEN

TRACTEUR

Le tracteur.

Observez toujours les règles de sécurité quand vous faites

FONCTIONNEMENT DU FREIN

Si le tracteur demande une distance d'arrêt de plus de cinq (5) pieds (1,5 m) pour s'arrêter à grande vitesse, sur une surface horizontale en béton sec ou pavé, vous devrez contrôler et régler les freins. (Voir la section "POUR RÉGLER LE FREIN" dans la section Révision et réglage fonctionnement correcte dans tous les pneus.)

Maintenez la pression correcte dans tous les pneus. (Voir la valise en PSI indiquée sur ce手册.)

Assurez-vous que vos pneus ne soient pas en contact avec des objets tranchants et/ou autres dangers qui pourraient causer des dégâts aux pneus.

Évitez les souches, de l'huile ou des produits chimiques insecticides qui pourraient endommager le caoutchouc.

Assurez-vous que vos pneus ne soient pas en contact avec des résidus de peinture ou d'autres substances chimiques qui peuvent étailler la peinture de la roue ou du pneu.

Pour éviter les crevasses de pneus et pour prévenir les dégâts aux pneus.

REMARQUE: Pour éviter les crevasses de pneus et pour prévenir les dégâts aux pneus.

ARRIÈRE (ROS) (Voir la Fig. 14)

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement. Si votre tracteur ne fonctionne pas de façon décrite, préparez-le immédiatement. En marche, sans tirer le frein de parking, le moteur s'arrête. Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

VERIFIÉZ PRÉSENCE DE L'OPÉRATEUR

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement. Si votre tracteur ne fonctionne pas de façon décrite, préparez-le immédiatement.

SYSTÈME DE PRÉSENCE DE L'OPÉRATEUR ET ARRIÈRE (ROS)

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement. Si votre tracteur ne fonctionne pas de façon décrite, préparez-le immédiatement. En marche, sans tirer le frein de parking, le moteur s'arrête. Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

VERIFIÉZ SYSTÈME DE FONCTIONNEMENT EN MARCHE ARRIÈRE (ROS)

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement. Si votre tracteur ne fonctionne pas de façon décrite, préparez-le immédiatement. En marche, sans tirer le frein de parking, le moteur s'arrête. Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

SI L'OPÉRATEUR TENNE LA POSITION NORMALE

Le système de fonctionnement en marche arrière (ROS) est du système de commutateur d'allumage sur la position ON du marche avec le commutateur d'allumage sur ON est l'embrayage avec le commutateur d'allumage sur ON est l'embrayage avec l'embrayage engagé, le moteur ne s'arrête PAS.




Fig. 14

BATTERIE

Le tracteur.

Observez toujours les règles de sécurité quand vous faites

l'entretien.

Si le tracteur demande une distance d'arrêt de plus de cinq (5) pieds (1,5 m) pour s'arrêter à grande vitesse, sur une surface horizontale en béton sec ou pavé, vous devrez contrôler et régler les freins. (Voir la section "POUR RÉGLER LE FREIN" dans la section Révision et réglage fonctionnement correcte dans tous les pneus.)

Maintenez la pression correcte dans tous les pneus. (Voir la valise en PSI indiquée sur ce手册.)

Assurez-vous que vos pneus ne soient pas en contact avec des objets tranchants et/ou autres dangers qui pourraient causer des dégâts aux pneus.

Évitez les souches, de l'huile ou des produits chimiques insecticides qui pourraient endommager le caoutchouc.

Assurez-vous que vos pneus ne soient pas en contact avec des résidus de peinture ou d'autres substances chimiques qui peuvent étailler la peinture de la roue ou du pneu.

Pour éviter les crevasses de pneus et pour prévenir les dégâts aux pneus.

POUR NETTOYER LA BATTERIE ET LES BORNES:

Le câble de batterie ROUGE être enlevé la batterie du tracteur.

le câble de batterie NOIR est ensuite

Prémierrement débranché le câble de batterie NOIR et ensuite

le câble de batterie ROUGE être enlevé la batterie du tracteur.

Rincer la batterie avec l'eau fraîche, et séchez-la.

Nettoyez les bornes et les boutons des câbles de batterie avec une brosse métallique jusqu'à ce qu'ils brillent.

Enduissez les bornes avec la graisse ou le graisseuse.

Enduissez les bornes avec la graisse ou le graisseuse.

Le tracteur.

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement.

En marche, sans tirer le frein de parking, le moteur s'arrête.

Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

VERIFIÉZ PRÉSENCE DE L'OPÉRATEUR

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement.

En marche, sans tirer le frein de parking, le moteur s'arrête.

Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

VERIFIÉZ SYSTÈME DE FONCTIONNEMENT EN MARCHE ARRRIÈRE (ROS)

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement.

En marche, sans tirer le frein de parking, le moteur s'arrête.

Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

INSPÉCIEZ LE VENTILATEUR DE LA TRANSMISSION

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement.

En marche, sans tirer le frein de parking, le moteur s'arrête.

Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

INSPÉCIEZ LE VENTILATEUR DE LA TRANSMISSION

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement.

En marche, sans tirer le frein de parking, le moteur s'arrête.

Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

INSPÉCIEZ LE VENTILATEUR DE LA TRANSMISSION

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement.

En marche, sans tirer le frein de parking, le moteur s'arrête.

Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

INSPÉCIEZ LE VENTILATEUR DE LA TRANSMISSION

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement.

En marche, sans tirer le frein de parking, le moteur s'arrête.

Si l'opérateur quitte le poste de conduite, lorsqu'il embrayage est engagé, le moteur s'arrête.

INSPÉCIEZ LE VENTILATEUR DE LA TRANSMISSION

Vérifiez si les systèmes de présence de l'opérateur, de marche arrière et de verrouillage fonctionnement correctement.

En marche, sans tirer le frein de parking, le moteur s'arrête.

IMPORtant: NE METTEZ NI HUILE NI GRAISSE SUR LES POINTS D'ARRET DE LA CHAINE. UTILISEZ SEULEMENT DES POINTS D'ARRET POUR LUBRIFICATION.

- ② Préférez-vous le "Moteur" à la section Entrée.
- ① Lubrifiant tout usage




TABLEAU DE LUBRIFICATION

1-Changer les plus souvent le tracteur lorsque vous avez un changement. 2-Remplacez plus souvent si les conditions sont possibles ou de vente. 3-Remplacez plus souvent les lames en cas d'utilisation sur un terrain sablonneux. 4-Pas exigé si équipé avec une batterie sans entretien. 5-Voyez "Nettoyage" dans la section ENTRETIEN de ce manuel.

GUIDE D'ENTRETIEN	AVANT CHAQUE CHAQUE CHAQUE CHAQUE AVANT-ENTRE-	USAGE HEURES HEURES HEURES POSAGE	TOUTES LES 8 HEURES LES 25 HEURES LES 50 HEURES TOUTES	AVANT CHAQUE CHAQUE CHAQUE CHAQUE AVANT-ENTRE-	
				CHARGE	CHARGE
Vérifiez le système de frein					
Vérifiez la pression des pneus					
Vérifiez le système de présentation et le système de ROS					
Tableau de lubrification					
Vérifiez le niveau de batterie					
Nettoyez la batterie et les bornes					
Vérifiez le rendissage de transmission					
Nettoyez la transmission de friction					
Vérifiez les courroies trapézoïdale					
Nettoyez l'unisson de friction					
Vérifiez le niveau d'huile du moteur					
Remplacez l'huile du moteur (pour modèles avec filtre à huile)					
Nettoyez le filtre à air					
Nettoyez le silencieux/pare-étincelles					
Nettoyez les ailettes de refroidissement					
Remplacez la bougie d'allumage					
Remplacez la cartouche en papier du filtre à air					
Quelques ajustements sont nécessaires périodiquement pour maintenir correctement votre tracteur.					
Tous les réglages dans la section Révision et Réglages de ce manuel devraient être vérifiés au moins une fois par saison.					
Une fois par an, remplacez la bougie d'allumage, nettoyez ou remplacez le filtre à air, et vérifiez la lame et les courroies pour les signes d'usure. Une nouvelle bougie d'allumage et un nouveau filtre à air peuvent aider à prolonger la durée de service d'un moteur.					
Une fois par an, vérifiez la section Révision et Réglages de ce manuel pour couvrir les éléments qui ont été oubliés.					
La garantie pour ce tracteur ne couvre pas les éléments qui ont été oubliés.					
LES RECOMMANDATIONS GÉNÉRALES					
1-Changer les plus souvent quand le tracteur fonctionne avec un chargement. 2-Remplacez plus souvent si les conditions sont possibles ou de vente.					
3-Remplacez plus souvent les lames en cas d'utilisation sur un terrain sablonneux.					
4-Pas exigé si équipé avec une batterie sans entretien.					
5-Voyez "Nettoyage" dans la section ENTRETIEN de ce manuel.					

AVANT CHAQUE UTILISATION

- Vérifiez la pression des pneus.
- Vérifiez le niveau d'huile de moteur.
- Vérifiez le fonctionnement du système de frein.
- Vérifiez la pression des pneus.
- Vérifiez que le système de présence d'opérateur et ROS fonctionnent bien.
- Vérifiez l'intégrité des systèmes de fixation.

CONSEILS DE TONTE

UTILISATION

PURGER LA TRANSMISSION

**ATTENTION : N'engagez jamais ou ne dégag-
gez jamais le levier de la route libre pendant
que le moteur fonctionne.**

ATTENTION: A tout moment, au cours de l'étape 4, il peut y avoir du mouvement des routes d'entraînement.

- The diagram illustrates the logic of traction control for a rear-wheel drive vehicle. It shows a rear-wheel drive car with arrows indicating the direction of power delivery from the engine through the transmission and differentials to the rear wheels. The logic flow starts with the detection of wheel slip, which triggers a feedback loop. This loop involves comparing the measured wheel speed with a reference speed. If a wheel is slipping (measured speed is higher than reference), the system reduces torque to that wheel. The reduced torque is then compared with a minimum torque limit. If the reduced torque is below this limit, the system applies a lock-up clutch to prevent wheel spin. The process then loops back to the initial wheel speed measurement.

Le complément horaire indique le nombre total d'heures de fonctions d'information du moteur. Pour l'entretien courant du moteur et de la tondeuse, préférez-vous à la section Entretien de ce manuel.

POUR REMORQUER DES CHARRETTES ET AUTRES ACCESSOIRES

Remorquage seulement les accessoires recommandés, dans les spécifications du fabricant de votre tracteur. Faites preuve de prudence lorsque vous remorquez un accessoire. Il est dangereux d'ajouter des charges trop lourdes dans une pente. Les engins peuvent perdre de l'adhérence avec le terrain et vous faire perdre la maîtrise de votre tracteur.

COMPTEUR HORAIRES

Le compteur horaires mesure le temps que vous passez à faire fonctionner votre tracteur. Il est utile pour déterminer quand il faut faire faire une révision ou remplir les huiles et lubrifiants.

Fig. 12



le transport de votre tracteur sur un chemin ou une remorque, assurez-vous que le capot soit fermé et fixé au tracteur. Utilisez les moyens appropriés (corde, gabarre, etc.).

BEMARQUE: Pour protéger le capot des dommages pendant dessus.

(Voir la Fig. 3 et 12)

POLIB TRANSPORTER1 E TBC1TELLB


UTILISATION

- Choisissez la vitesse la plus lente avant de commencer à monter ou descendre une côte.
 - Évitez de changer la vitesse ou d'arrêter dans une côte.
 - Si l'estabilissement nécessaire d'arrêter, enoncez rapidement la pédale de frein jusqu'à sa position de freinage. Engagez le frein de stationnement.
 - Pour redémarrer, déengagez lentement le frein de stationnement et la pédale de frein.
 - Pour redémarrer, déengagez lentement le frein de stationnement sur la pédale de marche avant jusqu'à ce que le véhicule commence à rouler.
 - Appuyez lentement sur la pédale de marche avant jusqu'à ce que le véhicule commence à rouler.
 - Virez toujours très progressivement.



POUR UTILISER DANS LES PENTES

Fig. 11



- Utilisez que si vous êtes certifiés qu'aucun enfant ou tiers n'est présent sur la surface à tondre.
 - Enfournez complètement la pédale de frein sans la lâcher.
 - Avec le moteur en marche, introduisez la clé dans les commutateurs ROIS et faites-la tourner en sens anti-horaire sur ON.
 - Regardez vers le bas et vers l'arrière avant de reculer.
 - Enfournez lentement la pédale renversée d'entraînement pour commencer le mouvement.
 - Lorsque l'utilisation du ROIS n'est plus nécessaire, faites tourner la clé de contact en sens horaire sur ON.

CHIÉGATION DE SÉRIE DE QUINQUENNEMENT

AVERTISSEMENT: Il est fortement déconseillé de faire reculer avec l'embryagage de l'accèssoire de tonne engagé. L'opérateur ne doit mettre le ROS sur ON, pour pouvoir reculer avec l'embryagage de l'accèssoire de la machine. Ne pourrez pas en marche arrêter à moins qu'il accèsse soie engagé. Ne trouvez pas en marche arrêter à moins qu'il accèsse soie nécessaire.

SYSTÈME DE FONCTIONNEMENT EN MARCHE ARRIÈRE (ROS)

- UTILISATION**
- COMMENT UTILISER LE RÉGULATEUR DE VITESSE (J) (Voir la Fig. 7)**
- Le régulateur de vitesse n'est utilisable qu'en marche avant.
- VITESSE**
- Fig. 7**
-
- REMARQUE: Réglez les roues avant et arrière sur un plateau plat.
 - Réglez la tonduse à la hauteur de coupe désirée (Voyez la section de "POUR UTILISER LA TONDEUSE").
 - Quand la tonduse est à la hauteur désirée hauteur de coupe désirée, placez pour prévenir le dégagement de la plupart des tressins. Les roues arrière dépassent de la bordure de la tonduse et trouvent le degré de serrage désiré. Dans ce cas, les roues gardent le centre en coupe désirée.
 - TONDEUSE": dans la section fonctionnement de ce manuel).
 - Réglez la tonduse à la hauteur de coupe désirée (Voyez la section de "POUR REGLER LA HAUTEUR DE COUPE DE LA TONDEUSE").
 - Quand la tonduse est à la hauteur désirée hauteur de coupe désirée, placez dessus de la tôle. Installez la roue dans le même trou comme indiqué et serrez à fond.
 - Répétez de l'autre côté. Installez la roue dans le même trou comme indiqué et serrez à fond.
 - Le réglage de vitesse nécessite que lors du roulage sur un transporteur, le régulateur sur des surfaces qui sont relativement ou très rugueuses. D'autres conditions telles que le décolpage de tressins à vitesses élevées peuvent faire désexcécher le régulateur. Pour désexcécher le régulateur, tirez le levier vers l'arrière sur "SET", et maintenez-le tout en soulevant votre pied de la pédale, puis lâchez le régulateur.
 - Appuyez sur la pédale de marche avant jusqu'à ce que la position à vitesse normale soit atteinte, possessez le régulateur sur (J) "SET", et maintenez-le tout en soulevant votre pied de la pédale, puis lâchez le régulateur.
 - Pour désexcécher le régulateur, appuyez à fond sur la pédale de frein. La position du levier d'accrochage (A) détermine la hauteur de tonte.
 - Placez le levier d'accrochage dans la rainure correspondant à la hauteur désirée.
- POUR RÉGLER LA HAUTEUR DE COUPE DE LA TONDEUSE (Voir la Fig. 8)**
- Fig. 8**
-
- Poussez le bouton (A) vers l'avant pour augmenter la hauteur de coupe.
 - Poussez le bouton (A) vers l'arrière pour diminuer la hauteur de coupe.
- POUR ARRETER LES LAMES DE TONDEUSE**
- ATTENTION: N'utilisez pas la tonduse sans le déflecteur ou sans le ramasse-herbé si la lame (Voir la Fig. 10).**
- Fig. 10**
-
- Engagez les lames de tonduse en déplaçant la lame de la position "DEBRAVÉE".
 - Déplacez la lame de tonduse d'accèssoire à la position "EMBRAYAGE".
 - Sélectionnez la hauteur de coupe de la tonduse (Voir "POUR RÉGLER LA HAUTEUR DE COUPE DE LA TONDEUSE").
 - Votre tracteur est muni d'un interrupteur de détection de présence d'un opérateur. Le moteur s'arrête si l'opérateur essaie de quitter le siège pendant que le moteur fonctionne et que l'embarayage est engagé. Vous devrez rester bien assis au milieu d'accèssoire est utilisé. Vous devrez également essayer de déclencher l'interrupteur de détection de présence lorsque vous déclenchez l'interrupteur de détection de présence.
 - Engagez les lames de tonduse en déplaçant la lame de la position "DEBRAVÉE".
 - Sélectionnez la hauteur de coupe de la tonduse (Voir "POUR RÉGLER LA HAUTEUR DE COUPE DE LA TONDEUSE").
 - Engagez les lames de tonduse en déplaçant la lame de la position "EMBRAYAGE".
 - La tonduse doit être tondue à 63,5 mm (2-1/2 po), pendant la saison fraîche et à plus de 76,2 mm (3 po), pendant la saison chaude. Tondez souvent pour les meilleurs résultats.
 - La pelouse doit être tondue à 25,4 mm (1 po) pour les meilleures conditions du terrain, de la hauteur de l'herbe et des types de sols tondus.
 - La hauteur de coupe de la lame quand le moteur ne marche pas. Ces hauteurs sont approximatives et elles pourraient changer à cause d'une partie de la lame qui a été mesurée du terrain à 101,6 mm (1 a 4 po). Les hauteurs sont mesurées du terrain à la hauteur de coupe est environ de 25,4 à 101,6 mm (1 a 4 po).
 - Placez le levier d'accrochage dans la rainure correspondant à la hauteur désirée.

UTILISATION

POUR AVANCER ET POUR REGULER





Fig. 7

- Utilisez toujours le moteur à pleine vitesse (rapide).
- Faire fonctionner le moteur à une vitesse inférieure à sa vitesse maximale (rapide) réduit l'efficacité du moteur (D).
- Une pleine vitesse (rapide) permet une meilleure performance de la tondeuse.

POUR UTILISER LA COMMANDE DES GAZ (D)

POUR UTILISER LA COMMANDE DES GAZ (D)



REMARQUE: Quand le tracteur marche au ralenti, les gaz d'échappement d'un moteur chaud peuvent causer des dommages au gazon. Pour éviter les dommages, coupez toujours le moteur quand vous arrêtez le tracteur sur le gazon.

IMPORTEANT: SI LE CONTACT D'ALUMAGE EST LASISSE
DECHARGERA ET SERA ALLE A PLAT.
UNE AUTRE POSITION QUE OFF, LA BATTERIE SE
DÉCHARGE RAPIDEMENT POUR CHARGER LA
BATTERIE.


ralenti avant de couper les gaz peut entraîner un retour de flamme. Tournez la clé de contact à la position coupée (F) STOP et enlevez la clé de contact pour empêcher d'empêcher que l'autre ne démarre.

- MOTEUR - Placer la commande des gaz en position (D) « SLOW » (en). REMARQUE : Le fait de ne pas déplacer la commande des gaz en position « SLOW » (en) et de laisser le moteur tourner au ralenti peut entraîner un surchauffe du moteur.

MARCHE ARRIERE REVIENT AU POINT MORT SI VOUS
N'APPUYEZ PAS DESSUS.

- Pour arrêter l'entraînement, abaisser complètement, la pédale en trainement. frein à la position "Frein".


Fig. 5



- LAMES DE TONDEUSE - Pour arrêter les lames de tondeuse, bougez le, contrôle embrayage d'accessoire à la position "DEBRAYE" (*).

POUR ARRETER (Voir la Fig. 5)


-19- 4



frein (BRAKE). Maintenez le pied sur la pédale. Tirez sur levier du frein de stationnement (C) et tenez-le, relâchez la pression sur la pédale de frein/d'embryagé (B), puis relâchez le levier du frein de stationnement. La pédale (B) devrait rester à la position de frein (BRAKE). Assurez-vous que le frein de stationnement retienne le tracteur sans risque.

• Votre tracteur est munie d'un interrupteur de détection de présence qui s'active lorsque le siège d'opérateur est occupé. Le moteur s'arrête, si l'opérateur quitte le siège sans engager le frein de stationnement lorsqu'il marche.


FIGURE 1. Voir la Fig. 4.)



UTILISATION

- Nos tracteurs sont conformes aux normes de sécurité de l'American National Standards Institute.
-
- CONNAISSEZ VOTRE TRACTEUR, LISEZ CE MANUEL ET LES RÈGLES DE SÉCURITÉ**
- Comparez les illustrations ci-dessous à celles de votre tracteur afin de vous familiariser avec l'emplacement des différentes commandes avec les réglages. Gardez ce manuel pour référence.
- (A) LEVIER DE FREIN D'ACCESOIRE - permet de soulever et de baisser le carter de transmission pour débrayer la transmission.
- (B) PEDALE DE FREIN - permet de débrayer la transmission, d'arrêter le tracteur et de débrayer les accessoires montés au tracteur.
- (C) LEVIER DU FREIN DE STATIONNEMENT - bloque la pédale de frein/embrayage en position de frein.
- (D) COMMANDE DES GAZ/ETRANGLEUR - permet de démarrer le moteur et de commander la vitesse de moteur.
- (E) INTERRUPTEUR D'EMBRAYAGE D'ACCESOIRE - est utilisé pour débrayer les lames de tondeuse ou les autres accessoires montés sur le tracteur.
- (F) CONTACTEUR D'ALLUMAGE - permet de démarrer et de couper le moteur.
- (G) COMMUTATEUR DU SYSTÈME DE PRÉSENCE DE L'OPÉRATEUR (ROS) POSITION "ON" - permet de fonctionnement de la plate-forme de fauteuil roulant dans tous les sens.
- (H) L'INTERUPTEUR DES LUMIÈRES - permet d'allumer/éteindre les phares du tracteur.
- (J) LEVIER DE COMMANDE DE VITESSE - permet de faire avancer le tracteur à la vitesse voulue sans appuyer sur la pédale de marche avant.
- (K) PEDALE DE MARCHE AVANT - permet de faire avancer le tracteur.
- (L) PEDALE DE MARCHE ARRIÈRE - permet de reculer le tracteur.
- (M) COMMANDE DE LA ROUTE LIBRE - débraye la transmission pour le transport de la charge.
- (P) INDICATEUR D'ENTRETIEN/HORMOMETRE - indique le niveau d'huile moteur et de la tension de la batterie.
- (Z) AMPÈREMÈTRE - indique le chargement (+) ou le déchargement (-) de la batterie.

Fig. 3



Autre attachement actionné tandis qu'à l'envers.

UTILISATION


- DANGER indique un risque qui, s'il n'est pas évité, aura comme conséquence la mort ou des blessures sérieuses.
- AVERTISSEMENT indique un risque qui, s'il n'est pas évité, pas évité, pourraient avoir comme conséquence la mort ou des blessures sérieuses.
- ATTENTION lorsqu'il est utilisé sans le symbole d'alerte, indique une situation qui pourraient résulter en un endommagement du tracteur et/ou du moteur.
- SURFACES CHAUDES indique un risque qui, s'il n'est pas évité, pourraient avoir comme conséquence la mort, des blessures sérieuses et/ou
- L'endommagement de la propriété.
- FEU indique un risque qui, s'il n'est pas évité, pourraient avoir comme conséquence la mort, des blessures sérieuses et/ou l'endommagement de la propriété.



Le mandatement a suivre les instructions de sécurité pourra être résulté en de sérieuses blessures ou même la mort. Le symbole d'alerte à la sécurité est utilisé pour identifier les informations de sécurité pour identifier les risques, qui peuvent avoir pour résultats la mort, de sérieuses blessures et/ou endommager votre propriété.



(Seullement pour les modèles)




GARDER L'AIR LIBRE RISQUE PENITE VOYEZ SECURITE REGLES PARTIE



Ces symboles peuvent se montrer sur votre tracteur ou dans les publications touristiques avec le produit. Apprenez et comprenez la signification des symboles.

UTILISATION


Fig. 2



- Relâchez du levier pour assurer le siège en position.
- Soulvez le levier de réglage (a) et glissez le siège jusqu'à ce que vous soyez dans une position confortable qui vous permet d'appuyer complètement sur la pédale d'embrayage/ frein.
- Assoyez-vous sur le siège.

AJUSTEZ LE SIEGE (Voir la Fig. 2)

Fig. 1



- Fermez le siège ou le capot.
- Connectez le câble de terre NOIR (-) avec le boulon et l'écroû restant. Bien serrer.
- Connectez le câble de terre à la couverture de la batterie ROUGE à la section "REPLACEZ LA BATTERIE" dans la section Révision et section "REPLACEMENT DE LA BATTERIE" dans la section Révision.

- Fermez le siège ou le capot.
- Retirer deux caps de protection des bornes et les jeter.
- Retirer deux caps de protection des bornes et les jeter.
- Localiser la batterie. Elle doit se trouver sous le siège ou le capot.
- Soullever le siège ou le capot.
- Soullever le siège ou le capot.
- Fermer le siège ou le capot.
- Connectez le câble de terre NOIR (-) avec le boulon et l'écroû restant. Bien serrer.
- Connectez le câble de terre à la couverture de la batterie ROUGE à la section "REPLACEZ LA BATTERIE" dans la section Révision et section "REPLACEMENT DE LA BATTERIE" dans la section Révision.

REMARQUE: Si cette batterie est mise en service après le mois à 6-10 ampères. (Voir « BATTERIE » dans la section Entretien de ce manuel.)

AVERTISSEMENT: Évitez tout autre objet provoquant une prise de terre accidentelle. Pour prévenir les électricités qui peuvent être causées par une prise de terre accidentelle, la borne positive doit être connectée en premier en même temps. Avant de brancher la batterie, enlevez tout bijou, bracelet, montre, bague etc. Vous assurant qu'un outil ou que d'autres objets ne sont pas en contact avec deux bornes en même temps.



CONNEXION LA BATTERIE (Voir la Fig. 1)

AVANT RETIRER LE TRACTEUR DE PALTE

- Vérifiez si il y a des pièces détachées et conservées.
- Étendre à plat les panneaux situés à chaque bout et de carton. Enlever les panneaux situés sur les autres surfaces de long des lignes pointillées et les petites boîtes contenants toutes les pièces du carton.
- Couper le long des lignes pointillées et les petites boîtes contenants toutes les pièces du carton.

DEBALLER LE CARTON



POUR SORTIR LE TRACTEUR DU CARTON

Quand on utilise l'expression "DROITE" ou "GAUCHE", elle signifie la droite ou la gauche à partir de la position derrière le volant de direction.

- Utilisez la clé de 1/2" pour installer la batterie à la position derrière le volant de direction.
- Utilisez la clé de 7/16" pour installer le manomètre à pneu.
- Utilisez la clé de 1/2" pour installer le tube de vidange.
- Utilisez la clé de 1/2" pour installer le connecteur rapide.
- Utilisez la clé de 1/2" pour installer le connecteur d'accouplement.
- Utilisez la clé de 1/2" pour installer le tube de vidange.
- Utilisez la clé de 1/2" pour installer le connecteur rapide.

Votre nouveau tracteur a été monté à l'aide sauf les pièces qui ne sont pas montées pour l'expédition.

MONTAGE



PIÈCES PAS ASSÉMBLÉ

REGLES DE SECURITE	4
SPECIFICATIONS DE PRODUIT	4
RESPONSABILITES DU CLIENT	4
ENTRETIEN	2-3
REVISION ET REGLAGES	14-18
ENTRETIEN	26
ENTREPOSAGE	27-28
GUIDE DE DÉPANNAGE	5-6
UTILISATION	7-13
MONTAGE	14

SOMMAIRE

d'entretien autorisé le plus proche.
Un pare-échappement pour le silencieux est disponible au centre par l'opérateur.

est utilisé, il doit être maintenu en bon état de fonctionnement et possède des lois locales applicables. Quant à un pare-échappement n'est pas aussi durable que le système d'échappement couvert d'arbres, d'arbres, ou d'herbe sur un terrain bâti, il ne doit pas être utilisé sur un pré ou un terrain avec une autre personne lorsque vous êtes à proximité d'un autre.

AERTISSSEMENT: Ce tracteur est équipé d'un moteur à com-

- Toujours aviser une autre personne lorsque vous êtes à proximité d'un autre.
- Porter de l'équipement de protection individuelle lors de l'utilisation de cette machine, y compris (à tout le moins) des gants résistants, des lunettes de sécurité et un protège-oreilles antibruit. Ne pas toucher le gazon avec des outils courtes après l'utilisation de cette machine.
- Si vous utilisez les instructions dans les sections Entretien et Entretien du tracteur.
- Si vous suivez un programme régulier d'entretien, et d'utilisation du tracteur.
- Lisez et observez les règles de sécurité.

RESPONSABILITES DU CLIENT

Il existe un contrat d'entretien Séasipourceproduit. Contactez-le maintenant. Séasipourceproduit déclare pour des informations supplémentaires.

CONTRAT D'ENTRETIEN

Veuillez lire et conserver ce manuel. Les instructions qui contiennent vos permis sont de monter, et d'entretenir correctement votre tracteur. Déservrez toujours les "RÈGLES DE SECURITE".
Veuillez lire et conserver ce manuel. Les instructions qui contiennent vos permis sont de monter, et d'entretenir correctement votre tracteur. Déservrez toujours les "RÈGLES DE SECURITE".
Pour faire l'entretien et la réparation de ce tracteur,
trouvez des techniciens qualifiés équipés des outils appropriés
qui suivent un problème que vous ne pouvez pas résoudre,
contacter le centre d'entretien autorisé le plus proche. Vous y
trouverez l'entretien et la réparation de ce tracteur.
Si vous avez un problème que vous ne pouvez pas résoudre,
telle que la fuite d'eau pour assurer un rendement et une sûreté
maximum.

FELICITATIONS pour votre achat. Ce tracteur a été conçu, per-

* Vous pouvez utiliser de l'essence contenant jusqu'à 10% d'éthanol (E10) avec cet appareil. L'utilisation d'essence contenant plus de 10% d'éthanol annule la garantie du produit.

Capacité de type	11,35 L / 3 Gallons	d'essence
Type d'huile	SAE 30 (supérieure de 32°F/0°C)	(API: SJ-SN): SAE 5W30 (inférieure de 32°F/0°C)
Capacité d'huile	1,89 L/64 Oz.	AVec un filtre: 1,77 L/60 Oz.
Bougie d'allumage:	QC12YC	(Ecart: .030"/0,76 mm)
Système de chargement:	16 Ampères @ 3600 RPM	Chargement: 16 Ampères @ 3600 RPM
Batterie:	Amp/Hr: 28	Min. CCA: 230
Couple de rotation	62-75 Nm	au boulon de lame: (45-55 Ft. Lbs.)
* Vous pouvez utiliser de l'essence contenant jusqu'à 10% d'éthanol (E10) avec cet appareil. L'utilisation d'essence contenant plus de 10% d'éthanol annule la garantie du produit.		

REGLES DE SECURITE

DANGERS : CET TRACTEUR PEUT AMPUTER LES MAINS, LES PIEDS ET PROJETER DES OBJETS. L'INOBRESERVATION DES REGLES DE SECURITE SUIVANTES PEUT ETRE LA CAUSE DE BLESSURES SERIEUSES ET MEMES MORTELLES.

Conseils pour l'admission en toute sécurité des enfants

cacher un enfant à la vue.

- Faites extrêmement attention et éteignez le moteur si un enfant penètre dans la zone.
- Regardez toujours s'il y a pas d'enfants en bas âge vers le bas et vers l'arrière avant de prendre la marche arrière.
- Ne transportez jamais d'enfant même si les lampes ne tournent pas. Ils pourraient tomber et se blesser gravement ou gêner le fonctionnement de la machine.
- Transportez toujours avec une personne supplémentaire dans la zone de toutefois pour faire une autre tour d'école ou de révélations près d'une zone de toute autre.
- N'oubliez jamais les enfants utilisés par la machine.
- Faites extrêmement attention à proximité des angles morts, des arbres ou d'autres objets susceptibles de déclencher l'alarme.

- Des accidents tragiques peuvent avoir lieu si l'opérateur ne fait pas assez attention en présence d'enfants. Les enfants sont souvent très attirés par la machine et par la rotule. Ne croyez jamais que les enfants restent immobiles si l'endroit où vous venez de les laisser. Les enfants dorivent se tenir hors de la zone de tombe et sous la supervision d'un adulte responsable, **autre que l'opérateur.**

AVERTISSEMENT : LES ENFANTS PEUVENT ÊTRE GRAVEMENT BLESSÉS OU TUÉS PAR CET ÉQUIPEMENT. Lisez attentivement et respectez toutes les consignes de sécurité ci-dessous.

**AVERTISSEMENT : LES ENFANTS PEUVENT ÊTRE
BLESSÉS PAR CET ÉQUIPEMENT.** L'American
Academy of Pediatrics recommande que les enfants
soient âgés d'au moins 12 ans avant de pouvoir
utiliser une tondeuse à condutteur à pied et d'au
moins 16 ans dans le cas d'un tracteur à gazon.

L'ÉNÉGANT

Les bornes des batteries, ainsi que toutes les bornes et leurs accessoires contenant du plomb, des dérivés du plomb ou des produits chimiques à base de plomb, sont reconvertis dangereux par l'Etat de la Californie, sorte de cancérogènes ou tératogènes ou responsables d'autres troubles de la reproduction. Lavez-vous soigneusement les mains après les avoir touchées.

AVERTISSEMENT: Les gaz d'échappement contiennent des véhicules chimiques reconnus dangereux pour l'Etat de la Californie, parce que certaines substances peuvent causer des maladies cancéreuses ou tératogènes ou responsables d'autres troubles de la reproduction.

Avertissement: Remorduez vous de la recommandation de votre tracteur. Les accessoires recommandés par le fabricant de votre tracteur sont spécifiquement conçus pour ce tracteur. Utilisez ces recommandations du fabricant de votre tracteur. Utilisez les accessoires recommandés par le fabricant de votre tracteur. Utilisez les recommandations du fabricant de votre tracteur. Utilisez les recommandations du fabricant de votre tracteur.

AVERTISSEMENT: Ne descendez pas les pentes à point mort, vous pourriez perdre la commande du tracteur.

AVERTISSEMENT: Débranchez toujours le fil de bougie d'allumage et pour prévenir les démar- rages accidentels, posez-le de telle façon qu'il ne puisse pas entrer en contact avec la bague d'allumage lors de l'installation, du transport, des ajustements ou des réparations.


Sears Canada, Inc., Toronto, Ontario M5B 2B8

* La puissance nominale indiquée par le fabricant du moteur est la puissance brute moyenne (à un régime en t/min spécifique) d'un moteur de production type pour le modèle de moteur mesuré selon les normes SAE pour la puissance brute du moteur. Se reporter au fabricant du moteur pour tous les détails.

- Montage
- Utilisation
- Entretien
- Révision et Régages

TRACTEUR DE PELOUSE
AUTOMATIQUE
TONDEUSE DE 117 CM (46 PO.)
DÉMARAGE ÉLECTRIQUE
23 C.V.*

CRAFTSMAN



944.10134
MODÈLE
NUMERO DE
L'OPÉRATEUR
MANUEL DE
SEARS

IMPORTANT:
Lisez et suivez le
modèle d'emploi et
toutes les règles
de sécurité avant
d'utiliser cet
équipement